





Assistenza Tecnica After Sales Service Service Apres Vente Kundendienst Servicio Post-Venta

ROSIERES 

CUISINIÈRES / TRIO

39353339 4040DBDEF

Service Manual



**Mod: 39353339 4040DBDEF 9905 (27/01/1999)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
1b	Carcasse four chauff.plats	93630267		
2	Revetement four	93660926		
5	Decharge gaz	93631158		
6a	Cheminee complete - DR.	93675957		
6b	Cheminee complete - GA.	93676302		
7a	Protection posterieure	93629327		
7c	Paroi isolante poster.-DR	93682367		
7d	Paroi isolante poster.-GA	93682359		
12	Bordure superieure	93660082		
14	Pied complete	93626364		
15a	Socle posterieure	93630291		
16	Extremite laterale gauche	93646164		
17	Extremite laterale droite	93646172		
19	Patin glissiere tiroir	93631125		
20	Tiroir chauffage plats	93627834		
21a	Contreporte chauffe-plat	93616639		
21h	Porte chauffe-plat - DR.	93668291		
21i	Porte chauffe-plat - GA.	93658706		
24	Tablette four	93710887		
24e	Tablette four -G	93594422		
25c	Grille supp.tablette four	93768364		
25f	Grille four - DR	93633980		
26b	Bordure infer.piece fron.	93660991		
31a	Tableau de bord en metal	93906741		
32c	Pare-chocs caoutchouc	93387975		
34	Panneau lateral emaille'	93658748		
35	Extrem.lat.DR pour rebord	93660272		
36	Extrem.lat.GA pour rebord	93660264		
37	Rebord	93660959		
39	Table travail emaille	93700888		
39g	Bordure lat.droi.p.table	93661627		

**Mod: 39353339 4040DBDEF 9905 (27/01/1999)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piec E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
39h	Bordure lat.gauc.p.table	93661619		
40d	Arret droite p.couvercle	93631869		
40e	Arret gauche p.couvercle	93631851		
48	Lampe interieure four	93665370		
60	Grille 2 F	93782236		
64a	Couv.tete du bruleur rap.	93680569		
64c	Couv.tete du br.demi-rap.	93654481		
64d	Couv.tete du br.ultrarap.	93656874		
64d	Couv.tete du br.ultrarap.	93594190		
65a	Support bruleur rapide	93647857		
65b	Support bruleur demi-rap.	93647709		
65c	Support brul.ultra rapide	93673507		
66a	Regulat.d'air brul.rapide	93618783		
66b	Regul.d'air br.demi-rapi.	93618775		
66d	Regul.d'air brul.ultrara.	93647899		
67	Boite allumage electroni.	93748200		
68c	Bougie dallumage el.L500	93645422		
70	Ressort bougie allumage	93629301		
71	Anneau benzing	93531945		
71a	Ressort arret bougie all.	93666394		
74	Set injecteurs gaz liqui.	93924595		
74b	Set injecteurs gas natur.	93924603		
75	Support injecteur plaque	93463941		
80	Manette	93672152		
80f	Manette commut./thermost.	93662690		
83	Rosette thermostat gas	93661890		
85a	Thermostat electrique	93682722		
90a	Commutateur four	93757789		
91	Robinet plan de travail	93657849		
92d	Tuyau bruleur anterie. DR	93660124		
92e	Tuyau bruleur posterie.DR	93660132		

**Mod: 39353339 4040DBDEF 9905 (27/01/1999)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
92f	Tuyau bruleur anterie. GA	93660157		
92g	Tuyau bruleur posterie.GA	93660140		
96	Tuyau distribution gas	93660306		
97b	Joint pour porte-caoutch.	93409514		
97l	Raccord coud conique	93580769		
104	Douille four	93642700		
106a	Lampe temoin orange	93594513		
106b	Lampe temoin rouge	93477255		
109a	Manchon pussoir	93415164		
110	Microdeviateur all.elect.	93463131		
111	Microinterrupteur	93477636		
111b	Microinterrupteur bloque	93664811		
116	Resistance grilloir	93767291		
116b	Resist. grille el.-2000 W	93767523		
119	Resistance four	93696821		
119f	Resistance four -DR	93700953		
120	Support pour resistance	93706406		
127	Plaque patisserie	93617223		
127a	Grille supp.plaque patis.	93632537		
128a	Bruleur demi-rapide	93653848		
128b	Bruleur rapide	93649911		
128c	Bruleur ultrarapide	93653855		
131	Boite a bornes	93884666		
131b	Boite a' bornes - GA.	93520765		
132	Motoventilateur	93639110		
133	Helice	93503597		
136	Protection helice	93629228		
155	Pivot sortie panier four	93618742		
155a	Plaquette posterieu.pivot	93382216		
171	Joint horizontal	93633964		
173	Joint trois cotes	93628147		

**Mod: 39353339 4040DBDEF 9905 (27/01/1999)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
173a	Joint quatre cotes	93616647		
175	Contreporte four	93661015		
176	Verre interie.porte four	93632792		
176b	Verre centrale porte four	93582021		
176c	Epaisseur verre centrale	93617066		
178	Verre porte four	93573830		
178a	Porte four - exterieure	93628741		
179	Poignee porte four	93702652		
182b	Bordure infer.porte four	93640258		
184a	Charniere porte droite	93703924		
184b	Charniere porte gauche	93703932		
185	Support charniere p/four	93758795		
193	Protection chaleur	93657781		
203	Socle	93630259		
208	Passefil	93592061		
221	Plaque fixation robinet	93404325		
222	Joint pour robinet	93457513		
247	Panneau autonettoy.droite	93907152		
247a	Panneau autonettoy.gauche	93907145		
249	Bougie dallumage p/grill	93629293		
251a	Ecrou fixat. thermocouple	93664449		
257	Thermocouple L.600	93594455		
257c	Thermocouple L.330	93742815		
269	Equerre sup. paroi post.	93627511		
278a	Equerre DR supp. rouleau	93584712		
278b	Equerre GA supp. rouleau	93584704		
291	Equerre fixat.resistance	93621647		
292	Pivot a' vis	93628824		
293	Joint verre interieure	93617090		
297	Poignee p.tablett.four UK	92950468		
298	Crochet pour tabl.four UK	92890953		

**Mod: 39353339 4040DBDEF 9905 (27/01/1999)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
349	Rondelle pour poignee	93628634		
1002	Galet superieur	93903854		
1002a	Galet inferieur	93903862		
1003	Rail de panier	93633196		
1004	Glissiere droite	93380079		
1004a	Glissiere gauche	93567212		
1005a	Panier sortant four	93903847		
1019	Support verre	93629434		
1020	Distancier	93617074		
1023a	Collerette commut.four DR	93665917		
1023b	Collerette commut.four GA	93662260		
1039a	Sachet de pontets	93527422		
1063a	Regulat.air brul.viande	93463891		
1065	Dessus de cuisson	93906584		
1065a	Coup de feu	93860245		
1065b	Plaque pour viandes	93595049		
1065c	Protection infer.plaque	93660363		
1067	Avant de dosseret	93723500		
1068	Plaquette sigle	93747582		
1069	Plaquette posit.bruleurs	93477453		
1070	Outil decentrage	93445500		
1071a	Corp de bruleur viandes	93586584		
1072	Robinet bruleur viandes	93663581		
1072a	Tuyau bruleur viandes	93661643		
1073	Support bruleur viandes	93661536		
1074	Separateur anterieur	93666105		
1074a	Separateur posterieur	93659951		
1075b	Equerre obturatrice	93662989		
1076	Ecran interieure	93666022		
1078	Rondelle steatite	93633725		
1203	Pion accrochage	93582518		



Mod: 39353339 4040DBDEF 9905 (27/01/1999)

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
1207	Support	93675536		
1210	Protection laterale gauche	93672400		

	0	1	2	3	4	5
P3	5	●	●	●	●	
P1	1		●	●	●	
P2	4	●	●	●	●	

