


11. Styling Sheets

11-1 Rembrandt 32"


REMBRANDT 32"



Pos Nbr	Description	Remarks
1085	Remote Control	Not displayed
0004	Front Cabinet	
0012	Rear Cover	
0017	Flare bottom	
0021	I/O bracket side	
0024	I/O bracket bottom	
0029	Switch bracket	
0260	Stand	

11-2 Rembrandt 37" & 42"


REMBRANDT 37" & 42"



Pos Nbr	Description	Remarks
1085	Remote Control	Not displayed
0004	Front Cabinet	
0012	Rear Cover	
0017	Flare bottom	
0021	I/O bracket side	
0024	I/O bracket bottom	
0029	Switch bracket	
0260	Stand	

11-3 Van Gogh 32" - 52"


VAN GOGH 32" - 52"



Pos Nbr	Description	Remarks
0004	Front Cabinet	
0260	Stand	
0018	Flare Van Gogh	
0029	Switch bracket	
0012	Rear Cover	
0026	Mounting bracket x 4	Only for screen size 40"
0018	Leading edge cover	
0021	I/O bracket side	
0024	I/O bracket bottom	
0154	Speaker bracket	Not displayed only for screen size 46" & 52"
1085	Remote Control	Not displayed

11-4 Matisse 32" - 46"

MATISSE 32" - 46"



Pos Nbr	Description	Remarks
0260	Stand	
0004	Front Cabinet	
1004	Display panel	
0029	Switch bracket	
0010	Rear Cover (with left & right diffuser)	
0018	Leading edge cover	
0021	I/O bracket side	
0024	I/O bracket bottom	
0189	Front Cabinet Locking Bracket 40"	Not displayed
0162	Mid High Speaker Interface bracket 32"	Not displayed
1085	Remote Control	Not displayed