

## DISASSEMBLY

### 1 ) ACCESSIBILITY

#### 1.1 ) Front Panel

a) Remove six screws that fix the front panel.



b).Pull down the front panel as it shown in the Picture.

