

Gebrauchsanweisung
 (D,GB,F,NL,I,E)
 52 0891


1) 16 7354

Düsensätze:

Flüssiggas 50mbar
 26 4032

Flüssiggas 30mbar
 16 7552

Erdgas E20mbar
 16 7553



- 1) 16 6325
- 2) 26 3933
- 3) 02 7479
- 4) 16 7284
- 5) 16 7363
- 6) 16 6653