


SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl

HERDE
Einzelbackofen



Gebrauchsanweisung
58 7570 (fr)

Montageanweisung
58 6500
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ331000
Backblech emailliert
HZ331010
Backblech Antihaft
HZ332000
Universalpfanne
HZ332010
Universalpfanne
Antihaft
HZ333000
Profipfanne
HZ333001
Deckel f. Profipfanne
HZ334000
Kombirost
HZ324000
Einlegerost
HZ325000
Grillblech 2-teilig
HZ336000
Glaspfanne
HZ26001
Backform
Auslaufsicher


1) 01 4254



SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl

HERDE
Einzelbackofen




- 1) 49 0541
Set
- Zubehoer:
 - HZ317000
Pizzaform
 - HZ9150
Glasbraeter
 - HZ26000
Metallbraeter
 - HZ338200
Teleskopauszug
2-fach
 - HZ338300
Teleskopauszug
3-fach
 - HZ338305
Teleskop-Vollauszug
3-fach
 - HZ390800
breiter Braeter

SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl


HERDE
Einzelbackofen



SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl

HERDE
Einzelbackofen




1) 42 0735

SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl

HERDE
Einzelbackofen



SIEMENS

HB430220F/01-V01, weiss
HB430620F/01-V02, schwarz
HB430520F/01-V03, Edelstahl

HERDE
Einzelbackofen

