



Mat. – Nr. – Konstante  
3740 . . . . .  
Gebrauchsanweisung  
58 8382 (en)

Montageanweisung  
58 6500  
(de,en,fr,it,nl,da,sv,no  
fi,es,pt,el,cs,pl,tr,ru)


Zubehoer:  
HZ331070  
Backblech emailliert  
HZ331010  
Backblech Antihaft  
HZ332070  
Universalpfanne  
HZ332010  
Universalpfanne  
Antihaft











1) 42 2707

