


Gebrauchsanweisung  
52 2675  
(DE,FR,IT,NL,SE,NO,  
FI)


Zubehör:

- HZ 24010
- Backblech Alu
- HZ 24150
- Backblech emailliert
- HZ 22550
- Grillblech
- HZ 24350
- Universalpfanne
- HZ 24400
- Kombirost
- HZ9150
- Glasbräter

1) 02 0943



1) Befestigungssatz  
06 9488



- 1) Typenschild  
51 9252
- 2) 35 0811  
Kompl.
- 3) 21 4386  
Kompl.

