

Service  
Service  
Service



Philips Domestic Appliances and Personal Care

# Service Manual

## PRODUCT INFORMATION


### Features :

- Adjustable attachment comb for even cutting result.
- 7 hair length settings from 4 to 21 mm.
- Maintenance free cutting element; no oiling required.
- Width cutting unit 32 mm.
- Rechargeable for cordless operation.
- Mains operation possible for trimming when batteries are empty.
- AC/DC adapter.
- Charging time ( empty → full ) 12 hours.
- Operation time ( full → empty ) 30 minutes.

**Product meets the requirements regarding interference suppression on radio and TV.**





**TO REPLACE TRIMMER CLAMP (5)**




**TO REPLACE BATTERY (6)**

- Remove styling comb (2)
- Remove cutter (1)
- Remove trimmer clamp (5)
- Remove screw "A"
- Open housing



Dimensions screw A : 2.2 x 6



Pos	Description	Service code
1	Cutter	4822 690 10212
2	Adjustable comb	4822 690 10203
3	Cleaning brush	4822 479 30183
4	Styling comb	4822 690 30433
5	Trimmer clamp	4203 035 71060
6	Battery (NiCd)	4822 138 10336
7	AC/AD adapter EURO	4822 690 30441
	AC/AD adapter UK	4822 690 30442
	AC/AD adapter USA	4822 690 30443
	AC/AD adapter CDN	4822 690 30444
	AC/AD adapter JPN	4822 219 10148
	AC/AD adapter AUS	4822 219 10149
	AC/AD adapter TWN	4822 219 10151
	AC/AD adapter KOR	4822 219 10152
8	Scissors	4822 690 30434
	Dir. for use: UK, D, N, S, SF, DK, GR	4203 035 74180
	Dir. for use: UK, D, F, NL, E, P, I, TR	4203 035 74190
	Dir. for use: UK, Russian, Polish, Estonian, Latvian, Lithuanian	4203 035 74200
	Dir. for use: UK, Russian, Ukrainian, Croatian, Slovenian, Czech, Slovak, Hungarian, Rumanian	4203 035 74210
	Dir. for use: Japan	4203 035 74220
	Dir. for use: UK, Arabic, Farsi, E, Brazilian, F	4203 035 74230
	Dir. for use: UK, S-Chinese, T-Chinese, KOR, Malay, Bahasa-Indonesia, Vietnamese	4203 035 74250
	Dir. for use: USA	4203 035 74240