

9. Exploded View of the Set




Figure 9-1

HTS3115**MISCELLANEOUS**

0110	3139 244 13501	COVER CD TRAY HTS3115
0127	3139 244 10091	KNOB VOLUME HTS3455 CHROME
0151	2422 549 00493	DVD LOADER WXD-8829(Y) B
0152	2422 549 00629	DVD MECHANISM KHM-313AAA Y
0331	2422 076 00546	FM AERIAL 24AWG BK B
0332	2422 549 45813	ANT AM LOOP 039S20014 B
0333	2422 549 00934	REMOTE CONTR HTS3440/3450 B
0336	2422 070 98236	△ MAINSCORD UK 5A 1M8 VH BK B /05
0336	4822 321 11499	△ MAINSCORD 2.0M - EU /12
0342	2422 076 00468	△ CBLE SCART 1M1 SCART 21P BK B
0900	3143 027 65491	FRONT ASSY HTS3115
0920	3143 027 64021	FRAME ASSY HTS3455
1020	3139 248 00181	LOADER ASSY WXD8829 KHM313 RX
1030	3139 247 12711	MODULE PSU 06T400M EU
1040	2422 542 00031	TUN A F ENG07806QRF EUR B
1050	3139 247 12251	MODULE AMP-05-02 500W
1060	3139 248 50291	PCBAS FRONT HTS3115 EU
1080	2822 031 00048	FAN 12VDC 0.5W 3700RPM B
1090	3139 248 50301	PCBAS MONO HTS3115 EU
1101	3139 241 00341	FFC FOIL 24P/220/24P AD 0.5MMP
8001	3139 241 01381	FFC FOIL10P/120/10P AD FOLD
8005	3139 241 02011	FFC FOIL 20P/140/20P AD

SPK ASSY SW-3110

9965 000 35004	SW3105 SUBWOOFER BOX
9965 000 34997	RUBBER FOOT SW
9965 000 34998	CABLE A'SSY 5.3M PURPLE SMK

SPK ASSY C-3110

9965 000 35003	SPEAKER BOX CENTER
9965 000 34995	RUBBER FOOT 39.5LX5.5WX2T
9965 000 34994	CABLE A'SSY 5.2M GREEN SMK S

FRONT SATELLITE SPEAKER

9965 000 36534	SPEAKER BOX FRONT-L
9965 000 36535	SPEAKER BOX FRONT-R
9965 000 34987	CABLE A'SSY 5.2M WHITE SMK
9965 000 34988	CABLE A'SSY 5.2M RED SMK
9965 000 36536	RUBBER FOOT

REAR SATELLITE SPEAKER

9965 000 35390	SPEAKER BOX REAR-L
9965 000 35391	SPEAKER BOX REAR-R
9965 000 34989	CABLE A'SSY 5.2M BLUE SMK
9965 000 34990	CABLE A'SSY 5.2M GREY SMK
9965 000 35392	RUBBER FOOT
9965 000 35393	RUBBER FOOT