



MECHANICAL PART LIST

Main Unit

LOC.	PART NO.	Description
1	996510001254	DISPLAY LENS
2	996510001661	FRONT ASSY
3	996510001256	STANDY BUTTON
4	996510001257	OPEN/CLOSE BUTTON
5	996510001662	STANDY LED LENS
6	996510003634	OPEN /CLOSE BUTTON HOLDER
7	996510001663	FUNCTION BUTTON RING
8	996510001664	VOLUME KNOB RING
9	996510001261	VOLUME KNOB RING
10	996510001262	FUNCTION BUTTON
11	996510003633	DVD DOOR
12	996510003635	SOURCE BUTTON
13	996510003636	SOURCE BUTTON HOLDER
15	996510003637	VFD FILTER
18	996510007181	BOTTOM CAB
23	996510008394	BACK PANEL for /12
23	996510008396	BACK PANEL for /05
25	996510001615	FAN COVER
26	996510008395	TOP CAB
27	994000065305	RUBBER FOOT D14XT3.0MM W/ADV
28	996510003675	PVC SHEET
34	996510007174	DVD LOADER MODULE
35	996510001659	POWER BOARD
36	996510001658	MAIN BOARD
37	996510001660	SCART BOARD
38	996510001607	TUNER PACK
39	996510003638	POWER CORD for /12
39	996510003775	POWER CORD for /05
A1	996510007314	CONTROL+USB+PJACK+STANDBY+BKT LOOP ANT
AM	996510001621	FM ANTENNA
FM	996510023583	FM ANTENNA 1000MM 1007#24 TC
CN301	996510000673	FFC CABLE 10P 100MM P1.25MM
CN801	996510007319	FFC CABLE 24P 180MM
RC	996510001649	REMOTE CONTROL
STEREO	996510001598	STEREO CABLE
SCART	996510001650	SCART CABL
LSCREW	996510009092	LINK SCREW

Speaker

LOC.	PART NO.	Description
SPKC	996510009246	SPEAKER BOX -CENTER
SPKFL	996510009247	SPEAKER BOX -FRONT LEFT
SPKFR	996510009248	SPEAKER BOX - FRONT RIGHT
SPKRL	996510009249	SPEAKER BOX- REAR LEFT
SPKRR	996510009250	SPEAKER BOX- REAR RIGHT
SUBW	996510009251	SUBWOOFER
JACKC	996510009240	JACK CONNECTOR PA GREEN center
JACKFL	996510009241	JACK CONNECTOR PA WHITE FL
JACKFR	996510009242	JACK CONNECTOR PA RED F-R
JACKRL	996510009243	JACK CONNECTOR PA BLUE S-L
JACKRR	996510009244	JACK CONNECTOR PA GREY S-R
JACKS	996510009245	JACK CON PA PURPLE s.subwoofer
RFC	996510001599	RUBBER FOOT -CENTER SPK
RFF	996510001600	RUBBER FOOT-FRONT SPK
RFR	996510001601	RUBBER FOOT - REAR SPK
RFS	996510003838	RUBBER FOOT -REAR
RFS	996500028375	RUBBER FOOT