









| TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS | | | |
|---|--|----------|--|
| Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux. | DANFOSS NLX 10KK 0462 7,5 18,1 17,3 | | |
| Klape Therm./Thermostat/Termostat Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm' | kalt warm | | |
| Füllmenge/Fill. quantity/Charge/Carga R600 | g | 55 | |
| Anschlusswert/Comm. load/Puiss. Connect./Potenc. | W | 150 | |
| Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia | KW W | 190/240V | |
| Ventilator/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia | | 2W | |