


5 Exploded View and Parts List

- You can search for updated part codes through ITSELF web site.
URL : <http://itself.sec.samsung.co.kr/>

5-1 LE32R32B Exploded View



5 Exploded View & Parts List

5-2 LE32R32B Parts list

| Location | Code.No | Item & Specification | Q'ty | SA/SNA | Remark |
|----------|-------------|--|------|--------|--------|
| T0003 | BN96-04423A | ASSY COVER P-FRONT;ROME-5,32EO,ABS,HB,BK | 1 | S.A | |
| M0215 | BN07-00276A | LCD-PANEL;CLAA320WA01,8bit/60Hz,743*447* | 1 | S.A | |
| T0447 | BN96-04526A | ASSY BRACKET P-PANEL;ROME-5,32EO,OLD CPT | 1 | S.N.A | |
| M0146 | BN61-02872A | BRACKET-PANEL SIDE;ROME V 32",SECC,T1.2, | 1 | S.N.A | |
| M0146 | BN61-02873A | BRACKET-PANEL SIDE;ROME V 32",SECC,T1.2, | 1 | S.N.A | |
| M0014 | BN94-01128A | ASSY PCB MAIN;LE32R32BX/* | 1 | S.A | |
| T0159 | BN96-02583A | ASSY PCB P-SMPS;Free Voltage SMPS,GTR32K | 1 | S.A | |
| T0279 | BN63-02959A | COVER-JACK;ROME(2)-5,32,HIPS,T3.0,-,-,HB | 1 | S.N.A | |
| M0013 | BN96-04424A | ASSY COVER P-REAR;ROME-5,32EO,HIPS,HB,GR | 1 | S.A | |
| M0115 | BN61-01525A | BRACKET-STAND LINK;32,ROME,SECC,T1.6 | 1 | S.N.A | |
| M0013 | BN96-01733B | ASSY STAND P-BASE;ROME3,32,HIPS,HB,GR503 | 1 | S.A | |