


5. Exploded View & Part List


5-1 PS50C6500TWXXC Exploded View



■ Part List

Loc. No.	Part No.	Description;Specification	Qty.	SNA	Remark
F001	BN63-06478D	COVER-FRONT;50PC6500,PC(Clear)+PC(Charco	1	SNA	
F001A	BN96-12992D	ASSY COVER P-FRONT;PC6500 50,PC(Clear)+P	1	SA	
FB21A	BN96-14336B	ASSY BOARD P-TOUCH FUNCTION&IR;PC6500,CT	1	SA	
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	SNA	
M0014	BN94-03359A	ASSY PCB MISC-MAIN;C6500	1	SA	△
R001A	BN96-13008J	ASSY COVER P-REAR;PC6500/PC7000 50,PCM,T	1	SA	
SB04A	BN96-13025A	ASSY STAND P-BASE;PC7000 50,SUS T0.6	1	SA	
SG03A	BN96-13019B	ASSY STAND P-GUIDE;50 PC7000,SUS T0.6	1	SA	
SP01A	BN96-12941K	ASSY SPEAKER P;8ohm,4pin,10,L:250 R:670,	1	SA	
SP01A	BN96-13273A	ASSY SPEAKER P;4ohm,4pin,20W,R:750,Enclo	1	SA	
U001A	BN96-13441A	ASSY PDP MODULE P;S50FH-YB07,PL50FF017B,	1	SA	△

5-2 PS50C6500TWXXH Exploded View



■ Part List

Loc. No.	Part No.	Description;Specification	Qty.	SNA	Remark
F001	BN63-06478D	COVER-FRONT;50PC6500,PC(Clear)+PC(Charco	1	SNA	
F001A	BN96-12992D	ASSY COVER P-FRONT;PC6500 50,PC(Clear)+P	1	SA	
FB21A	BN96-14336B	ASSY BOARD P-TOUCH FUNCTION&IR;PC6500,CT	1	SA	
HC001	BN61-04922A	HOLDER-CORD;LB7000 46,ABS,V0,BLK	1	SNA	
M0014	BN94-03359A	ASSY PCB MISC-MAIN;C6500	1	SA	△
R001A	BN96-13008J	ASSY COVER P-REAR;PC6500/PC7000 50,PCM,T	1	SA	
SB04A	BN96-13025A	ASSY STAND P-BASE;PC7000 50,SUS T0.6	1	SA	
SG03A	BN96-13019B	ASSY STAND P-GUIDE;50 PC7000,SUS T0.6	1	SA	
SP01A	BN96-12941K	ASSY SPEAKER P;8ohm,4pin,10,L:250 R:670,	1	SA	
SP01A	BN96-13273A	ASSY SPEAKER P;4ohm,4pin,20W,R:750,Enclo	1	SA	
U001A	BN96-13441A	ASSY PDP MODULE P;S50FH-YB07,PL50FF017B,	1	SA	△

5-3 PS50C6500TWXXC Service Item

Loc. No.	Part No.	Description;Specification	Qty.	Remark
R001A	BN96-13008J	ASSY COVER P-REAR;PC6500/PC7000 50,PCM,T	1	
SP01A	BN96-12941K	ASSY SPEAKER P;8ohm,4pin,10,L:250 R:670,	1	
F001A	BN96-12992D	ASSY COVER P-FRONT;PC6500 50,PC(Clear)+P	1	
FB21A	BN96-14336B	ASSY BOARD P-TOUCH FUNCTION&IR;PC6500,CT	1	
EC13	BN39-01267H	LEAD CONNECTOR;PN50C8000YFXZA,Flat Conne	1	
P001A	BN44-00333A	DC VSS-PDP TV;PZ-5A,AC/DC,AC100~240V,50/	1	△
M0014	BN94-03359A	ASSY PCB MISC-MAIN;C6500	1	△
ET01	BN40-00172A	TUNER;DTOS40CVH081A,DVB-T/C,164CH,38.9MH	1	
EC11	BN96-09872S	ASSY POWER CORD;16A/250V, IEC,LP-33R,Y,P	1	△
FL06	BN96-12723U	ASSY CABLE P-FPCB LVDS CABLE;PDP 50 U/SL	1	
SP01A	BN96-13273A	ASSY SPEAKER P;4ohm,4pin,20W,R:750,Enclo	1	
U001A	BN96-13441A	ASSY PDP MODULE P;S50FH-YB07,PL50FF017B,	1	△
T0941	BN96-12958A	ASSY PDP P-E-BUFFER BOARD;S50FH-YB05,PL5	1	
T0942	BN96-12959A	ASSY PDP P-F-BUFFER BOARD;S50FH-YB05,PL5	1	
UX03A	BN96-12960A	ASSY PDP P-X-MAIN BOARD;S50FH-YB05,PL50F	1	△
UX03A	BN96-12961A	ASSY PDP P-X-MAIN BUFFER BOARD;S50FH-YB0	1	
UY04A	BN96-12962A	ASSY PDP P-Y-MAIN BOARD;S50FH-YB05,PL50F	1	△
UL01A	BN96-12964A	ASSY PDP P-LOGIC MAIN BOARD;S50FH-YB05,P	1	
	BN96-14114A	ASSY PDP P-Y-SCAN BUFFER BOARD;S50FH-YB0	1	
T0214	AA61-20285C	HOLDER-BOX;CORAL,PP,BLACK,HB,17.5g	4	
M0114	BN39-01154C	CBF SIGNAL;Chelsea Slim, STEREO Plug to	1	
M0114	BN39-01154F	CBF SIGNAL;UE40B7000WWXXC,24P/20P,30AWG,	1	
M0114	BN39-01154H	CBF SIGNAL;UE40B7000WWXXC,RCA 3PIN,30AWG	1	
REMO2	BN59-01039A	REMOCON;TM1060,SAMSUNG,20PIN SINGLE,49KE	1	
M9889	BN63-01798B	CLOTH-CLEAN;cloth,180,200,sea blue,ToC	1	
EH02A	BN96-10810A	ASSY HOLDER P;09 LEDTV MODEL,NYRON	1	
SG03A	BN96-13019B	ASSY STAND P-GUIDE;50 PC7000,SUS T0.6	1	
SB04A	BN96-13025A	ASSY STAND P-BASE;PC7000 50,SUS T0.6	1	

5-4 PS50C6500TWXXH Service Item

Loc. No.	Part No.	Description;Specification	Qty.	Remark
R001A	BN96-13008J	ASSY COVER P-REAR;PC6500/PC7000 50,PCM,T	1	
SP01A	BN96-12941K	ASSY SPEAKER P;8ohm,4pin,10,L:250 R:670,	1	
F001A	BN96-12992D	ASSY COVER P-FRONT;PC6500 50,PC(Clear)+P	1	
FB21A	BN96-14336B	ASSY BOARD P-TOUCH FUNCTION&IR;PC6500,CT	1	
EC13	BN39-01267H	LEAD CONNECTOR;PN50C8000YFXZA,Flat Conne	1	
P001A	BN44-00333A	DC VSS-PDP TV;PZ-5A,AC/DC,AC100~240V,50/	1	△
M0014	BN94-03359A	ASSY PCB MISC-MAIN;C6500	1	△
ET01	BN40-00172A	TUNER;DTOS40CVH081A,DVB-T/C,164CH,38.9MH	1	
EC11	BN96-09872S	ASSY POWER CORD;16A/250V, IEC,LP-33R,Y,P	1	△
FL06	BN96-12723U	ASSY CABLE P-FPCB LVDS CABLE;PDP 50 U/SL	1	
SP01A	BN96-13273A	ASSY SPEAKER P;4ohm,4pin,20W,R:750,Enclo	1	
U001A	BN96-13441A	ASSY PDP MODULE P;S50FH-YB07,PL50FF017B,	1	△
T0941	BN96-12958A	ASSY PDP P-E-BUFFER BOARD;S50FH-YB05,PL5	1	
T0942	BN96-12959A	ASSY PDP P-F-BUFFER BOARD;S50FH-YB05,PL5	1	
UX03A	BN96-12960A	ASSY PDP P-X-MAIN BOARD;S50FH-YB05,PL50F	1	△
UX03A	BN96-12961A	ASSY PDP P-X-MAIN BUFFER BOARD;S50FH-YB0	1	
UY04A	BN96-12962A	ASSY PDP P-Y-MAIN BOARD;S50FH-YB05,PL50F	1	△
UL01A	BN96-12964A	ASSY PDP P-LOGIC MAIN BOARD;S50FH-YB05,P	1	
	BN96-14114A	ASSY PDP P-Y-SCAN BUFFER BOARD;S50FH-YB0	1	
T0214	AA61-20285C	HOLDER-BOX;CORAL,PP,BLACK,HB,17.5g	4	
M0114	BN39-01154C	CBF SIGNAL;Chelsea Slim, STEREO Plug to	1	
M0114	BN39-01154F	CBF SIGNAL;UE40B7000WWXXC,24P/20P,30AWG,	1	
M0114	BN39-01154H	CBF SIGNAL;UE40B7000WWXXC,RCA 3PIN,30AWG	1	
REMO2	BN59-01039A	REMOCON;TM1060,SAMSUNG,20PIN SINGLE,49KE	1	
M9889	BN63-01798B	CLOTH-CLEAN;cloth,180,200,sea blue,ToC	1	
EH02A	BN96-10810A	ASSY HOLDER P;09 LEDTV MODEL,NYRON	1	
SG03A	BN96-13019B	ASSY STAND P-GUIDE;50 PC7000,SUS T0.6	1	
SB04A	BN96-13025A	ASSY STAND P-BASE;PC7000 50,SUS T0.6	1	

MEMO