


5. Exploded View & Part List

5-1. UE32B6000VW Exploded View



5-1-1. UE32B6000VW Parts List

Location No.	Code No.	Description & Specification	Q'ty	S.A/S.N.A	Remark
T0003	BN96-11248A	ASSY COVER P-FRONT;LB6000 32,PC(CLR)+PC(1	S.A	
M0215	BN07-00737A	LCD-PANEL;T320FBE1-DB	1	S.A	
T0175	BN96-09470F	ASSY SPEAKER P;8ohm,4pin,15W,R:650 / L:4	1	S.A	
M0115	BN61-05486A	BRACKET-STAND LINK;UB6000 32inch,SECC,T2	1	S.N.A	
M0014	BN94-02662C	ASSY PCB MAIN-CNE;UE32B6000VWXXC	1	S.A	
M0523	BN96-11440A	ASSY STAND P-GUIDE;UB6000 32,PC+G/F,20%,	1	S.N.A	
M0013	BN96-11254A	ASSY COVER P-REAR;B7000 32,PCM T0.5,BKN-	1	S.A	
M0027	BN96-11245A	ASSY STAND P-BASE;B6000 32,PI50 X L96,GL	1	S.A	