















2-3 Accessories Supplied with Camcorder

Accessories	Description	Part No	Remark	Accessories	Description	Part No	Remark
	1. Lithium Ion Battery Pack	AD43-00136A AD43-00146A	Model standard of VP-D353i/XEU		8. USB Cable	AD39-00073A	Model standard of VP-D353i/XEU (VP-D352(i), VP-D353(i), VP-D354(i), VP-D355(i) only)
	2. AC Power Adapter (AA-E8 TYPE)	AD44-00090A	Model standard of VP-D353i/XEU		9. Software CD	AD46-00061A AD46-00082A	Model standard of VP-D353i/XEU (VP-D352(i), VP-D353(i), VP-D354(i), VP-D355(i) only)
	3. AC Cord	AD39-00078A	Model standard of VP-D353i/XEU		10. Lens Cover	AD97-07354B	Model standard of VP-D353i/XEU
	4. Audio/Video Cable	AD39-00001A	Model standard of VP-D353i/XEU		11. Lens Cover strap	AD72-00049A	Model standard of VP-D353i/XEU
	5. Instruction Book	AD68-00839G	Model standard of VP-D353i/XEU		12. S-Video Cable	AC39-42001Z	Model standard of VP-D353i/XEU
	6. Lithium Battery (CR2025)	AD43-10130H	Model standard of VP-D353i/XEU (VP-D353(i), VP-D354(i), VP-D355(i) only)		13. Memory Stick	1109-001221	Model standard of VP-D353i/XEU (VP-D353(i), VP-D354(i), VP-D355(i) only)
	7. Remote Control	AD59-00085A	Model standard of VP-D353i/XEU (VP-D353(i), VP-D354(i), VP-D355(i) only)		14. Scart Adapter		Model standard of VP-D353i/XEU