




N° VB7631F11 - VW7631F11
 VB7631F12 - VW7631F12
 VB7631F14 - VW7631F13
 VW7631F14



N° VB7631F11 - VW7631F11
 VB7631F12 - VW7631F12
 VB7631F14 - VW7631F13
 VW7631F14




LAVE-VAISSELLE
CUVE

GESCHIRRSPÜLER
BEHÄLTER


DISHWASHERS
WASHING CHAMBER

N° VB7631F11 - VW7631F11
 VB7631F12 - VW7631F12
 VB7631F14 - VW7631F13
 VW7631F14




* = Pas de pièce de rechange / Kein Ersatzteil / Not service part

N° VB7631F11 - VW7631F11
VB7631F12 - VW7631F12
VB7631F14 - VW7631F13
VW7631F14



* = Pas de pièce de rechange / Kein Ersatzteil / Not service part

N° VB7631F11 - VW7631F11
 VB7631F12 - VW7631F12
 VB7631F14 - VW7631F13
 VW7631F14



N° VB7631F11 - VW7631F11
 VB7631F12 - VW7631F12
 VB7631F14 - VW7631F13
 VW7631F14

