



**BOSCH**


WMV 4280–WMV4280FG/02–FG1  
WMV 4280–WMV4280AA/02–AA1  
WMV 4280–WMV4280FF/02–FF1  
WMV 4280–WMV4280SK/02–SK1

WMV 4280–WMV4280KJ/02–KJ1

WASCHGERÄTE  
Waschvollautomaten

Ident – Nummern – Konstante  
3740 . . . . .

Gebrauchsanweisung  
51 5075  
(D,NL,F,GB,I,GR)  
51 5070  
(GB)  
51 5953  
(SF,S,N,DK)  
51 5077  
(P)






**BOSCH**

WMV 4280–WMV4280FG/02–FG1  
WMV 4280–WMV4280AA/02–AA1  
WMV 4280–WMV4280FF/02–FF1  
WMV 4280–WMV4280SK/02–SK1

WMV 4280–WMV4280KJ/02–KJ1

WASCHGERÄTE  
Waschvollautomaten


Ident – Nummern – Konstante  
3740 . . . . .





Ident – Nummern – Konstante  
3740 . . . . .

- 1) 05 9886
- 2) 05 8766



Ident – Nummern – Konstante  
 3740 . . . . .

Zubehör:  
 Flüssigwaschmittel-  
 behälter  
 09 0827

