


Mat. – Nr. – Konstante
 3740

Gebrauchsanweisung
 52 7430 – V01
 (es,pt.)
 52 7431 – V02
 (tr,sl,ru,ro,pl,nl,it,hu,
 fr,de,cs,en)
 52 7432 – V03
 (sv,no,fi,da)

- 1) 36 0258
 V01
 (Symb)
- 36 0259
 V02,V03
 (Symb)
 Komplett
- 2) 18 3288
 (tr,sl,so,pl,nl,it,fr,de,
 ru,hu,cs,en)
 18 3289
 (da,no,fi)




Mat. – Nr. – Konstante
3740
1) 15 3150
Komplett

BOSCH

WVF2401 – WVF2401EE/01–V01
WVF2401 – WVF2401EU/01–V02
WVF2401 – WVF2401SN/01–V03

WASCHGERÄTE
Waschvollautomaten




Mat. – Nr. – Konstante
3740
* Schraubensatz
05 9132

AET58300600083211000

BOSCH

WVF2401 – WVF2401EE/01–V01
WVF2401 – WVF2401EU/01–V02
WVF2401 – WVF2401SN/01–V03

WASCHGERÄTE
Waschvollautomaten




Mat. – Nr. – Konstante
3740

AET58300600083211000

BOSCH

WVF2401 – WVF2401EE/01–V01
WVF2401 – WVF2401EU/01–V02
WVF2401 – WVF2401SN/01–V03

WASCHGERÄTE
Waschvollautomaten



Mat. – Nr. – Konstante
3740

AET5830060083211000