


6000 series 42"



Pos No.	Description	Remarks
0011	Rear cover	
0017	Bottom deco assembly	
0026	Wifi clip	Not displayed
0030	Top deco assembly	
0030	Left deco assembly	
0030	Right deco assembly	
0031	Ambilight door	
0032	IR cover	
0035	Swivel Pom	Not displayed
0040	Main inlet bracket	
0085	Left filler assembly	Not displayed
0086	Right filler assembly	Not displayed
0259	Stand accessory	
0260	Stand assembly	
1004	Panel	
1005	Board PSU	Not displayed
1043	Wifi antenna	
1114	Keyboard assembly	Under position number 0011
1115	Wifi assembly	
1122	IR assembly	
1150	Board SSB	
1162	Ambilight	Under position number 0011
1185	Remote Control	Not displayed
5213	Loudspeaker	
5216	Tweeter	Not displayed

FOR ELECTRICAL PARTS/ASSEMBLIES SEE WIRING DIAGRAM CHAPTER 9