


**Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section
(1) (H-FS12032)**

H-FS12032




**Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section
(2) (H-FS35100)**

H-FS35100




**Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section
(3) (H-FS12060)**

H-FS12060




**Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section
(4) (H-FS1442A)**




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section (5) (H-FS14140)

H-FS14140




**Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Camera Lens Section
(6) (H-H020A)**


H-H020A




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (1) (GX9)




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (2) (GX9K)




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (3) (GX9W)




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (4) (GX9M)




Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (5) (GX9N)



Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (6) (GX9H)



Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Packing Parts and Accessories Section (7) (GX9C)



Instructions of packing case
 *Excepting the black color model, No.1640 (COLOR LABEL) is necessary.
 *Please attach the COLOR LABEL on the original "BLACK" printed location, completely.
 Directions for putting GC LABEL
 *Stick the GC LABEL (Ref.No.1641) for specific models on the original printed place.

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		1	1PB1DVLB1200Z	MAIN P.C.B.	1	E.S.D. P, PP, EE, GC, GH, GT, GK, GN, GD
		1	1PB1DVLB1200Y	MAIN P.C.B.	1	E.S.D. EG, EC, EF, EB
		2	1PB1DVLB1201Z	SUB P.C.B.	1	(RTL)E.S.D.
		3	1PB1DVLB1203Z	BATTERY P.C.B.	1	(RTL)E.S.D.
		4	1PB1DVLB1204Z	TOP P.C.B.	1	(RTL)E.S.D.
		5	1PB1DVLB1205Z	AF LED P.C.B.	1	(RTL)E.S.D.
		6	1PB1DVLB1206Z	FLASH P.C.B.	1	(RTL)
		7	1KE13DCGX9EGKZ	STRAP HOLDER R UNIT	1	
		8	DVKM1106Y/K	TOP LVF BASE	1	
		9	DVMF1010Z	LVF HINGE UNIT	1	
		10	1KK1DCGX9EGZ	BATTERY DOOR UNIT	1	
		11	1DX1MC282Z	IMAGE SENSOR UNIT	1	
		12	1KE1DCGX9EGKZ	FRONT PLATE UNIT	1	
		13	2KM4DCGX9EGKZ	BATTERY FRAME UNIT	1	
		14	DVKJ1013Z/K	JACK COVER	1	
		15	DVUR1092Z	JACK COVER SPRING	1	
		16	DVUR1092Z	JACK COVER SPRING	1	
		17	F2A2F8500015	E.CAPACITOR	1	(C8301)
		18	SEE0249	CONDENSER WIRE	1	
		19	STJ0184	MAIN-FLASH FPC	1	
		20	VGQ0T64-A	FPC SHEET	1	
		21	VMB4517	CONDENSER EARTH SPRING	1	
		23	2KM6DCGX9EGKZ	FRONT CASE UNIT	1	
		23-1	DVGX1157Y	FRONT GRIP L	1	
		23-2	DVGX1158Y	FRONT GRIP R	1	
		24	DVGX1159Z/K	LENS RING	1	
		25	DVMA1021Z	FRONT SHOE PLATE	1	
		26	DVME1011Z	LENS LOCK PIN	1	
		27	SGQ0714	CONDENSER HOLDER	1	
		28	SMB0206	ADJUST SPRING	1	
		29	SMB0206	ADJUST SPRING	1	
		30	SMB0206	ADJUST SPRING	1	
		31	SMG0100	O RING	1	
		32	SMP0271	TRIPOD	1	
		33	SXQ0635-SB	SHUTTER UNIT	1	
		34	VMB4497	LENS LOCK PIN SPRING	1	
		35	VMC2063	MOUNT SPRING	1	
		36	VMD6652	MOUNT	1	
		37	1KE10DCGX9EGKZ	MODE FPC UNIT	1	
		38	1KE12DCGX9EGKZ	STRAP HOLDER L UNIT	1	
		39	1KE8DCGX9EGKZ	EYE CUP UNIT	1	
		42	1KM7DCGX9EGKZ	LVF UNIT	1	(-K)
		42	1KM7DCGX9EGSZ	LVF UNIT	1	(-S)
		42-1	L5EDDY00516	LVF MODULE	1	
		42-2	1PB1DVLD1084Z	LVF FPC	1	
		43	2KM5DCGX9EGKZ	TOP CASE UNIT	1	(-K)
		43	2KM5DCGX9EGSZ	TOP CASE UNIT	1	(-S)
		44	DVGE1241Z	EXP ROTOR	1	
		45	DVGE1242Z	ROTOR GUIDE	1	
		46	DVGE1275Z	MODE PLATE	1	
		47	DVMA1022Z	LVF TOP PLATE	1	
		48	DVSG1005Z	DIAL SWITCH	1	
		50	ML-421S/DB	BUTTON BATTERY	1	
		51	STJ0185	MAIN-TOP FPC	1	
		52	VGQ0X85	TOP PCB SHEET	1	
		53	1KM8DCGX9EGKZ	LCD UNIT	1	
		54	1PB1DVLD1083Z	REAR OPERATION FPC	1	
		55	1KM1CSMC282KZ	REAR CASE UNIT	1	Simultaneous exchange with No. 69 (REAR GRIP A) is recommended
		55-1	DVGX1156Y	REAR GRIP B	1	
		56	DVLD1078Z	MAIN-SUB FPC	1	
		57	DVMA1014Y	REAR PLATE	1	

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		58	DVMA1015Z	REAR PLATE B	1	
		59	L0AA01A00185	SPEAKER	1	
		60	SMB0037	SHUTTER SPRING	1	
		61	VMS8262-A	BATTERY DOOR SHAFT	1	
		62	VMT2075	HEAT RADIATION PAD	1	
		63	VXS0266	LEVER ROTOR	1	
		64	DVBC1090Y/K	FLASH BUTTON	1	
		65	DVMA1012Z	BATTERY EARTH PLATE	1	
		66	DVUR1093Z	BATTERY DOOR SPRING	1	
		67	VGQ1J71	HEAT RADIATION SHEET C	1	
		68	VMC2111	SHOE SPRING	1	
		69	DVGX1155Y	REAR GRIP A	1	
		70	DVGE1321Z	REAR OP SHEET	1	
		71	SEP0776AA	SLK FPC UNIT	1	
		72	DVZM1018Z	MOUNT BASE UNIT	1	
		73	SEQ0138	LENS CONNECTOR	1	
		74	SMA0345	LENS RELEASE FPC PLATE	1	
		B1	VHD2457	SCREW	1	
		B2	VHD2457	SCREW	1	
		B3	DVHD1062Z	SCREW	1	
		B4	DVHD1062Z	SCREW	1	
		B5	DVHD1062Z	SCREW	1	
		B6	SHD0118	SCREW	1	
		B7	SHD0118	SCREW	1	
		B8	VHD2124	SCREW	1	
		B9	VHD2124	SCREW	1	
		B10	VHD2190	SCREW	1	
		B11	VHD2190	SCREW	1	
		B12	VHD2252-B	SCREW	1	
		B13	VHD2252-B	SCREW	1	
		B14	VHD2252-B	SCREW	1	
		B15	VHD2252-B	SCREW	1	
		B16	VHD2252-B	SCREW	1	
		B17	VHD2252-B	SCREW	1	
		B18	VHD2252-B	SCREW	1	
		B19	VHD2335	SCREW	1	
		B20	VHD2337	SCREW	1	
		B21	VHD2337	SCREW	1	
		B22	VHD2457	SCREW	1	
		B23	VHD2457	SCREW	1	
		B24	VHD2457	SCREW	1	
		B25	VHD1681	SCREW	1	
		B26	VHD2290	SCREW	1	
		B27	VHD2290	SCREW	1	
		B28	VHD2290	SCREW	1	
		B29	VHD2380	SCREW	1	
		B30	VHD2476	SCREW	1	
		B31	VHD2476	SCREW	1	
		B32	VHD2480	SCREW	1	
		B33	VHD2480	SCREW	1	
		B34	DVHD1073Z	SCREW	1	
		B35	VHD2473	SCREW	1	
		B36	VHD2515	SCREW	1	
		B37	VHD2515	SCREW	1	
		B38	XQN14+BJ4FJK	SCREW	1	
		B39	XQN14+BJ4FJK	SCREW	1	
		B40	XQN14+BJ4FJK	SCREW	1	
		B41	XQN14+BJ4FJK	SCREW	1	
		B42	VHD2306	SCREW	1	
		B43	VHD2306	SCREW	1	
		B44	VHD2306	SCREW	1	
		B45	VHD2306	SCREW	1	

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		B46	VHD2437-B	SCREW	1	
		B47	VHD2437-B	SCREW	1	
		B48	VHD2437-B	SCREW	1	
		B49	VHD2437-B	SCREW	1	
		B50	VHD2437-B	SCREW	1	
		B51	VHD2437-B	SCREW	1	
		B52	VHD2437-B	SCREW	1	
		B53	VHD2437-B	SCREW	1	
		B54	VHD1681	SCREW	1	
		B55	VHD2240	SCREW	1	
		B56	VHD2240	SCREW	1	
		B57	VHD2240	SCREW	1	
		B58	VHD2240	SCREW	1	
		B59	VHD2240	SCREW	1	
		B60	VHD2240	SCREW	1	
		B61	VHD2291	SCREW	1	
		B62	VHD2291	SCREW	1	
		B63	VHD2291	SCREW	1	
		B64	VHD2291	SCREW	1	
		B65	VHD2337	SCREW	1	
		B66	VHD2337	SCREW	1	
		B67	VHD2431	SCREW	1	
		B68	VHD2431	SCREW	1	
		B69	VHD2457	SCREW	1	
		B70	VHD2457	SCREW	1	
		B71	VHD2457	SCREW	1	
		B72	VHD2473	SCREW	1	
		B73	VHD2473	SCREW	1	
		B75	VHD2384	SCREW	1	
		B76	VHD2384	SCREW	1	
		B77	VHD2384	SCREW	1	
		B78	XQN16+BJ4FN	SCREW	1	
		B79	DVHD1063Z	SCREW	1	
		200	SXW0228	LENS UNIT	1	(GX9K), (GX9W)
		201	VYC1134	DECORATION RING	1	(GX9K), (GX9W)
		203	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		206	VEK0U87	MOUNT CONTACT UNIT	1	(GX9K), (GX9W)
		207	VDW2722	L MOUNT UNIT	1	(GX9K), (GX9W)
		208	-----	SHADING FRAME	1	(NOT SUPPLIED)
		211	VMG2117	FLOATING RUBBER	1	(GX9K), (GX9W)
		212	VMG2117	FLOATING RUBBER	1	(GX9K), (GX9W)
		213	VMG2117	FLOATING RUBBER	1	(GX9K), (GX9W)
		214	VXW1724	REAR FRAME UNIT	1	(GX9K), (GX9W)
		220	VDW2714	P.C.B. FRAME	1	(GX9K), (GX9W)
		B201	SHD0130	SCREW	1	(GX9K), (GX9W)
		B202	SHD0130	SCREW	1	(GX9K), (GX9W)
		B203	SHD0131	SCREW	1	(GX9K), (GX9W)
		B204	SHD0131	SCREW	1	(GX9K), (GX9W)
		B205	SHD0131	SCREW	1	(GX9K), (GX9W)
		B206	SHD0132	SCREW	1	(GX9K), (GX9W)
		B207	VHD2296	SCREW	1	(GX9K), (GX9W)
		B208	VHD2296	SCREW	1	(GX9K), (GX9W)
		B209	VHD2296	SCREW	1	(GX9K), (GX9W)
		B210	VHD2296	SCREW	1	(GX9K), (GX9W)
		B211	VHD2296	SCREW	1	(GX9K), (GX9W)
		B212	VHD2296	SCREW	1	(GX9K), (GX9W)
		B213	VHD2296	SCREW	1	(GX9K), (GX9W)
		B214	VHD2296	SCREW	1	(GX9K), (GX9W)
		B215	VHD2296	SCREW	1	(GX9K), (GX9W)
		400	SXW0094	LENS UNIT	1	(GX9W)
		401	SDW0081K	FILTER RING	1	(GX9W)
		402	-----	SHADING FRAME	1	(NOT SUPPLIED)

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		403	VEJ2333	MOUNT CONTACT UNIT	1	(GX9W)
		405	VMG2117	FLOATING RUBBER	1	(GX9W)
		406	VMG2117	FLOATING RUBBER	1	(GX9W)
		407	VMG2117	FLOATING RUBBER	1	(GX9W)
		408	SXQ0172	REAR FRAME UNIT	1	(GX9W)
		409	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		410	SGH0017K	DECORATION RING	1	(GX9W)
		411	VMF0608	DUST PROOF RING	1	(GX9W)
		412	VMS8278	ADJUST PIN	1	(GX9W)
		413	SXQ0174	L MOUNT UNIT	1	(GX9W)
		B400	VHD2296	SCREW	1	(GX9W)
		B401	VHD2296	SCREW	1	(GX9W)
		B402	VHD2296	SCREW	1	(GX9W)
		B403	VHD2246	SCREW	1	(GX9W)
		B404	VHD2246	SCREW	1	(GX9W)
		B406	VHD2298	SCREW	1	(GX9W)
		B407	VHD2299	SCREW	1	(GX9W)
		B408	VHD2299	SCREW	1	(GX9W)
		B409	VHD2299	SCREW	1	(GX9W)
		B410	VHD1868	SCREW	1	(GX9W)
		B411	VHD2109	SCREW	1	(GX9W)
		B412	VHD2109	SCREW	1	(GX9W)
		B413	VHD2109	SCREW	1	(GX9W)
		B414	VHD2296	SCREW	1	(GX9W)
		B415	VHD2296	SCREW	1	(GX9W)
		B416	VHD2296	SCREW	1	(GX9W)
		B417	SHD0021	SCREW	1	(GX9W)
		B419	VHD2296	SCREW	1	(GX9W)
		B420	VHD2296	SCREW	1	(GX9W)
		B421	VHD2296	SCREW	1	(GX9W)
		500	SXW0282	LENS UNIT	1	(GX9M)
		501	SDW0373K	DECORATION RING	1	(GX9M)
		502	SDW0372K	FILTER RING	1	(GX9M)
		503	VMC2220	WAVE WASHER	1	(GX9M)
		504	SXQ0655	FRONT FRAME UNIT	1	(GX9M)
		505	SXQ0653	FOCUS RING UNIT	1	(GX9M)
		506	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		507	VMS8326	ZOOM PIN	1	(GX9M)
		508	VMG1855	FLOATING RUBBER	3	(GX9M)
		509	VMG1855	FLOATING RUBBER	3	(GX9M)
		510	VMG1855	FLOATING RUBBER	3	(GX9M)
		511	SEJ0005	MOUNT CONTACT UNIT	1	(GX9M)
		512	SXQ0648	REAR FRAME UNIT	1	(GX9M)
		513	VMS8278	ADJUST PIN	1	(GX9M)
		514	SMG0095	SEALING RUBBER	1	(GX9M)
		515	SXQ0649	L MOUNT UNIT	1	(GX9M)
		516	-----	SHADING FRAME	1	(NOT SUPPLIED)
		B501	VHD2296	SCREW	1	(GX9M)
		B502	VHD2296	SCREW	1	(GX9M)
		B503	VHD2296	SCREW	1	(GX9M)
		B504	XQN16+BJ4FNK	SCREW	1	(GX9M)
		B505	XQN16+BJ4FNK	SCREW	1	(GX9M)
		B506	XQN16+BJ4FNK	SCREW	1	(GX9M)
		B507	VHD2296	SCREW	1	(GX9M)
		B508	VHD2296	SCREW	1	(GX9M)
		B509	VHD2296	SCREW	1	(GX9M)
		B510	VHD2296	SCREW	1	(GX9M)
		B511	VHD2298	SCREW	1	(GX9M)
		B512	VHD2299	SCREW	1	(GX9M)
		B513	VHD2299	SCREW	1	(GX9M)
		B514	VHD2299	SCREW	1	(GX9M)
		B515	VHD2246	SCREW	1	(GX9M)

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		B516	VHD2246	SCREW	1	(GX9M)
		600	SXW0210	LENS UNIT	1	(GX9N)
		602	-----	SHADING FRAME	1	(NOT SUPPLIED)
		603	VEJ2337	LENS MOUNT CONTACT UNIT	1	(GX9N) [INBD]
		604	VGH5356	DECORATION RING	1	(GX9N) [INBD]
		606	VDW2695	L MOUNT UNIT	1	(GX9N) [INBD]
		607	SYF0076	REAR FRAME UNIT	1	(GX9N) [INBD]
		608	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		B601	VHD2246	SCREW	1	(GX9N) [INBD]
		B602	VHD2246	SCREW	1	(GX9N) [INBD]
		B603	VHD2246	SCREW	1	(GX9N) [INBD]
		B604	VHD2296	SCREW	1	(GX9N) [INBD]
		B605	VHD2296	SCREW	1	(GX9N) [INBD]
		B606	VHD2296	SCREW	1	(GX9N) [INBD]
		B607	VHD2296	SCREW	1	(GX9N) [INBD]
		B608	VHD2299	SCREW	1	(GX9N) [INBD]
		B609	VHD2299	SCREW	1	(GX9N) [INBD]
		B610	VHD2299	SCREW	1	(GX9N) [INBD]
		B613	VHD2298	SCREW	1	(GX9N) [INBD]
		B614	VHD1868	SCREW	1	(GX9N) [INBD]
		B620	VHD2496	SCREW	1	(GX9N) [INBD]
		B621	VHD2496	SCREW	1	(GX9N) [INBD]
		B622	VHD2496	SCREW	1	(GX9N) [INBD]
		700	SXW0205	LENS UNIT	1	(GX9H) [INBD]
		701	VDW2635	FILTER RING	1	(GX9H) [INBD]
		702	-----	SHADING FRAME	1	(NOT SUPPLIED)
		703	VEJ2336	LENS MOUNT CONTACT UNIT	1	(GX9H) [INBD]
		704	VMG1855	FLOATING RUBBER	1	(GX9H) [INBD]
		705	VMG1855	FLOATING RUBBER	1	(GX9H) [INBD]
		706	VMG1855	FLOATING RUBBER	1	(GX9H) [INBD]
		707	VMG1855	FLOATING RUBBER	1	(GX9H) [INBD]
		708	SXQ0394	REAR FRAME UNIT	1	(GX9H) [INBD]
		709	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		710	VYC1120	DECORATION RING	1	(GX9H) [INBD]
		711	VMG2090	DUST PROOF RING	1	(GX9H) [INBD]
		712	K0ZZ00000641	OIS SWITCH	1	(GX9H) [INBD]
		713	VXQ2372	L MOUNT UNIT	1	(GX9H) [INBD]
		B700	VHD2096	SCREW	1	(GX9H) [INBD]
		B701	VHD2096	SCREW	1	(GX9H) [INBD]
		B702	VHD2096	SCREW	1	(GX9H) [INBD]
		B703	VHD2096	SCREW	1	(GX9H) [INBD]
		B704	VHD2096	SCREW	1	(GX9H) [INBD]
		B705	VHD2296	SCREW	1	(GX9H) [INBD]
		B706	VHD2296	SCREW	1	(GX9H) [INBD]
		B707	VHD2296	SCREW	1	(GX9H) [INBD]
		B708	VHD2299	SCREW	1	(GX9H) [INBD]
		B709	VHD2299	SCREW	1	(GX9H) [INBD]
		B710	VHD2299	SCREW	1	(GX9H) [INBD]
		B711	VHD1868	SCREW	1	(GX9H) [INBD]
		B712	VHD2298	SCREW	1	(GX9H) [INBD]
		B713	VHD2246	SCREW	1	(GX9H) [INBD]
		B714	VHD2246	SCREW	1	(GX9H) [INBD]
		B715	VHD2096	SCREW	1	(GX9H) [INBD]
		B716	VHD2096	SCREW	1	(GX9H) [INBD]
		B717	VHD2096	SCREW	1	(GX9H) [INBD]
		800	VXW1668	LENS UNIT	1	(GX9C) [INBD]
		801	VEJ2310	MOUNT CONTACT UNIT	1	(GX9C) [INBD]
		802	VXQ2434	L MOUNT UNIT	1	(GX9C) [INBD]
		803	-----	SHADING FRAME	1	(NOT SUPPLIED)
		804	VMB4295	1ST PUSH SPRING	1	(GX9C) [INBD]
		805	VMX3794	SPRING HOLDER	1	(GX9C) [INBD]
		806	VYC1124	DECORATION RING UNIT	1	(GX9C) [INBD]

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		807	VDS0246	L7 LENS COVER	1	(GX9C) [INBD]
		814	VYF3555	REAR FRAME UNIT	1	(GX9C) [INBD]
		815	-----	LENS MAIN UNIT	1	(NOT SUPPLIED)
		B801	VHD2142	SCREW	1	(GX9C) [INBD]
		B802	VHD2142	SCREW	1	(GX9C) [INBD]
		B803	VHD2142	SCREW	1	(GX9C) [INBD]
		B804	VHD2299	SCREW	1	(GX9C) [INBD]
		B805	VHD2299	SCREW	1	(GX9C) [INBD]
		B806	VHD2299	SCREW	1	(GX9C) [INBD]
		B807	VHD1868	SCREW	1	(GX9C) [INBD]
		B808	VHD2298	SCREW	1	(GX9C) [INBD]
		B809	VHD2296	SCREW	1	(GX9C) [INBD]
		B810	VHD2296	SCREW	1	(GX9C) [INBD]
		B811	VHD2296	SCREW	1	(GX9C) [INBD]
		B812	VHD2073	SCREW	1	(GX9C) [INBD]
		B813	VHD2073	SCREW	1	(GX9C) [INBD]
		B814	XQN16+BJ45FN	SCREW	1	(GX9C) [INBD]
		B815	XQN16+BJ45FN	SCREW	1	(GX9C) [INBD]
		B816	XQN16+BJ45FN	SCREW	1	(GX9C) [INBD]
		900	VPF1316A	CAMERA BAG	1	
		901	VKF5259	HOT SHOE COVER	1	(-K)
		901	SKF0133H	HOT SHOE COVER	1	(-S)
	⚠	902	SAE0012AC	USB ADAPTOR	1	P, PP, GT
	⚠	902	SAE0012DB	USB ADAPTOR	1	EG, EC, EF, EE, GC
	⚠	902	SAE0012FB	USB ADAPTOR	1	EB, GH
	⚠	902	SAE0012HB	USB ADAPTOR	1	GC
	⚠	902	SAE0012CB	USB ADAPTOR	1	GK
	⚠	902	SAE0012GB	USB ADAPTOR	1	GN
	⚠	902	SAE0012EB	USB ADAPTOR	1	GD
		903	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		904	VFC5167	SHOULDER STRAP	1	
	⚠	906	-----	BATTERY PACK	1	
	⚠	907	DVQX1379Z	BASIC O/I (ENGLISH)	1	P, PP
	⚠	907	DVQX1380Z	BASIC O/I (SPANISH)	1	P, PP
	⚠	907	DVQX1381Z	BASIC O/I (FRENCH)	1	PP
	⚠	907	DVQX1382Z	BASIC O/I (GERMAN)	1	EG
	⚠	907	DVQX1383Z	BASIC O/I (FRENCH)	1	EG, EF
	⚠	907	DVQX1384Z	BASIC O/I (ITALIAN)	1	EG
	⚠	907	DVQX1385Z	BASIC O/I (DUTCH)	1	EG, EF
	⚠	907	DVQX1386Z	BASIC O/I (SPANISH)	1	EC
	⚠	907	DVQX1387Z	BASIC O/I (PORTUGUESE)	1	EC
	⚠	907	DVQX1388Z	BASIC O/I (SWEDISH)	1	EC
	⚠	907	DVQX1389Z	BASIC O/I (DANISH)	1	EC
	⚠	907	DVQX1390Z	BASIC O/I (FINNISH)	1	EC
	⚠	907	DVQX1391Z	BASIC O/I (ENGLISH)	1	EB
	⚠	907	DVQX1392Z	BASIC O/I (RUSSIAN)	1	EE
	⚠	907	DVQX1393Z	BASIC O/I (UKRAINIAN)	1	EE
	⚠	907	DVQX1394Z	BASIC O/I (ENGLISH)	1	GC, GH
	⚠	907	DVQX1395Z	BASIC O/I (CHINESE (TRADITIONAL))	1	GC, GH
	⚠	907	DVQX1396Z	BASIC O/I (ARABIC)	1	GC
	⚠	907	DVQX1397Z	BASIC O/I (CHINESE (TRADITIONAL))	1	GT
	⚠	907	DVQX1398Z	BASIC O/I (CHINESE (SIMPLIFIED))	1	GK
	⚠	907	DVQX1399Z	BASIC O/I (ENGLISH)	1	GN
	⚠	907	DVQX1400Z	BASIC O/I (KOREAN)	1	GD
		908	VPF1542	BAG, POLYETHYLENE	1	P
		908	VPF1539	BAG, POLYETHYLENE	1	PP, EG, EC, EF, EB, EE, GC, GH, GT, GK, GN, GD
		920	VKF4971	BODY CAP	1	
		930	DVPK1133001Z	PACKING CASE	1	P, PP, EG, EC, EF, EB, EE, GC, GH, GT, GN, GD
		930	DVPK1134001Z	PACKING CASE	1	GK





















Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		931	DVPN1219Z	PAD A	1	(GX9)
		932	DVPN1195Z	PAD	1	
		940	VQL2T97	COLOR LABEL	1	P-S, PP-S, EG-S, EC-S, EF-S, EB-S, EE-S, GC-S, GH-S, GT-S, GN-S, GD-S
		940	VQL2V11	COLOR LABEL	1	GK-S
		941	SQL0064	GC LABEL	1	GC, GD
		1000	VPF1316A	CAMERA BAG	1	
		1001	VKF5259	HOT SHOE COVER	1	(-K)
		1001	SKF0133H	HOT SHOE COVER	1	(-S)
	⚠	1002	SAE0012AC	USB ADAPTOR	1	KP
	⚠	1002	SAE0012DB	USB ADAPTOR	1	KEG, KEC, KEF, KEE, KGC
	⚠	1002	SAE0012FB	USB ADAPTOR	1	KEB, KGH
	⚠	1002	SAE0012HB	USB ADAPTOR	1	KGC
	⚠	1002	SAE0012CB	USB ADAPTOR	1	KGK
	⚠	1002	SAE0012GB	USB ADAPTOR	1	KGN
	⚠	1002	SAE0012EB	USB ADAPTOR	1	KGD
		1003	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1004	VFC5167	SHOULDER STRAP	1	
	⚠	1006	-----	BATTERY PACK	1	
	⚠	1007	DVQX1379Z	BASIC O/I (ENGLISH)	1	KP
	⚠	1007	DVQX1380Z	BASIC O/I (SPANISH)	1	KP
	⚠	1007	DVQX1382Z	BASIC O/I (GERMAN)	1	KEG
	⚠	1007	DVQX1383Z	BASIC O/I (FRENCH)	1	KEG, KEF
	⚠	1007	DVQX1384Z	BASIC O/I (ITALIAN)	1	KEG
	⚠	1007	DVQX1385Z	BASIC O/I (DUTCH)	1	KEG, KEF
	⚠	1007	DVQX1386Z	BASIC O/I (SPANISH)	1	KEC
	⚠	1007	DVQX1387Z	BASIC O/I (PORTUGUESE)	1	KEC
	⚠	1007	DVQX1388Z	BASIC O/I (SWEDISH)	1	KEC
	⚠	1007	DVQX1389Z	BASIC O/I (DANISH)	1	KEC
	⚠	1007	DVQX1390Z	BASIC O/I (FINNISH)	1	KEC
	⚠	1007	DVQX1391Z	BASIC O/I (ENGLISH)	1	KEB
	⚠	1007	DVQX1392Z	BASIC O/I (RUSSIAN)	1	KEE
	⚠	1007	DVQX1393Z	BASIC O/I (UKRAINIAN)	1	KEE
	⚠	1007	DVQX1394Z	BASIC O/I (ENGLISH)	1	KGC, KGH
	⚠	1007	DVQX1395Z	BASIC O/I (CHINESE (TRADITIONAL))	1	KGC, KGH
	⚠	1007	DVQX1396Z	BASIC O/I (ARABIC)	1	KGC
	⚠	1007	DVQX1398Z	BASIC O/I (CHINESE (SIMPLIFIED))	1	KGK
	⚠	1007	DVQX1399Z	BASIC O/I (ENGLISH)	1	KGN
	⚠	1007	DVQX1400Z	BASIC O/I (KOREAN)	1	KGD
		1008	VPF1542	BAG, POLYETHYLENE	1	KP
		1008	VPF1539	BAG, POLYETHYLENE	1	KEG, KEC, KEF, KEB, KEE, KGC, KGH, KGK, KGN, KGD
		1021	SYF0059-M	LENS CAP	1	(GX9K)
		1030	DVPK1136001Z	PACKING CASE	1	KP, KEG, KEC, KEF, KEB, KEE, KGC, KGH, KGN, KGD
		1030	DVPK1137001Z	PACKING CASE	1	KGK
		1031	DVPN1196Z	PAD B	1	(GX9K)
		1032	DVPN1195Z	PAD	1	
		1040	VQL2T97	COLOR LABEL	1	KP-S, KEG-S, KEC-S, KEF-S, KEB-S, KEE-S, KGC-S, KGH-S, KGN-S, KGD-S
		1040	VQL2V11	COLOR LABEL	1	KGK-S
		1041	SQL0064	GC LABEL	1	KGC, KGD
		1200	VPF1316A	CAMERA BAG	1	
		1201	VKF5259	HOT SHOE COVER	1	(-K)
		1201	SKF0133H	HOT SHOE COVER	1	(-S)
	⚠	1202	SAE0012DB	USB ADAPTOR	1	WEG, WEF
	⚠	1202	SAE0012FB	USB ADAPTOR	1	WEB
		1203	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1204	VFC5167	SHOULDER STRAP	1	
	⚠	1206	-----	BATTERY PACK	1	

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		1207	DVQX1382Z	BASIC O/I (GERMAN)	1	WEG
		1207	DVQX1383Z	BASIC O/I (FRENCH)	1	WEG, WEF
		1207	DVQX1384Z	BASIC O/I (ITALIAN)	1	WEG
		1207	DVQX1385Z	BASIC O/I (DUTCH)	1	WEG, WEF
		1207	DVQX1391Z	BASIC O/I (ENGLISH)	1	WEB
		1208	VPF1539	BAG, POLYETHYLENE	1	(GX9W)
		1221	SYF0059-M	LENS CAP	1	(GX9W)
		1222	SYA0024	LENS HOOD	1	(GX9W)
		1223	VFC4605-B	LENS REAR CAP	1	(GX9W)
		1224	SYF0073	LENS CAP	1	(GX9W)
		1225	VPF1535	AIR CAP BAG	1	(GX9W)
		1230	DVFK1138001Z	PACKING CASE	1	(GX9W)
		1231	DVPN1196Z	PAD B	1	(GX9W)
		1232	DVPN1195Z	PAD	1	
		1233	DVPN1220Z	PAD F	1	(GX9W)
		1240	VQL2T97	COLOR LABEL	1	WEG-S, WEF-S, WEB-S
		1300	VPF1316A	CAMERA BAG	1	
		1301	VKF5259	HOT SHOE COVER	1	(-K)
		1301	SKF0133H	HOT SHOE COVER	1	(-S)
		1302	SAE0012AC	USB ADAPTOR	1	MP, MPP
		1302	SAE0012DB	USB ADAPTOR	1	MEG, MEC, MEF
		1302	SAE0012FB	USB ADAPTOR	1	MEB
		1303	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1304	VFC5167	SHOULDER STRAP	1	
		1306	-----	BATTERY PACK	1	
		1307	DVQX1379Z	BASIC O/I (ENGLISH)	1	MP, MPP
		1307	DVQX1380Z	BASIC O/I (SPANISH)	1	MP, MPP
		1307	DVQX1381Z	BASIC O/I (FRENCH)	1	MPP
		1307	DVQX1382Z	BASIC O/I (GERMAN)	1	MEG
		1307	DVQX1383Z	BASIC O/I (FRENCH)	1	MEG, MEF
		1307	DVQX1384Z	BASIC O/I (ITALIAN)	1	MEG
		1307	DVQX1385Z	BASIC O/I (DUTCH)	1	MEG, MEF
		1307	DVQX1386Z	BASIC O/I (SPANISH)	1	MEC
		1307	DVQX1387Z	BASIC O/I (PORTUGUESE)	1	MEC
		1307	DVQX1388Z	BASIC O/I (SWEDISH)	1	MEC
		1307	DVQX1389Z	BASIC O/I (DANISH)	1	MEC
		1307	DVQX1390Z	BASIC O/I (FINNISH)	1	MEC
		1307	DVQX1391Z	BASIC O/I (ENGLISH)	1	MEB
		1308	VPF1542	BAG, POLYETHYLENE	1	MP
		1308	VPF1539	BAG, POLYETHYLENE	1	MPP, MEG, MEC, MEF, MEB
		1320	VKF4971	BODY CAP	1	
		1321	VYF3514	LENS CAP	1	(GX9M)
		1322	SDW0355K	LENS HOOD	1	(GX9M)
		1323	VFC4605-B	LENS REAR CAP	1	(GX9M)
		1325	VPF1535	AIR CAP BAG	1	(GX9M)
		1330	DVFK1142001Z	PACKING CASE	1	(GX9M)
		1331	DVPN1219Z	PAD A	1	(GX9M)
		1332	DVPN1195Z	PAD	1	
		1333	DVPN1220Z	PAD F	1	(GX9M)
		1340	VQL2T97	COLOR LABEL	1	MP-S, MPP-S, MEG-S, MEF-S, MEB-S
		1400	VPF1316A	CAMERA BAG	1	
		1401	VKF5259	HOT SHOE COVER	1	(-K)
		1401	SKF0133H	HOT SHOE COVER	1	(-S)
		1402	SAE0012DB	USB ADAPTOR	1	NEG, NEC, NEF
		1402	SAE0012FB	USB ADAPTOR	1	NEB
		1403	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1404	VFC5167	SHOULDER STRAP	1	
		1406	-----	BATTERY PACK	1	
		1407	DVQX1382Z	BASIC O/I (GERMAN)	1	NEG
		1407	DVQX1383Z	BASIC O/I (FRENCH)	1	NEG, NEF

Model No. : DC-GX9/GX9K/GX9W/GX9M/GX9N/GX9H/GX9C Parts List

Change	Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
		1407	DVQX1384Z	BASIC O/I (ITALIAN)	1	NEG
		1407	DVQX1385Z	BASIC O/I (DUTCH)	1	NEG,NEF
		1407	DVQX1386Z	BASIC O/I (SPANISH)	1	NEC
		1407	DVQX1387Z	BASIC O/I (PORTUGUESE)	1	NEC
		1407	DVQX1388Z	BASIC O/I (SWEDISH)	1	NEC
		1407	DVQX1389Z	BASIC O/I (DANISH)	1	NEC
		1407	DVQX1390Z	BASIC O/I (FINNISH)	1	NEC
		1407	DVQX1391Z	BASIC O/I (ENGLISH)	1	NEB
		1408	VFF1539	BAG, POLYETHYLENE	1	(GX9N)
		1420	VKF4971	BODY CAP	1	
		1421	VYF3510	LENS CAP	1	(GX9N)
		1422	VYC1113-B	LENS HOOD	1	(GX9N)
		1423	VFC4605-B	LENS REAR CAP	1	(GX9N)
		1425	VFF1535	AIR CAP BAG	1	(GX9N), (GX9H)
		1430	DVPK1187001Z	PACKING CASE	1	(GX9N)
		1431	DVPN1219Z	PAD A	1	(GX9N)
		1432	DVPN1195Z	PAD	1	
		1433	DVPN1220Z	PAD F	1	(GX9N)
		1440	VQL2T97	COLOR LABEL	1	NEG-S,NEF-S,NEB-S
		1500	VFF1316A	CAMERA BAG	1	
		1501	VKF5259	HOT SHOE COVER	1	(-K)
		1501	SKF0133H	HOT SHOE COVER	1	(-S)
		1502	SAE0012DB	USB ADAPTOR	1	(GX9H)
		1503	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1504	VFC5167	SHOULDER STRAP	1	
		1506	-----	BATTERY PACK	1	
		1507	DVQX1382Z	BASIC O/I (GERMAN)	1	HEG
		1507	DVQX1383Z	BASIC O/I (FRENCH)	1	(GX9H)
		1507	DVQX1384Z	BASIC O/I (ITALIAN)	1	HEG
		1507	DVQX1385Z	BASIC O/I (DUTCH)	1	(GX9H)
		1508	VFF1539	BAG, POLYETHYLENE	1	(GX9H)
		1520	VKF4971	BODY CAP	1	
		1521	VYF3514	LENS CAP	1	(GX9H)
		1522	VYC1119-B	LENS HOOD	1	(GX9H)
		1523	VFC4605-B	LENS REAR CAP	1	(GX9H)
		1525	VFF1535	AIR CAP BAG	1	(GX9H)
		1530	DVPK1141001Z	PACKING CASE	1	(GX9H)
		1531	DVPN1219Z	PAD A	1	(GX9H)
		1532	DVPN1195Z	PAD	1	
		1533	DVPN1220Z	PAD F	1	(GX9H)
		1540	VQL2T97	COLOR LABEL	1	HEG-S,HEF-S
		1600	VFF1316A	CAMERA BAG	1	
		1601	VKF5259	HOT SHOE COVER	1	(-K)
		1601	SKF0133H	HOT SHOE COVER	1	(-S)
		1602	SAE0012DB	USB ADAPTOR	1	(GX9C)
		1602	SAE0012HB	USB ADAPTOR	1	CGC
		1603	K1HY04YY0106	USB CONNECTION CABLE (BATTERY CHARGER)	1	
		1604	VFC5167	SHOULDER STRAP	1	
		1606	-----	BATTERY PACK	1	
		1607	DVQX1394Z	BASIC O/I (ENGLISH)	1	CGC
		1607	DVQX1395Z	BASIC O/I (CHINESE (TRADITIONAL))	1	CGC
		1607	DVQX1396Z	BASIC O/I (ARABIC)	1	CGC
		1608	VFF1539	BAG, POLYETHYLENE	1	(GX9C)
		1621	VYF3371	LENS CAP	1	(GX9C)
		1630	DVPK1139001Z	PACKING CASE	1	(GX9C)
		1631	DVPN1196Z	PAD B	1	(GX9C)
		1632	DVPN1195Z	PAD	1	
		1640	VQL2T97	COLOR LABEL	1	CGC-S
		1641	SQL0064	GC LABEL	1	CGC