


5-1-7. CABINET (R) SECTION-2



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
301	3-082-532-11	CABINET (R), LCD (PC105E)	308	3-082-519-01	FOOT (R), RUBBER
301	3-082-532-21	CABINET (R), LCD (PC105)	309	3-969-387-01	FOOT, RUBBER
301	3-083-693-01	CABINET (R) (N), LCD (PC103E)	310	1-962-115-11	HARNESS (PB-052)
301	3-083-693-11	CABINET (R) (N), LCD (PC104E)	311	3-082-535-01	COVER (BACK), HINGE
302	4-974-725-01	SCREW (M1.7), LOCK ACE, P2	312	X-3953-359-1	HINGE ASSY, LCD
303	A-7016-624-A	PD-193 BOARD, COMPLETE	313	3-082-534-01	COVER (FRONT), HINGE
304	3-082-533-01	SHEET, PROTECTION, LCD PANEL	314	3-989-735-31	SCREW (M1.7), LOCK ACE, P2
305	X-3953-358-1	CABINET (L) ASSY, LCD	315	A-7016-626-A	FP-697 BOARD, COMPLETE
306	X-3953-390-2	CABINET (R) ASSY	LCD901	8-753-052-41	ACX500DMM-1
307	3-082-536-01	CLAW, PANEL LOCK	ND901	1-477-759-11	BLOCK LIGHT GUIDE PLATE (2.5)