


6-1-8. MECHANISM CHASSIS BLOCK ASSEMBLY



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
801	3-059-211-01	GEAR, CONVERSION		818	3-059-139-01	GEAR, GL DRIVING	
802	3-059-220-01	GEAR, RELAY		819	3-059-188-01	GEAR, DECELERATION	
803	3-059-187-01	SHAFT, WORM		820	A-7094-818-A	COASTER (S) BLOCK ASSY	
804	3-059-186-03	HOF DR, MOTOR		821	A-7094-817-A	COASTER (T) BLOCK ASSY	
805	3-060-002-01	ROLLER, LS GUIDE		822	3-059-126-01	RAIL, GUIDE	
806	3-059-189-01	GEAR (A), CAM		823	3-962-914-01	SCREW (M1.4X2)	
807	3-703-816-41	SCREW (M1.4X2.5), SPECIAL HEAD		824	A-7094-822-A	DRUM BASE BLOCK ASSY	
808	3-059-225-01	SHIELD, MOTOR		825	3-059-118-01	COVER (B), GEAR	
809	3-059-191-01	ROLLER, LS		826	3-059-083-01	COVER (C), GEAR	
810	3-059-190-01	ARM, LS		827	X-3950-368-1	ARM ASSY, PINCH DRIVING	
811	1-677-049-11	FP-228 FLEXIBLE BOARD (DEW SENSOR)		828	3-059-192-01	GEAR (B), CAM	
812	1-677-084-11	FP-100 FLEXIBLE BOARD		829	3-063-355-01	ROLLER (S1), LS GUIDE	
813	3-059-149-01	SLIDER, TG1 CAM		830	3-065-202-01	SUPPORT, TG7	
814	3-059-148-01	ARM, TG1 DRIVING					
815	3-703-816-14	SCREW (M1.4)		M902	8-835-685-01	MOTOR, DC SCD18A/C-NP (INCLUDING BELT)(CAPSTAN)	
816	3-059-117-01	COVER (A), GEAR		M903	A-7094-823-A	MOTOR BLOCK ASSY (LOADING)	
817	X-3950-367-1	GEAR ASSY, MODE					