

5-2. ELECTRICAL PARTS LIST

Ref. No. Part No. Description
A-1231-932-A CM-076 BOARD, COMPLETE (SR5/SR5C/SR5E)

(IC6901 is not supplied, but this is included in CMOS block assy.)

< CAPACITOR >

C6802	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V
C6803	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6805	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V
C6806	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6808	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V

C6809	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6811	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6812	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6904	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6905	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V

C6906	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6907	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6908	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6909	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6915	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V

C6916	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6917	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6919	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6925	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6928	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V

C6930	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6931	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C8201	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C8202	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C8203	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V

C8204	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C8205	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C8206	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C8207	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C8208	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V

C8209	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V
C8210	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V
C8211	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V

< CONNECTOR >

* CN6801 1-820-561-11 CONNECTOR, COAXIAL (RECEPTACLE)

< FERRITE BEAD >

FB8201	1-400-833-21	SMD EMI FERRITE
FB8202	1-400-833-21	SMD EMI FERRITE
FB8203	1-400-833-21	SMD EMI FERRITE
FB8204	1-400-833-21	SMD EMI FERRITE

< IC >

IC6801	6-703-977-01	IC R1114Q331D-TR-FA
* IC6802	6-708-444-01	IC R1114Q281D-TR-FA
IC6803	6-703-977-01	IC R1114Q331D-TR-FA
* IC6804	6-708-457-01	IC R1114Q151D-TR-FA
IC6901	A-1172-742-A	CMOS BLOCK ASSY (CMOS IMAGER)(Note)
IC8201	6-707-333-01	IC NJM3230SE7

Ref. No. Part No. Description

< COIL >

L6907	1-216-295-91	SHORT CHIP	0
L6909	1-216-295-91	SHORT CHIP	0
L6911	1-216-295-91	SHORT CHIP	0
L6912	1-216-295-91	SHORT CHIP	0
L6914	1-216-295-91	SHORT CHIP	0
L8201	1-400-588-11	INDUCTOR	10uH

< RESISTOR >

R6901	1-218-990-11	SHORT CHIP	0
R6903	1-208-643-11	RES-CHIP	22 5% 1/16W
R8201	1-218-965-11	RES-CHIP	10K 5% 1/16W
R8202	1-218-989-11	RES-CHIP	1M 5% 1/16W
R8203	1-218-989-11	RES-CHIP	1M 5% 1/16W

R8204	1-218-965-11	RES-CHIP	10K 5% 1/16W
-------	--------------	----------	--------------

< COMPOSITION CIRCUIT BLOCK >

RB8201	1-234-379-21	RES, NETWORK	22K (1005X4)
--------	--------------	--------------	--------------

< SENSOR >

* SE8201	1-479-022-61	SENSOR, ANGULAR VELOCITY (YAW)
* SE8202	1-479-022-51	SENSOR, ANGULAR VELOCITY (PITCH)

A-1237-309-A CM-077 BOARD, COMPLETE (SERVICE)
(SR7/SR7E/SR8/SR8E)

(IC6701 is not supplied, but this is included in CMOS block assy.)

< CAPACITOR >

C6607	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V
C6608	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V
C6609	1-100-415-11	CERAMIC CHIP	0.47uF	10%	6.3V
C6610	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6611	1-165-908-11	CERAMIC CHIP	1uF	10%	10V

C6612	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6613	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6614	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C6705	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6706	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V

C6707	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6708	1-125-889-11	CERAMIC CHIP	2.2uF	10%	10V
C6709	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6717	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6718	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V

C6719	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6720	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C6724	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6725	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C6729	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V

C6731	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6732	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6733	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6736	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6738	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V

Note: Be sure to read "Precautions for Replacement of Imager" on page 4-3 when changing the imager.

Note: イメージャの交換時は4-4ページの「イメージャ交換時の注意」を必ずお読みください。

Ref. No.	Part No.	Description			
C6739	1-117-919-11	TANTAL. CHIP	10uF	20%	6.3V
C6740	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C6743	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C7201	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C7202	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C7203	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C7204	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C7205	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C7206	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C7207	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C7208	1-119-923-11	CERAMIC CHIP	0.047uF	10%	10V
C7209	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V
C7210	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V
C7211	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V

< CONNECTOR >

CN6601	1-820-560-11	CONNECTOR, COAXIAL (RECEPTACLE)
--------	--------------	---------------------------------

< FERRITE BEAD >

FB7201	1-400-833-21	SMD EMI FERRITE
FB7202	1-400-833-21	SMD EMI FERRITE
FB7203	1-400-833-21	SMD EMI FERRITE
FB7204	1-400-833-21	SMD EMI FERRITE

< IC >

IC6603	6-703-977-01	IC R1114Q331D-TR-FA
* IC6604	6-708-444-01	IC R1114Q281D-TR-FA
IC6605	6-703-977-01	IC R1114Q331D-TR-FA
IC6606	6-703-976-01	IC R1114Q181D-TR-FA
IC6701	A-1209-688-A	CMOS BLOCK ASSY (CMOS IMAGER)(Note)
IC7201	6-707-333-01	IC NJM3230SE7

< COIL >

L6702	1-216-295-91	SHORT CHIP	0
L6704	1-216-295-91	SHORT CHIP	0
L6705	1-216-295-91	SHORT CHIP	0
L6706	1-216-295-91	SHORT CHIP	0
L6707	1-216-295-91	SHORT CHIP	0
L7201	1-400-588-11	INDUCTOR	10uH

< RESISTOR >

R6703	1-218-990-11	SHORT CHIP	0
R6709	1-218-929-11	RES-CHIP	10 5% 1/16W
R7201	1-218-965-11	RES-CHIP	10K 5% 1/16W
R7202	1-218-989-11	RES-CHIP	1M 5% 1/16W
R7203	1-218-989-11	RES-CHIP	1M 5% 1/16W
R7204	1-218-965-11	RES-CHIP	10K 5% 1/16W

< COMPOSITION CIRCUIT BLOCK >

RB7201	1-234-379-21	RES, NETWORK 22K (1005X4)
--------	--------------	---------------------------

< SENSOR >

* SE7201	1-479-022-61	SENSOR, ANGULAR VELOCITY (YAW)
* SE7202	1-480-218-11	SENSOR, ANGULAR VELOCITY (PITCH)

Note: Be sure to read "Precautions for Replacement of Imager" on page 4-3 when changing the imager.

Note: イメージャの交換時は4-4ページの「イメージャ交換時の注意」を必ずお読みください。

Ref. No.	Part No.	Description
	A-1274-032-A	LD-228 (FIR) BOARD, COMPLETE (SR7/SR7E/SR8/SR8E)
	A-1274-033-A	LD-228 (FIY) BOARD, COMPLETE (SR5/SR5C/SR5E)

< CAPACITOR >		
C5315	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5316	1-119-750-11	TANTAL. CHIP 22uF 20% 6.3V
C5318	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C5401	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR5/SR5C/SR5E)
C5404	1-164-942-11	CERAMIC CHIP 0.0068uF 10% 16V (SR5/SR5C/SR5E)
C5405	1-137-987-81	CERAMIC CHIP 0.068uF 10% 10V
C5406	1-137-987-81	CERAMIC CHIP 0.068uF 10% 10V
C5409	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V (SR7/SR7E/SR8/SR8E)
C5409	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V (SR5/SR5C/SR5E)
C5410	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5411	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V (SR7/SR7E/SR8/SR8E)
C5411	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V (SR5/SR5C/SR5E)
C5412	1-164-866-11	CERAMIC CHIP 47PF 5% 50V
C5413	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C5414	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5415	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5416	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5417	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5419	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5421	1-165-897-11	TANTAL. CHIP 22uF 20% 10V
C5422	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5423	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5424	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5425	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5427	1-164-930-11	CERAMIC CHIP 330PF 5% 16V
C5428	1-119-750-11	TANTAL. CHIP 22uF 20% 6.3V
C5430	1-127-715-11	CERAMIC CHIP 0.22uF 10% 16V
C5431	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5433	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V
C5434	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V
C5435	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V
C5436	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V
C5705	1-165-897-11	TANTAL. CHIP 22uF 20% 10V (SR7/SR7E/SR8/SR8E)
C5706	1-165-908-11	CERAMIC CHIP 1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5707	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5708	1-165-908-11	CERAMIC CHIP 1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5712	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V (SR7/SR7E/SR8/SR8E)
C5713	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V (SR7/SR7E/SR8/SR8E)
C5715	1-164-943-11	CERAMIC CHIP 0.01uF 10% 16V (SR7/SR7E/SR8/SR8E)
C5716	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V (SR7/SR7E/SR8/SR8E)

Ref. No.	Part No.	Description
C5717	1-107-819-11	CERAMIC CHIP 0.022uF 10% 16V (SR7/SR7E/SR8/SR8E)
C5719	1-164-943-81	CERAMIC CHIP 0.01uF 10% 16V (SR7/SR7E/SR8/SR8E)
C5723	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5724	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5725	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5729	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5730	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C5801	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5803	1-100-611-91	CERAMIC CHIP 22uF 20% 6.3V
< CONNECTOR >		
* CN5301	1-817-283-71	CONNECTOR, FPC (ZIF) 51P (SR7/SR7E/SR8/SR8E)
* CN5302	1-817-564-71	CONNECTOR, FPC (ZIF) 33P (SR5/SR5C/SR5E)
* CN5303	1-817-910-71	CONNECTOR, FPC (ZIF) 45P
* CN5305	1-816-643-51	FFC/FPC CONNECTOR (LIF) 10P
* CN5306	1-816-654-51	FFC/FPC CONNECTOR (LIF) 6P (SR7/SR7E/SR8/SR8E)
< DIODE >		
D5301	6-500-044-01	DIODE DF6A6.8FU (TE85R) (SR7/SR7E/SR8/SR8E)
D5302	6-500-776-01	DIODE MAZW068H0LS0
< FERRITE BEAD >		
FB5401	1-414-760-21	BEAD, FERRITE (CHIP) (1608)
< IC >		
* IC5304	6-708-444-01	IC R1114Q281D-TR-FA
IC5401	8-759-359-49	IC NJM3414AV (TE2) (SR5/SR5C/SR5E)
IC5402	8-759-359-49	IC NJM3414AV (TE2)
IC5403	8-759-359-49	IC NJM3414AV (TE2)
IC5404	6-708-814-01	IC BU2343GLU-E2
* IC5703	6-709-026-01	IC R2J30500LG (SR7/SR7E/SR8/SR8E)
IC5801	6-706-173-01	IC BD6878GLU-E2
< COIL >		
L5301	1-400-588-11	INDUCTOR 10uH
L5401	1-469-555-21	INDUCTOR 10uH
L5701	1-400-588-11	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)
L5801	1-469-553-21	INDUCTOR 4.7uH
< TRANSISTOR >		
Q5301	6-550-384-01	TRANSISTOR DTC123JMT2L
< RESISTOR >		
R5342	1-218-941-11	RES-CHIP 100 5% 1/16W
R5344	1-218-990-11	SHORT CHIP 0 (SR7/SR7E/SR8/SR8E)
R5345	1-218-990-11	SHORT CHIP 0 (SR7/SR7E/SR8/SR8E)
R5347	1-218-990-11	SHORT CHIP 0 (SR7/SR7E/SR8/SR8E)
R5401	1-218-990-11	SHORT CHIP 0 (SR5/SR5C/SR5E)
R5402	1-218-990-11	SHORT CHIP 0 (SR5/SR5C/SR5E)

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
R5403	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5725	1-218-978-11	RES-CHIP	120K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5404	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5726	1-208-689-11	METAL CHIP	1.8K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5405	1-218-990-11	SHORT CHIP	0	(SR5/SR5C/SR5E)	R5729	1-208-705-11	METAL CHIP	8.2K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)	
R5406	1-218-990-11	SHORT CHIP	0	(SR7/SR7E/SR8/SR8E)	R5733	1-208-707-11	METAL CHIP	10K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)	
R5409	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5736	1-208-721-11	METAL CHIP	39K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5410	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5737	1-208-721-11	METAL CHIP	39K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5411	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5741	1-218-978-11	RES-CHIP	120K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5412	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5742	1-208-689-11	METAL CHIP	1.8K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5413	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5745	1-208-705-11	METAL CHIP	8.2K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5414	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5749	1-208-707-11	METAL CHIP	10K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)
R5415	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5770	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5420	1-218-965-11	RES-CHIP	10K	5%	1/16W (SR5/SR5C/SR5E)	R5771	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5421	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5772	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5422	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5773	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5423	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5774	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5424	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5776	1-218-977-11	RES-CHIP	100K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5425	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5791	1-218-953-11	RES-CHIP	1K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5426	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5792	1-218-953-11	RES-CHIP	1K	5%	1/16W (SR7/SR7E/SR8/SR8E)
R5427	1-218-990-11	SHORT CHIP	0	(SR7/SR7E/SR8/SR8E)	R5793	1-218-935-11	RES-CHIP	33	5%	1/16W (SR7/SR7E/SR8/SR8E)	
R5430	1-218-965-11	RES-CHIP	10K	5%	1/16W						
R5431	1-218-965-11	RES-CHIP	10K	5%	1/16W						
R5433	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5434	1-208-721-11	METAL CHIP	39K	0.5%	1/16W						
R5435	1-218-958-11	RES-CHIP	2.7K	5%	1/16W						
R5436	1-218-958-11	RES-CHIP	2.7K	5%	1/16W						
R5437	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5438	1-208-721-11	METAL CHIP	39K	0.5%	1/16W						
R5439	1-208-703-11	METAL CHIP	6.8K	0.5%	1/16W						
R5440	1-208-941-11	METAL CHIP	180K	0.5%	1/16W						
R5441	1-208-671-11	METAL CHIP	330	0.5%	1/16W						
R5442	1-218-953-11	RES-CHIP	1K	5%	1/16W						
R5443	1-208-943-11	METAL CHIP	220K	0.5%	1/16W						
R5444	1-208-911-11	METAL CHIP	10K	0.5%	1/16W						
R5445	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5446	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5449	1-208-911-11	METAL CHIP	10K	0.5%	1/16W						
R5450	1-208-943-11	METAL CHIP	220K	0.5%	1/16W						
R5451	1-206-643-11	RES-CHIP	22	5%	1/16W						
R5452	1-218-965-11	RES-CHIP	10K	5%	1/16W						
R5454	1-208-941-11	METAL CHIP	180K	0.5%	1/16W						
R5455	1-208-703-11	METAL CHIP	6.8K	0.5%	1/16W						
R5456	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5457	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W						
R5458	1-218-953-11	RES-CHIP	1K	5%	1/16W						
R5459	1-208-721-11	METAL CHIP	39K	0.5%	1/16W						
R5460	1-208-721-11	METAL CHIP	39K	0.5%	1/16W						
R5461	1-218-958-11	RES-CHIP	2.7K	5%	1/16W						
R5462	1-218-958-11	RES-CHIP	2.7K	5%	1/16W						
R5720	1-208-719-11	METAL CHIP	33K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)						
R5721	1-208-721-11	METAL CHIP	39K	0.5%	1/16W (SR7/SR7E/SR8/SR8E)						

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
A-1274-786-A	VC-504 BOARD, COMPLETE (SREVICE)	(SR7/SR8)	C1313	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
A-1274-787-A	VC-504 BOARD, COMPLETE (SREVICE)	(SR7E/SR8E)	C1314	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
A-1274-788-A	VC-504 BOARD, COMPLETE (SREVICE)	(SR5/SR5C)	C1315	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
A-1274-789-A	VC-504 BOARD, COMPLETE (SREVICE) (SR5E)	*****	C1316	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
(IC2201 is not supplied, but this is included in VC-504 complete board.)			C1317	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
< CAPACITOR >			C1318	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C1008	1-164-860-11	CERAMIC CHIP 27PF 5% 50V	C1319	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
* C1023	1-112-298-91	CERAMIC CHIP 1uF 10% 16V	C1320	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C1027	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V	C1321	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C1028	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1322	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C1033	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V	C1323	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)
C1034	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V	C1324	1-117-919-11	TANTAL. CHIP 10uF 20% 6.3V (SR7/SR7E/SR8/SR8E)
C1035	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V	C1325	1-117-919-11	TANTAL. CHIP 10uF 20% 6.3V (SR7/SR7E/SR8/SR8E)
C1036	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V	C1702	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C1037	1-127-760-11	CERAMIC CHIP 4.7uF 10% 6.3V	C1703	1-117-919-11	TANTAL. CHIP 10uF 20% 6.3V
C1042	1-112-692-11	CERAMIC CHIP 1000PF 5% 50V	C1704	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1044	1-164-936-11	CERAMIC CHIP 680PF 10% 50V (SR7/SR7E/SR8/SR8E)	C1705	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1045	1-164-936-11	CERAMIC CHIP 680PF 10% 50V (SR7/SR7E/SR8/SR8E)	C1706	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C1205	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1707	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C1206	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1708	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1207	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1709	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1208	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1710	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C1209	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1713	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C1210	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1714	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1211	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR5/SR5C/SR5E)	C1715	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1212	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR5/SR5C/SR5E)	C1716	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1213	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1717	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1214	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1718	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1215	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1719	1-100-786-91	TANTAL. CHIP 22uF 20% 6.3V
C1216	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1720	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C1217	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1721	1-100-786-91	TANTAL. CHIP 22uF 20% 6.3V
C1218	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1722	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C1219	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1723	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1220	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1724	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C1221	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1725	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1222	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1726	1-100-786-91	TANTAL. CHIP 22uF 20% 6.3V
C1223	1-117-919-11	TANTAL. CHIP 10uF 20% 6.3V	C1727	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1224	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C1728	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C1225	1-117-919-11	TANTAL. CHIP 10uF 20% 6.3V	C1729	1-165-884-91	CERAMIC CHIP 2.2uF 10% 6.3V
C1305	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1730	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C1306	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1733	1-100-503-11	CERAMIC CHIP 4.7uF 20% 10V
C1307	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1819	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V
C1308	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1821	1-164-850-11	CERAMIC CHIP 10PF 0.5PF 50V
C1309	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1822	1-164-850-11	CERAMIC CHIP 10PF 0.5PF 50V
C1310	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C1823	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
			C1824	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
C1825	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2520	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1826	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2521	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1827	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2522	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1828	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2523	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1829	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V						
C1830	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C2524	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C1832	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C2525	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
				(SR5/SR5C/SR5E)		C2526	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1833	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C2531	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
				(SR5/SR5C/SR5E)		C2532	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C1834	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C2533	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1901	1-100-786-91	TANTAL. CHIP	22uF	20%	6.3V	C2534	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
						C2535	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C1903	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2536	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C1904	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2537	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C1905	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						
C2102	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2538	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V
C2103	1-164-850-11	CERAMIC CHIP	10PF	0.5PF	50V	C2539	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V
						* C2540	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2105	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	* C2541	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2106	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2542	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C2109	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V						
C2110	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2543	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C2111	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2545	1-127-895-91	TANTAL. CHIP	22uF	20%	4V
						C2546	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C2116	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2701	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2117	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2702	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2120	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V						
C2123	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C2703	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2124	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C2704	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
						C2705	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2125	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C2707	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2126	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C2708	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2128	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						
C2130	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2709	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2131	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C2710	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
						C2711	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2132	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C2712	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2201	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2713	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2202	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V						
C2203	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2714	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2204	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2715	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
						C2716	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2205	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2717	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2206	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2718	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2208	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V						
C2209	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	C2719	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2211	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V	C2721	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V
						C2722	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V
C2501	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2724	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2503	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2725	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2504	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						
C2505	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2726	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2506	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2728	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
						C2729	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C2508	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2902	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2509	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2903	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2510	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V						
C2511	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2904	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2512	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2905	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
						C2907	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2513	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C2910	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2514	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2911	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C2515	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						
C2517	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2912	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2518	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2914	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
						C2915	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2519	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V					(SR7/SR7E/SR8/SR8E)	

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
C2916	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3321	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2917	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3322	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C2923	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	* C3323	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2924	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	C3324	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C2925	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	* C3325	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C2943	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3326	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C2944	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3327	1-112-717-91	CERAMIC CHIP	1uF	10%	6.3V
C2945	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V	C3328	1-112-717-91	CERAMIC CHIP	1uF	10%	6.3V
C2946	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	C3329	1-112-717-91	CERAMIC CHIP	1uF	10%	6.3V
C3003	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3330	1-112-717-91	CERAMIC CHIP	1uF	10%	6.3V
C3004	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3331	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3005	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3332	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3007	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C3333	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3008	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C3334	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3010	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V	* C3335	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3011	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V	C3336	1-112-717-91	CERAMIC CHIP	1uF	10%	6.3V
C3013	1-100-611-91	CERAMIC CHIP	22uF	20%	6.3V	C3337	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V
C3103	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3338	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C3104	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3339	1-127-760-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3105	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3340	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C3106	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	* C3341	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3109	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3342	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C3113	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3344	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C3115	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3345	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C3116	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3346	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	50V
* C3117	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V	C3347	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	50V
C3201	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3348	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	50V
C3202	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3349	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	50V
C3203	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	* C3350	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3204	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	* C3351	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3205	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3352	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3206	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C3353	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3207	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	* C3354	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3208	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3355	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V
C3209	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	C3357	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V
C3212	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3360	1-100-842-91	TANTAL. CHIP	47uF	20%	6.3V
C3215	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V						(SR7/SR7E/SR8/SR8E)
C3216	1-165-884-91	CERAMIC CHIP	2.2uF	10%	6.3V	C3361	1-100-842-91	TANTAL. CHIP	47uF	20%	6.3V
C3250	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3251	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3362	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3252	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3253	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C3363	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3254	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V						(SR7/SR7E/SR8/SR8E)
C3255	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3364	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C3301	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3302	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3365	1-164-937-11	CERAMIC CHIP	0.001uF	10%	50V
C3305	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V						(SR7/SR7E/SR8/SR8E)
C3306	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V	C3366	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
					(SR5/SR5C/SR7/SR8)	* C3367	1-112-746-11	CERAMIC CHIP	4.7uF	10%	6.3V
C3308	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C3701	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C3309	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V						(SR7/SR7E/SR8/SR8E)
C3311	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V	C3702	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C3312	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3313	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3703	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V
C3314	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3318	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	C3704	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V
C3319	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V						(SR7/SR7E/SR8/SR8E)
C3320	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3705	1-100-567-81	CERAMIC CHIP	0.01uF	10%	25V
											(SR7/SR7E/SR8/SR8E)

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
C3706	1-164-739-11	CERAMIC CHIP 560PF 5% 50V (SR7/SR7E/SR8/SR8E)	C4730	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C3707	1-127-895-91	TANTAL. CHIP 22uF 20% 4V (SR7/SR7E/SR8/SR8E)	C4732	1-107-823-11	CERAMIC CHIP 0.47uF 10% 16V
C3708	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V (SR7/SR7E/SR8/SR8E)	C4733	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3709	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V (SR7/SR7E/SR8/SR8E)	C4734	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3710	1-127-760-11	CERAMIC CHIP 4.7uF 10% 6.3V (SR7/SR7E/SR8/SR8E)	C4735	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3712	1-127-760-11	CERAMIC CHIP 4.7uF 10% 6.3V (SR7/SR7E/SR8/SR8E)	C4736	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3713	1-125-889-11	CERAMIC CHIP 2.2uF 10% 10V (SR7/SR7E/SR8/SR8E)	C4737	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3714	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V (SR7/SR7E/SR8/SR8E)	C4738	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3715	1-125-889-11	CERAMIC CHIP 2.2uF 10% 10V (SR7/SR7E/SR8/SR8E)	C4739	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3716	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V (SR7/SR7E/SR8/SR8E)	C4740	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C3801	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V (SR5E/SR7/SR7E/SR8/SR8E)	C4744	1-107-823-11	CERAMIC CHIP 0.47uF 10% 16V
C3802	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V	C4745	1-107-823-11	CERAMIC CHIP 0.47uF 10% 16V
C3803	1-119-923-11	CERAMIC CHIP 0.047uF 10% 10V	C4746	1-107-823-11	CERAMIC CHIP 0.47uF 10% 16V
C3804	1-119-923-11	CERAMIC CHIP 0.047uF 10% 10V	C4748	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C3805	1-119-923-11	CERAMIC CHIP 0.047uF 10% 10V	C4750	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C3806	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4751	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C3807	1-165-908-11	CERAMIC CHIP 1uF 10% 10V (SR5/SR5C)	* C4752	1-112-746-11	CERAMIC CHIP 4.7uF 10% 6.3V
C3808	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V (SR5/SR5C)	C4754	1-127-895-91	TANTAL. CHIP 22uF 20% 4V
C4601	1-165-875-11	CERAMIC CHIP 10uF 10% 10V	C4755	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4602	1-165-875-11	CERAMIC CHIP 10uF 10% 10V	C4756	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4603	1-165-875-11	CERAMIC CHIP 10uF 10% 10V	C4757	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4605	1-100-591-91	CERAMIC CHIP 1uF 10% 25V	C4758	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4609	1-107-819-11	CERAMIC CHIP 0.022uF 10% 16V	C4759	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4701	1-164-939-11	CERAMIC CHIP 0.0022uF 10% 50V	C4760	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4702	1-115-467-11	CERAMIC CHIP 0.22uF 10% 10V	C4761	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4703	1-165-908-11	CERAMIC CHIP 1uF 10% 10V	C4762	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4704	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4770	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4705	1-119-923-11	CERAMIC CHIP 0.047uF 10% 10V	C4771	1-100-566-91	CERAMIC CHIP 0.1uF 10% 25V
C4706	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4774	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C4707	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4775	1-164-862-11	CERAMIC CHIP 33PF 5% 50V
C4708	1-165-908-11	CERAMIC CHIP 1uF 10% 10V	C4776	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4709	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4777	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4710	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4778	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4712	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4779	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4713	1-165-908-11	CERAMIC CHIP 1uF 10% 10V	C4780	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C4714	1-115-467-11	CERAMIC CHIP 0.22uF 10% 10V	C4781	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4715	1-165-908-11	CERAMIC CHIP 1uF 10% 10V	C4785	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4716	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V	C4787	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4719	1-107-819-11	CERAMIC CHIP 0.022uF 10% 16V	C4788	1-165-908-11	CERAMIC CHIP 1uF 10% 10V
C4721	1-165-908-11	CERAMIC CHIP 1uF 10% 10V	C4789	1-137-710-91	CERAMIC CHIP 10uF 20% 6.3V
C4723	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4790	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C4724	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4792	1-107-826-11	CERAMIC CHIP 0.1uF 10% 16V
C4725	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4793	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4726	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4794	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V
C4727	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4795	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
C4728	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C4798	1-164-934-11	CERAMIC CHIP 33PF 10% 50V
C4729	1-165-989-11	CERAMIC CHIP 10uF 10% 6.3V	C5101	1-127-895-91	TANTAL. CHIP 22uF 20% 4V
			C5103	1-164-937-11	CERAMIC CHIP 0.001uF 10% 50V
			C5107	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5109	1-164-852-11	CERAMIC CHIP 12PF 5% 50V
			C5110	1-164-854-11	CERAMIC CHIP 15PF 5% 50V
			C5111	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5114	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5115	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5117	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5118	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V
			C5119	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
			C5120	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V

Ref. No.	Part No.	Description
C5121	1-125-777-11	CERAMIC CHIP 0.1uF 10% 10V
C5122	1-100-567-81	CERAMIC CHIP 0.01uF 10% 25V
< CONNECTOR >		
* CN1001	1-779-333-51	CONNECTOR, FFC/FPC 18P
* CN1003	1-816-648-51	FFC/FPC CONNECTOR (LIF) 20P
* CN1004	1-817-283-71	CONNECTOR, FPC (ZIF) 51P
* CN1006	1-819-572-51	CONNECTOR, FFC/FPC (LIF) 30P
* CN1009	1-816-648-51	FFC/FPC CONNECTOR (LIF) 20P
CN1010	1-779-331-51	CONNECTOR, FFC/FPC 14P
* CN1012	1-819-781-61	CONNECTOR, FPC (ZIF) 45P
* CN1013	1-819-860-51	CONNECTOR, FPC (ZIF) 51P
CN1017	1-794-053-51	CONNECTOR, FFC/FPC 32P
* CN1019	1-816-645-51	FFC/FPC CONNECTOR (LIF) 14P
* CN1020	1-816-654-51	FFC/FPC CONNECTOR (LIF) 6P
* CN1021	1-816-650-51	FFC/FPC CONNECTOR (LIF) 24P
* CN1022	1-816-644-51	FFC/FPC CONNECTOR (LIF) 12P (SR7/SR7E/SR8/SR8E)
* CN1025	1-816-655-51	FFC/FPC CONNECTOR (LIF) 8P
* CN1026	1-818-087-51	CONNECTOR, FFC/FPC (LIF) 26P
CN1201	1-820-560-11	CONNECTOR, COAXIAL (RECEPTACLE) (SR7/SR7E/SR8/SR8E)
CN1201	1-820-562-11	CONNECTOR, COAXIAL (RECEPTACLE) (SR5/SR5C/SR5E)
* CN3701	1-779-334-51	CONNECTOR, FFC/FPC 20P (SR7/SR7E/SR8/SR8E)
< DIODE >		
D1001	8-719-084-17	DIODE EMZ6.8ET2R
D1002	8-719-084-17	DIODE EMZ6.8ET2R
D1003	8-719-083-91	DIODE EDZ TE61 6.8B
D1008	8-719-084-17	DIODE EMZ6.8ET2R
D1009	8-719-056-59	DIODE MAZS120008SO
D1011	8-719-074-67	DIODE EDZ-TE61-5.6B
D1016	8-719-083-91	DIODE EDZ TE61 6.8B
D1701	8-719-027-76	DIODE 1SS357-TPH3
D1702	8-719-027-76	DIODE 1SS357-TPH3
D4601	8-719-074-08	DIODE MA4ZD03001SO
D4602	8-719-421-67	DIODE MA132WK
D4604	8-719-069-28	DIODE 1SS400TE-61
D4605	8-719-991-00	DIODE DAP222
D4702	8-719-027-76	DIODE 1SS357-TPH3
D4703	8-719-046-85	DIODE MA2S728
D4707	6-500-813-01	DIODE MA2SD32008SO
D4708	6-500-813-01	DIODE MA2SD32008SO
D4709	6-500-813-01	DIODE MA2SD32008SO
< FUSE >		
△F4601	1-576-406-21	FUSE, MICRO (1608) (1.4A/32V)
△F4602	1-576-406-21	FUSE, MICRO (1608) (1.4A/32V)
△F4603	1-576-406-21	FUSE, MICRO (1608) (1.4A/32V)
△F4604	1-576-406-21	FUSE, MICRO (1608) (1.4A/32V)
△F4605	1-576-406-21	FUSE, MICRO (1608) (1.4A/32V)
△F4606	1-576-872-21	FUSE (0.25A/50V)
< FERRITE BEAD >		
FB1001	1-400-915-21	INDUCTOR (EMI FERRITE) (2012)
FB1008	1-469-581-21	INDUCTOR, FERRITE BEAD (1005)

Ref. No.	Part No.	Description
FB1009	1-400-927-31	BEAD, FERRITE (1005) (SR7/SR7E/SR8/SR8E)
FB1010	1-400-927-31	BEAD, FERRITE (1005) (SR7/SR7E/SR8/SR8E)
FB1011	1-414-760-21	BEAD, FERRITE (CHIP) (1608) (SR7/SR7E/SR8/SR8E)
FB1012	1-414-760-21	BEAD, FERRITE (CHIP) (1608) (SR7/SR7E/SR8/SR8E)
FB1013	1-400-927-31	BEAD, FERRITE (1005) (SR7/SR7E/SR8/SR8E)
FB1701	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB1702	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB1802	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB1901	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2101	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB2102	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB2180	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2181	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2201	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2202	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2301	1-469-580-21	INDUCTOR, FERRITE BEAD (1005)
FB2302	1-469-580-21	INDUCTOR, FERRITE BEAD (1005)
FB2501	1-469-869-21	INDUCTOR (EMI FERRITE) (2012)
FB2502	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2503	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2504	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2505	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2731	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2733	1-469-869-21	INDUCTOR (EMI FERRITE) (2012)
FB2734	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2735	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB2954	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB3101	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB3102	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB3103	1-400-619-11	BEAD, FERRITE (CHIP) (1608)
FB3301	1-400-331-11	FERRITE, EMI (SMD) (1005)
FB3701	1-400-619-11	BEAD, FERRITE (CHIP) (1608) (SR7/SR7E/SR8/SR8E)
< IC >		
* IC1007	6-708-445-01	IC R1114Q291D-TR-FA
* IC1201	6-709-440-01	IC VSP2435ZWDR (SR5/SR5C/SR5E)
* IC1201	6-710-806-01	IC VSP2436ZWDR (SR7/SR7E/SR8/SR8E)
* IC1301	6-710-806-01	IC VSP2436ZWDR (SR7/SR7E/SR8/SR8E)
IC1701	6-708-135-01	IC HD74ALVC2G74USE-E
* IC1702	6-710-008-01	IC CXD9886GG
* IC1803	6-807-463-01	IC MB91195ABGL-G-234-ERE1 (SR5/SR5C/SR5E)
* IC1803	6-807-464-01	IC MB91195ABGL-G-235-ERE1 (SR7/SR7E/SR8/SR8E)
* IC1804	6-710-155-01	IC AK6514CAM-E2
* IC1901	6-710-438-01	IC EDS2532JEBH-75TT-E (SR7/SR7E/SR8/SR8E)
* IC1902	6-708-857-01	IC K4M28163LH-BN75T (SR5/SR5C/SR5E)
* IC2101	8-753-284-01	IC CXD4212AGG-TL
IC2102	6-708-511-01	IC TC7SG08AFS
IC2201	(Not supplied)	IC K5R1213ACA-DK75T
* IC2701	8-753-269-69	IC CXD4206GG-T6
* IC2901	6-709-936-01	IC R8A01015ABGTLV
IC3001	6-708-108-01	IC TLS26A100PFBR
* IC3101	6-709-444-01	IC T6UL2XBG-0001 (E02)
IC3201	6-705-338-01	IC TK11250CMCL-G

• Refer to page 5-1 for mark △.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
* IC3202	6-710-771-01	IC SII9020CBUTR	L4719	1-400-135-11	INDUCTOR 1uH
* IC3301	6-710-466-01	IC NN12923A-BB	L4720	1-469-549-21	INDUCTOR 1uH
* IC3702	8-753-242-26	IC CXM3018GA-T2 (SR7/SR7E/SR8/SR8E)	L4721	1-469-845-11	INDUCTOR 4.7uH
* IC4701	6-710-636-01	IC MB44C005BBGL-G-ERE1	L4722	1-400-676-11	INDUCTOR 22uH
* IC4702	6-710-254-01	IC LV5254LG-TLM-E	L4723	1-400-676-11	INDUCTOR 22uH
* IC4705	6-708-464-01	IC R1114Q251D-TR-FA	L4724	1-469-845-11	INDUCTOR 4.7uH
IC4706	8-759-581-11	IC NJM2125F (TE2)	L4725	1-469-845-11	INDUCTOR 4.7uH
* IC5101	6-807-569-01	IC MB95005BGL-G-107-ERE1	L4726	1-469-966-21	INDUCTOR 1uH
IC5104	6-708-511-01	IC TC7SG08AFS	L4731	1-469-553-21	INDUCTOR 4.7uH
< COIL >			L4732	1-469-561-21	INDUCTOR 100uH
L1001	1-469-551-21	INDUCTOR 2.2uH	L4783	1-400-672-11	INDUCTOR 1uH
L1201	1-400-588-11	INDUCTOR 10uH	L4784	1-400-675-11	INDUCTOR 10uH
L1202	1-469-555-21	INDUCTOR 10uH	* L4785	1-481-240-11	INDUCTOR 1uH
L1301	1-400-588-11	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)	< LINE FILTER >		
L1302	1-469-555-21	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)	* LF1003	1-457-217-21	COMMON MODE CHOKE COIL
L1701	1-400-353-21	INDUCTOR 22uH	* LF3201	1-813-308-11	COMMON MODE CHOKE
L1702	1-469-757-11	INDUCTOR 10uH	* LF3202	1-813-308-11	COMMON MODE CHOKE
L1703	1-469-757-11	INDUCTOR 10uH	* LF3203	1-813-308-11	COMMON MODE CHOKE
L1704	1-469-757-11	INDUCTOR 10uH	* LF3204	1-813-308-11	COMMON MODE CHOKE
L2101	1-400-675-11	INDUCTOR 10uH	< TRANSISTOR >		
L2102	1-400-675-11	INDUCTOR 10uH	Q1001	6-550-102-01	TRANSISTOR 2SC5663T2L
L2501	1-400-675-11	INDUCTOR 10uH	Q1004	6-550-234-01	TRANSISTOR UNR32A300LSO
* L2701	1-481-102-21	INDUCTOR 10uH	Q1013	8-729-053-29	TRANSISTOR DTA143TMT2L
* L2702	1-481-102-21	INDUCTOR 10uH	Q2902	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L2903	1-400-588-11	INDUCTOR 10uH	Q2903	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L2904	1-400-588-11	INDUCTOR 10uH	Q2904	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L2952	1-400-588-11	INDUCTOR 10uH	Q2908	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L3001	1-400-588-11	INDUCTOR 10uH	Q2910	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L3002	1-400-588-11	INDUCTOR 10uH	Q2911	6-550-232-01	TRANSISTOR 2SA2029T2LQ/R
L3003	1-400-588-11	INDUCTOR 10uH	Q3201	6-550-014-01	TRANSISTOR SSM6N15FU (TE85R)
L3202	1-469-570-11	INDUCTOR 10uH	Q3202	6-550-025-01	TRANSISTOR EMD12T2R
L3203	1-469-570-11	INDUCTOR 10uH	Q3301	8-729-056-75	TRANSISTOR MCH3211-TL-E
L3255	1-469-570-11	INDUCTOR 10uH	Q3302	8-729-054-52	TRANSISTOR UP04216008S0
L3258	1-469-570-11	INDUCTOR 10uH	(SR7/SR7E/SR8/SR8E)		
L3302	1-400-588-11	INDUCTOR 10uH	Q3303	8-729-054-52	TRANSISTOR UP04216008S0
L3304	1-400-342-21	INDUCTOR 10uH	(SR7/SR7E/SR8/SR8E)		
L3305	1-400-342-21	INDUCTOR 10uH	Q3701	8-729-054-48	TRANSISTOR UP04601008S0
L3306	1-400-588-11	INDUCTOR 10uH	(SR7/SR7E/SR8/SR8E)		
L3701	1-400-588-11	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)	Q4601	6-551-442-01	TRANSISTOR TPCP8301 (T5RSONYF)
L3702	1-400-588-11	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)	Q4603	6-550-237-01	TRANSISTOR 2SC5658T2LQ/R
L3703	1-400-588-11	INDUCTOR 10uH (SR7/SR7E/SR8/SR8E)	Q4604	8-729-043-60	TRANSISTOR CPH6102-TL-E
L4701	1-456-135-11	INDUCTOR 4.7uH	Q4606	6-551-184-01	TRANSISTOR MCH6305-TL-E-S
L4702	1-456-500-21	INDUCTOR 10uH	Q4607	6-550-119-01	TRANSISTOR DTC144EMT2L
L4703	1-456-136-21	INDUCTOR 10uH	Q4608	6-550-809-01	TRANSISTOR EMB2T2R
L4704	1-456-500-21	INDUCTOR 10uH	Q4610	6-550-094-01	TRANSISTOR EMH2-T2R
L4705	1-456-500-21	INDUCTOR 10uH	Q4701	6-550-025-01	TRANSISTOR EMD12T2R
L4706	1-456-500-21	INDUCTOR 10uH	Q4702	8-729-037-74	TRANSISTOR UN9213J-(TX).SO
L4707	1-456-500-21	INDUCTOR 10uH	Q4703	6-550-006-01	TRANSISTOR UN911BJ-(K8).SO
L4708	1-456-135-11	INDUCTOR 4.7uH	Q4706	8-729-056-72	TRANSISTOR MCH5805-TL-E
L4709	1-481-212-11	INDUCTOR 10uH	Q4707	6-551-536-01	TRANSISTOR ECH8402-S-TL-E
L4710	1-419-311-21	INDUCTOR 100uH	Q4708	6-551-536-01	TRANSISTOR ECH8402-S-TL-E
L4712	1-400-135-11	INDUCTOR 1uH	Q4709	6-551-536-01	TRANSISTOR ECH8402-S-TL-E
L4714	1-469-757-11	INDUCTOR 10uH	Q4713	8-729-044-37	TRANSISTOR 2SK3019TL
L4715	1-469-845-11	INDUCTOR 4.7uH	Q4714	6-550-714-01	TRANSISTOR SCH1406-TL-E
L4716	1-469-549-21	INDUCTOR 1uH	Q4715	6-550-713-01	TRANSISTOR SCH2816-TL-E
* L4718	1-481-240-11	INDUCTOR 1uH	Q4716	6-550-180-01	TRANSISTOR SSM6N16FE (TPLR3)

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
Q4717	8-729-053-54	TRANSISTOR	HN1A01FE-Y/GR (TPLR3)			R1232	1-208-643-11	RES-CHIP	22	5%	1/16W
Q4720	8-729-054-48	TRANSISTOR	UP04601008S0			R1314	1-218-953-11	RES-CHIP	1K	5%	1/16W
			(SR7/SR7E/SR8/SR8E)								(SR7/SR7E/SR8/SR8E)
Q4721	8-729-055-88	TRANSISTOR	MCH3406-TL-E			R1316	1-218-990-11	SHORT CHIP	0		(SR7/SR7E/SR8/SR8E)
Q4722	6-550-237-01	TRANSISTOR	2SC5658T2LQ/R			R1702	1-218-990-11	SHORT CHIP	0		(SR5/SR5C/SR7/SR8)
Q4723	6-550-234-01	TRANSISTOR	UNR32A300LS0			R1704	1-218-990-11	SHORT CHIP	0		(SR5E/SR7E/SR8E)
Q4724	6-550-180-01	TRANSISTOR	SSM6N16FE (TPLR3)			R1706	1-218-929-11	RES-CHIP	10	5%	1/16W
						R1713	1-208-943-11	RES-CHIP	22	5%	1/16W
< RESISTOR >											
R1001	1-216-009-91	RES-CHIP	22	5%	1/10W	R1717	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1002	1-216-009-91	RES-CHIP	22	5%	1/10W	R1720	1-208-943-11	RES-CHIP	22	5%	1/16W
R1003	1-218-959-11	RES-CHIP	3.3K	5%	1/16W	R1721	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R1014	1-218-965-11	RES-CHIP	10K	5%	1/16W	R1722	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R1060	1-218-965-11	RES-CHIP	10K	5%	1/16W	R1725	1-218-990-11	SHORT CHIP	0		(SR7/SR7E/SR8/SR8E)
R1061	1-218-954-11	RES-CHIP	1.2K	5%	1/16W	R1726	1-218-990-11	SHORT CHIP	0		(SR5/SR5C/SR5E)
R1063	1-218-990-11	SHORT CHIP	0			R1821	1-218-941-81	RES-CHIP	100	5%	1/16W
R1076	1-218-969-11	RES-CHIP	22K	5%	1/16W	R1822	1-218-965-11	RES-CHIP	10K	5%	1/16W
						R1824	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1076	1-218-977-11	RES-CHIP	100K	5%	1/16W	R1825	1-218-985-11	RES-CHIP	470K	5%	1/16W
R1076	1-218-990-11	SHORT CHIP	0		(SR5E)	R1827	1-218-973-11	RES-CHIP	47K	5%	1/16W
						R1830	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R1077	1-218-969-11	RES-CHIP	22K	5%	1/16W						(SR5/SR5C/SR5E)
						R1831	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1077	1-218-977-11	RES-CHIP	100K	5%	1/16W	R1832	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
											(SR5/SR5C/SR5E)
R1077	1-218-990-11	SHORT CHIP	0		(SR5/SR5C)	R1833	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1090	1-218-935-11	RES-CHIP	33	5%	1/16W						
R1091	1-218-940-11	RES-CHIP	82	5%	1/16W	R1834	1-218-977-11	RES-CHIP	100K	5%	1/16W
						R1846	1-218-990-11	SHORT CHIP	0		(SR7/SR7E/SR8/SR8E)
R1092	1-208-643-11	RES-CHIP	22	5%	1/16W	R1847	1-218-990-11	SHORT CHIP	0		(SR5/SR5C/SR5E)
R1093	1-218-940-11	RES-CHIP	82	5%	1/16W	R1848	1-218-990-11	SHORT CHIP	0		(SR7/SR7E/SR8/SR8E)
R1094	1-208-643-11	RES-CHIP	22	5%	1/16W	R1849	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1095	1-208-643-11	RES-CHIP	22	5%	1/16W						
R1096	1-218-940-11	RES-CHIP	82	5%	1/16W	R1850	1-218-977-11	RES-CHIP	100K	5%	1/16W
						R1851	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1097	1-218-935-11	RES-CHIP	33	5%	1/16W						(SR7/SR7E/SR8/SR8E)
R1107	1-218-953-11	RES-CHIP	1K	5%	1/16W	R1852	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1108	1-218-945-11	RES-CHIP	220	5%	1/16W						(SR7/SR7E/SR8/SR8E)
R1110	1-218-953-11	RES-CHIP	1K	5%	1/16W	R1853	1-218-973-11	RES-CHIP	47K	5%	1/16W
R1112	1-218-953-11	RES-CHIP	1K	5%	1/16W						(SR7/SR7E/SR8/SR8E)
						R1854	1-218-990-11	SHORT CHIP	0		
R1127	1-218-977-11	RES-CHIP	100K	5%	1/16W						
R1128	1-218-989-11	RES-CHIP	1M	5%	1/16W	R1905	1-218-990-11	SHORT CHIP	0		(SR7/SR7E/SR8/SR8E)
R1137	1-218-949-11	RES-CHIP	470	5%	1/16W	R1906	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1138	1-218-951-11	RES-CHIP	680	5%	1/16W	R1907	1-218-977-11	RES-CHIP	100K	5%	1/16W
R1139	1-218-954-11	RES-CHIP	1.2K	5%	1/16W	R1939	1-218-990-11	SHORT CHIP	0		(SR5/SR5C/SR5E)
						R2113	1-218-935-11	RES-CHIP	33	5%	1/16W
R1140	1-218-955-11	RES-CHIP	1.5K	5%	1/16W						
R1147	1-218-964-11	RES-CHIP	8.2K	5%	1/16W	R2117	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1154	1-218-939-11	RES-CHIP	68	5%	1/16W	R2119	1-218-990-11	SHORT CHIP	0		(SR5/SR5C/SR7/SR8)
R1158	1-218-965-11	RES-CHIP	10K	5%	1/16W	R2120	1-218-990-11	SHORT CHIP	0		(SR5E/SR7E/SR8E)
R1170	1-218-937-11	RES-CHIP	47	5%	1/16W	R2121	1-220-180-11	RES-CHIP	620	5%	1/16W
						R2122	1-208-911-11	METAL CHIP	10K	0.5%	1/16W
R1171	1-218-990-11	SHORT CHIP	0								
R1172	1-218-990-11	SHORT CHIP	0			R2124	1-218-941-11	RES-CHIP	100	5%	1/16W
R1173	1-218-990-11	SHORT CHIP	0			R2125	1-208-683-11	METAL CHIP	1K	0.5%	1/16W
R1174	1-218-990-11	SHORT CHIP	0			R2126	1-208-683-11	METAL CHIP	1K	0.5%	1/16W
R1175	1-218-941-81	RES-CHIP	100	5%	1/16W	R2136	1-218-935-11	RES-CHIP	33	5%	1/16W
						R2139	1-218-937-11	RES-CHIP	47	5%	1/16W
R1176	1-218-943-11	RES-CHIP	150	5%	1/16W						
R1214	1-218-953-11	RES-CHIP	1K	5%	1/16W	R2152	1-218-989-11	RES-CHIP	1M	5%	1/16W
R1231	1-208-643-11	RES-CHIP	22	5%	1/16W	R2153	1-218-989-11	RES-CHIP	1M	5%	1/16W
						R2154	1-218-977-11	RES-CHIP	100K	5%	1/16W
					(SR5/SR5C/SR5E)	R2155	1-218-977-11	RES-CHIP	100K	5%	1/16W
						R2158	1-218-977-11	RES-CHIP	100K	5%	1/16W

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
R2172	1-218-935-11	RES-CHIP	33	5%	1/16W	R3025	1-218-953-11	RES-CHIP	1K	5%	1/16W
R2179	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3026	1-218-977-11	RES-CHIP	100K	5%	1/16W
R2183	1-218-977-11	RES-CHIP	100K	5%	1/16W	R3203	1-218-935-11	RES-CHIP	33	5%	1/16W
R2201	1-218-977-11	RES-CHIP	100K	5%	1/16W	R3204	1-218-935-11	RES-CHIP	33	5%	1/16W
R2202	1-218-973-11	RES-CHIP	47K	5%	1/16W	R3205	1-218-935-11	RES-CHIP	33	5%	1/16W
R2203	1-218-973-11	RES-CHIP	47K	5%	1/16W	R3206	1-218-935-11	RES-CHIP	33	5%	1/16W
R2204	1-218-941-81	RES-CHIP	100	5%	1/16W	R3207	1-218-935-11	RES-CHIP	33	5%	1/16W
R2206	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3208	1-218-935-11	RES-CHIP	33	5%	1/16W
R2329	1-218-977-11	RES-CHIP	100K	5%	1/16W	R3209	1-218-935-11	RES-CHIP	33	5%	1/16W
R2344	1-218-941-81	RES-CHIP	100	5%	1/16W	R3210	1-218-935-11	RES-CHIP	33	5%	1/16W
R2348	1-218-935-11	RES-CHIP	33	5%	1/16W	R3218	1-218-956-11	RES-CHIP	1.8K	5%	1/16W
R2351	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3219	1-218-956-11	RES-CHIP	1.8K	5%	1/16W
R2352	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3224	1-208-675-11	METAL CHIP	470	0.5%	1/16W
R2353	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3238	1-218-973-11	RES-CHIP	47K	5%	1/16W
				(SR7/SR7E/SR8/SR8E)		R3251	1-218-941-81	RES-CHIP	100	5%	1/16W
R2361	1-218-941-81	RES-CHIP	100	5%	1/16W	R3252	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R2368	1-218-990-11	SHORT CHIP	0	(SR5/SR5C/SR5E)		R3253	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R2369	1-218-990-11	SHORT CHIP	0	(SR5/SR5C/SR5E)		R3254	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2372	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3301	1-220-169-11	RES-CHIP	75	5%	1/16W
R2373	1-218-962-11	RES-CHIP	5.6K	5%	1/16W	R3302	1-220-169-11	RES-CHIP	75	5%	1/16W
R2374	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3305	1-220-169-11	RES-CHIP	75	5%	1/16W
R2375	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3307	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2379	1-218-953-11	RES-CHIP	1K	5%	1/16W					(SR5/SR5C/SR7/SR8)	
R2380	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3311	1-218-977-11	RES-CHIP	100K	5%	1/16W
R2385	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3312	1-218-977-11	RES-CHIP	100K	5%	1/16W
R2704	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3313	1-218-973-11	RES-CHIP	47K	5%	1/16W
R2705	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3314	1-218-973-11	RES-CHIP	47K	5%	1/16W
R2706	1-218-977-11	RES-CHIP	100K	5%	1/16W	R3315	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2707	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3316	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2709	1-218-977-11	RES-CHIP	100K	5%	1/16W	R3317	1-218-977-11	RES-CHIP	100K	5%	1/16W
R2730	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3318	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R2901	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3319	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R2902	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3320	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R2903	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3321	1-218-941-81	RES-CHIP	100	5%	1/16W
R2907	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3322	1-218-941-81	RES-CHIP	100	5%	1/16W
R2909	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3331	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R2910	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3333	1-218-975-11	RES-CHIP	68K	5%	1/16W
R2911	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3334	1-218-953-11	RES-CHIP	1K	5%	1/16W
R2912	1-218-944-11	RES-CHIP	180	5%	1/16W	R3335	1-218-960-11	RES-CHIP	3.9K	5%	1/16W
R2915	1-218-944-11	RES-CHIP	180	5%	1/16W	R3336	1-218-971-11	RES-CHIP	33K	5%	1/16W
R2916	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3337	1-218-953-11	RES-CHIP	1K	5%	1/16W
R2917	1-208-873-11	METAL CHIP	270	0.5%	1/16W	R3338	1-218-935-11	RES-CHIP	33	5%	1/16W
				(SR7/SR7E/SR8/SR8E)						(SR7/SR7E/SR8/SR8E)	
R2918	1-208-873-11	METAL CHIP	270	0.5%	1/16W	R3339	1-218-935-11	RES-CHIP	33	5%	1/16W
				(SR7/SR7E/SR8/SR8E)						(SR7/SR7E/SR8/SR8E)	
R2919	1-208-873-11	METAL CHIP	270	0.5%	1/16W	R3340	1-218-965-11	RES-CHIP	10K	5%	1/16W
				(SR7/SR7E/SR8/SR8E)						(SR7/SR7E/SR8/SR8E)	
R2920	1-208-709-11	METAL CHIP	12K	0.5%	1/16W	R3341	1-218-965-11	RES-CHIP	10K	5%	1/16W
				(SR7/SR7E/SR8/SR8E)						(SR7/SR7E/SR8/SR8E)	
R2921	1-208-709-11	METAL CHIP	12K	0.5%	1/16W	R3346	1-218-963-11	RES-CHIP	6.8K	5%	1/16W
				(SR7/SR7E/SR8/SR8E)		R3347	1-218-963-11	RES-CHIP	6.8K	5%	1/16W
R2922	1-208-873-11	METAL CHIP	270	0.5%	1/16W	R3702	1-218-975-11	RES-CHIP	68K	5%	1/16W
R2923	1-208-873-11	METAL CHIP	270	0.5%	1/16W					(SR7/SR7E/SR8/SR8E)	
R2924	1-208-873-11	METAL CHIP	270	0.5%	1/16W	R3705	1-218-953-11	RES-CHIP	1K	5%	1/16W
R2945	1-218-944-11	RES-CHIP	180	5%	1/16W					(SR7/SR7E/SR8/SR8E)	
R2946	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3706	1-208-935-11	METAL CHIP	100K	0.5%	1/16W
				(SR7/SR7E/SR8/SR8E)						(SR7/SR7E/SR8/SR8E)	
R2948	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3708	1-218-965-11	RES-CHIP	10K	5%	1/16W
R3018	1-220-169-11	RES-CHIP	75	5%	1/16W					(SR7/SR7E/SR8/SR8E)	
R3019	1-220-169-11	RES-CHIP	75	5%	1/16W					(SR7/SR7E/SR8/SR8E)	
R3020	1-220-169-11	RES-CHIP	75	5%	1/16W					(SR7/SR7E/SR8/SR8E)	

Ref. No.	Part No.	Description				Ref. No.	Part No.	Description			
R3713	1-208-691-11	METAL CHIP	2.2K	0.5%	1/16W	R4840	1-218-937-11	RES-CHIP	47	5%	1/16W
				(SR7/SR7E/SR8/SR8E)		R4841	1-218-941-81	RES-CHIP	100	5%	1/16W
R3714	1-208-687-11	METAL CHIP	1.5K	0.5%	1/16W	R4844	1-218-989-11	RES-CHIP	1M	5%	1/16W
				(SR7/SR7E/SR8/SR8E)		R5102	1-218-953-11	RES-CHIP	1K	5%	1/16W
R3716	1-218-957-11	RES-CHIP	2.2K	5%	1/16W	R5109	1-218-973-11	RES-CHIP	47K	5%	1/16W
				(SR7/SR7E/SR8/SR8E)		R5119	1-208-935-11	METAL CHIP	100K	0.5%	1/16W
R3717	1-208-861-81	METAL CHIP	82	0.5%	1/16W	R5120	1-208-927-11	METAL CHIP	47K	0.5%	1/16W
R3801	1-218-977-11	RES-CHIP	100K	5%	1/16W						
				(SR5E/SR7/SR7E/SR8/SR8E)		R5122	1-218-989-11	RES-CHIP	1M	5%	1/16W
R3803	1-218-981-81	RES-CHIP	220K	5%	1/16W	R5124	1-245-604-11	METAL CHIP	10M	5%	1/16W
				(SR5/SR5C)		R5133	1-218-977-11	RES-CHIP	100K	5%	1/16W
R3804	1-208-933-11	METAL CHIP	82K	0.5%	1/16W	R5149	1-208-893-11	METAL CHIP	1.8K	0.5%	1/16W
				(SR5/SR5C)		R5150	1-208-703-11	METAL CHIP	6.8K	0.5%	1/16W
R3805	1-208-933-11	METAL CHIP	82K	0.5%	1/16W	R5151	1-218-953-11	RES-CHIP	1K	5%	1/16W
				(SR5/SR5C)		R5153	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4601	1-216-001-00	RES-CHIP	10	5%	1/10W	R5154	1-218-949-11	RES-CHIP	470	5%	1/16W
R4602	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5156	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4603	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R5157	1-218-977-11	RES-CHIP	100K	5%	1/16W
R4604	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5160	1-218-977-11	RES-CHIP	100K	5%	1/16W
R4605	1-218-989-11	RES-CHIP	1M	5%	1/16W	R5161	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4606	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5162	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4632	1-218-989-11	RES-CHIP	1M	5%	1/16W	R5163	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4637	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5166	1-218-945-11	RES-CHIP	220	5%	1/16W
R4702	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R5169	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4703	1-218-965-11	RES-CHIP	10K	5%	1/16W	R5170	1-218-989-11	RES-CHIP	1M	5%	1/16W
R4704	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5171	1-218-977-11	RES-CHIP	100K	5%	1/16W
R4705	1-208-931-11	METAL CHIP	68K	0.5%	1/16W	R5172	1-218-985-11	RES-CHIP	470K	5%	1/16W
R4706	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R5174	1-218-977-11	RES-CHIP	100K	5%	1/16W
R4707	1-216-789-11	METAL CHIP	2.2	5%	1/10W	R5175	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4708	1-218-941-81	RES-CHIP	100	5%	1/16W	R5177	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4719	1-218-983-11	RES-CHIP	330K	5%	1/16W	< COMPOSITION CIRCUIT BLOCK >					
R4721	1-218-969-11	RES-CHIP	22K	5%	1/16W	RB1001	1-242-963-21	RES, NETWORK	33 (1005X4)		
R4724	1-218-953-11	RES-CHIP	1K	5%	1/16W	RB1002	1-242-963-21	RES, NETWORK	33 (1005X4)		
R4725	1-218-969-11	RES-CHIP	22K	5%	1/16W	RB1003	1-242-963-21	RES, NETWORK	33 (1005X4)		
R4727	1-218-969-11	RES-CHIP	22K	5%	1/16W	RB1004	1-242-963-21	RES, NETWORK	33 (1005X4)		
R4728	1-218-977-11	RES-CHIP	100K	5%	1/16W	RB1005	1-242-963-21	RES, NETWORK	33 (1005X4)		
R4729	1-218-989-11	RES-CHIP	1M	5%	1/16W						
R4730	1-218-941-81	RES-CHIP	100	5%	1/16W	RB1701	1-234-400-21	CONDUCTOR, NETWORK	(1005X4)		
R4733	1-218-941-81	RES-CHIP	100	5%	1/16W				(SR5/SR5C/SR5E)		
R4793	1-208-933-11	METAL CHIP	82K	0.5%	1/16W	RB1702	1-234-400-21	CONDUCTOR, NETWORK	(1005X4)		
R4794	1-208-944-81	METAL CHIP	240K	0.5%	1/16W				(SR5/SR5C/SR5E)		
R4795	1-208-691-11	METAL CHIP	2.2K	0.5%	1/16W	RB1703	1-234-400-21	CONDUCTOR, NETWORK	(1005X4)		
* R4796	1-208-889-11	METAL CHIP	1.2K	0.5%	1/16W				(SR5/SR5C/SR5E)		
R4802	1-218-969-11	RES-CHIP	22K	5%	1/16W	RB1704	1-234-400-21	CONDUCTOR, NETWORK	(1005X4)		
R4807	1-218-970-11	RES-CHIP	27K	5%	1/16W				(SR5/SR5C/SR5E)		
R4808	1-208-927-11	METAL CHIP	47K	0.5%	1/16W	RB2101	1-234-375-21	RES, NETWORK	1K (1005X4)		
R4822	1-208-709-11	METAL CHIP	12K	0.5%	1/16W	RB2102	1-234-375-21	RES, NETWORK	1K (1005X4)		
R4823	1-208-935-11	METAL CHIP	100K	0.5%	1/16W	RB2103	1-234-375-21	RES, NETWORK	1K (1005X4)		
R4824	1-208-927-11	METAL CHIP	47K	0.5%	1/16W	RB2104	1-234-378-21	RES, NETWORK	10K (1005X4)		
R4826	1-208-699-11	METAL CHIP	4.7K	0.5%	1/16W	RB2703	1-242-963-21	RES, NETWORK	33 (1005X4)		
				(SR7/SR7E/SR8/SR8E)	RB2704	1-242-963-21	RES, NETWORK	33 (1005X4)			
R4827	1-208-935-11	METAL CHIP	100K	0.5%	1/16W	RB2705	1-234-381-21	RES, NETWORK	100K (1005X4)		
				(SR7/SR7E/SR8/SR8E)	RB2706	1-234-381-21	RES, NETWORK	100K (1005X4)			
R4833	1-218-977-11	RES-CHIP	100K	5%	1/16W	RB2707	1-234-381-21	RES, NETWORK	100K (1005X4)		
				(SR7/SR7E/SR8/SR8E)	RB3701	1-234-369-21	RES, NETWORK	10 (1005X4)			
R4834	1-218-990-11	SHORT CHIP	0	(SR5/SR5C/SR5E)				(SR7/SR7E/SR8/SR8E)			
R4835	1-218-985-11	RES-CHIP	470K	5%	1/16W	RB5101	1-234-375-21	RES, NETWORK	1K (1005X4)		
R4837	1-218-985-11	RES-CHIP	470K	5%	1/16W						
R4839	1-218-941-81	RES-CHIP	100	5%	1/16W						

< ACCELEROMETER >

- * SE3801 1-478-556-11 3 AXIS ACCELEROMETER
(SR5E/SR7/SR7E/SR8/SR8E)
- * SE3802 1-480-307-21 3 AXIS ACCELEROMETER (SR5/SR5C)

< VIBRATOR >

- * X1701 1-813-763-21 QUARTZ CRYSTAL OSCILLATOR
(80.919081MHz) (SR5/SR5C)
 - * X1701 1-813-764-21 QUARTZ CRYSTAL OSCILLATOR
(62.370000MHz) (SR5E)
 - * X1701 1-813-854-21 QUARTZ CRYSTAL OSCILLATOR
(74.250000MHz) (SR7E/SR8E)
 - * X1701 1-813-855-21 QUARTZ CRYSTAL OSCILLATOR
(89.010989MHz) (SR7/SR8)
 - * X1802 1-767-205-81 VIBRATOR, CRYSTAL (20MHz)
 - * X2101 1-813-403-21 QUARTZ CRYSTAL OSCILLATOR (12MHz)
 - * X5101 1-781-525-11 VIBRATOR, CRYSTAL (32.768kHz)
-