



Mat. - Nr. - Konstante
 3740

Gebrauchsanweisung
 51 6969
 (D, F, GB, I, NL, E)
 V01, V02, V03, V04, V08
 51 7293
 (10A, D, GB, F, I, DK)
 V05, V06
 51 7401
 (S)
 V07
 Programmtabelle
 51 7597
 (DK, SS)
 V05, V07
 51 7579
 (D, GB, F, I, NL, E)
 V01, V02, V03,
 V04, V06, V08
 Kochbuch
 51 5732
 (D)
 V01, V04
 51 5858
 (F)
 V02
 51 5859
 (NL)
 V02, V03, V08

Zubehör:
 Einbaurahmen
 HMZ8122
 Alu-Backblech
 HMZ19BB
 Glaspfanne
 HMZ10GP
 Glasbräter
 HMZ21GB
 Abdeckplatte
 HMZ8720





Mat. - Nr. - Konstante
 3740

- 1) 11 4537
 Glaspfanne
- 2) 11 4539
- 3) 11 4538
 Backblech
- 4) 03 2778
- 5) 27 1244
 V01, V02, V03, V04,
 V05, V07, V08
 27 1621
 V06
- 6) 27 0323
 V01, V02, V03, V04,
 V05, V07, V08
 27 1620
 V06
- 7) 09 2677
 kompl.
 V01, V02, V03, V04,
 V05, V07, V08
 09 2676
 kompl.
 V06

02 8732
 Anschlag-Backblech

Mat. - Nr. - Konstante
 3740

