


5-3. LE40A65*A/LE40A68*M/LE40A616A Exploded View



5-3-1. LE40A65*A/LE40A68*M Parts List

| Location No. | Code No. | Description & Specification | Q'ty | S.A/S.N.A | Remark |
|--------------|---|--|------|-----------|--------|
| T0003 | BN96-06842C | ASSY COVER P-FRONT;40,L650A,EO(SD),PC(CL | 1 | S.A | |
| T0175 | BN96-06809A | ASSY SPEAKER P;8ohm,P750 50",Down Firing | 1 | S.A | |
| M0215 | BN07-00529A BN07-00615A BN07-00635A | LCD-PANEL;LTF400HC01 | 1 | S.A | |
| T0447 | BN96-06883C | ASSY BRACKET P-PANEL;40,L650,UO,,,,,GASK | 1 | S.N.A | |
| M0027 | BN96-06259B | ASSY STAND P-BASE;40AA1,ABS+PMMA,HB,RD02 | 1 | S.A | |
| M0115 | BN61-02882A | BRACKET-STAND LINK;TULIP,40,SECC,T1.6,-, | 1 | S.N.A | |
| M0146 | BN61-03414A | BRACKET-PANEL TOP;PEONY52,SECC T1.2 | 2 | S.N.A | |
| M0014 | BN94-01741B | ASSY PCB MAIN-AMLCD;LE40A656A1FXXC | 1 | S.A | |
| M0175 | BN96-07244B | ASSY BOARD P-TOUCH FUNCTION&IR;LN46A650A | 1 | S.A | |
| M0013 | BN96-06874A | ASSY COVER P-REAR;40,L650A,ABS+PMMA,HB,B | 1 | S.A | |

5-3-2. LE40A616A Parts List

| Location No. | Code No. | Description & Specification | Q'ty | S.A/S.N.A | Remark |
|--------------|---|--|------|-----------|--------|
| T0003 | BN96-06842P | ASSY COVER P-FRONT;40,L650A,EO(SD),PC(CL | 1 | S.A | |
| T0175 | BN96-06809B | ASSY SPEAKER P;8ohm,P750 50",Down Firing | 1 | S.A | |
| M0215 | BN07-00568A BN07-00616A BN07-00636A | LCD-PANEL;LTF400HC01 | 1 | S.A | |
| T0447 | BN96-06883C | ASSY BRACKET P-PANEL;40,L650,UO,,,,,GASK | 1 | S.N.A | |
| M0027 | BN96-06259B | ASSY STAND P-BASE;40AA1,ABS+PMMA,HB,RD02 | 1 | S.A | |
| M0115 | BN61-02882A | BRACKET-STAND LINK;TULIP,40,SECC,T1.6,-, | 1 | S.N.A | |
| M0146 | BN61-03414A | BRACKET-PANEL TOP;PEONY52,SECC T1.2 | 2 | S.N.A | |
| M0014 | BN94-01741M | ASSY PCB MAIN-AMLCD;LE40A656A1FXXC | 1 | S.A | |
| M0175 | BN96-07244B | ASSY BOARD P-TOUCH FUNCTION&IR;LN46A650A | 1 | S.A | |
| M0013 | BN96-06874C | ASSY COVER P-REAR;40,L650A,ABS+PMMA,HB,B | 1 | S.A | |