LE-233-EXPLODED

Power board and gas assembly NI 63 NI 65 ALT5 B100 (LE-202) Spare part number

	Screw (10)	
1.	Gas valve automatic 3/4 water to the manual (o) Gas valve automatic (o)	Not available
		501244*
2.	Gas inlet hose	
3.	Screw (5x)	
4.	Brass wall cover	
5.	Earth connection	
6.	Screw (4x)	
7.	Power board cover	
8.	Power board	491312
9.	Power board connector (4 valve)	
	Power board (+ display)	491303
10.	Power board base	
11.	Screw (5x)	
12.	Gas box	
13.	Spark electrode	420300
14.	Screw (5x)	
15.	Bushing	
16.	Gasket	
17.	Mounting bracket gas valve	
18.	Burner	420305
19.	Burner box cover	
20.	Burner box cover	
21.	Gasket	
22.	Screw (4x)	

* When UL has to be marked (not UL the gas tube has to also needed. Part number is depending on the model and can be found on the part itself.