



Order	Change		Ref.No.	Part No.	Part Name & Description	Qty	Remarks	Diagram ID
Order			IC3901	L2ES00000018	Gyro Sensor IC	1	E.S.D.	02
Order			IC3902	L2ES00000019	Gyro Sensor IC	1	E.S.D.	02
Order			Q3901	B1ADKB000015	TRANSISTOR	1	E.S.D.	02
Order			L3901	G1C100MA0410	CHIP INDUCTOR 10UH	1		02
Order			FP3901	K1MN22BA0197	CONNECTOR 22P	1		02
Order			HS3901	K1NA09E00038	CONNECTOR 9P	1		02
Order			C3901	F1G1C104A080	C.CAPACITOR CH 16V 0.1U	1		02
Order			C3903	ECJ0EB1C103K	C.CAPACITOR CH 16V 0.01U	1		02
Order			C3904	ECJ0EB1C103K	C.CAPACITOR CH 16V 0.01U	1		02
Order			C3905	ECJ0EC1H270J	C.CAPACITOR CH 50V 27P	1		02
Order			C3906	ECJ0EC1H270J	C.CAPACITOR CH 50V 27P	1		02
Order			C3907	ECJ0EC1H270J	C.CAPACITOR CH 50V 27P	1		02
Order			C3908	ECJ0EC1H270J	C.CAPACITOR CH 50V 27P	1		02
Order			C3909	ECJ0EC1H270J	C.CAPACITOR CH 50V 27P	1		02
Order			C3910	F3G0J107A017	C.CAPACITOR CH 6.3V 100U	1		02
Order			C3911	F1G0J1050007	C.CAPACITOR CH 6.3V 1U	1		02
Order			C3912	F3F0J226A032	T.CAPACITOR CH 6.3V 22U	1		02
Order			C3913	F3F0J226A032	T.CAPACITOR CH 6.3V 22U	1		02
Order			C3914	F3F0J476A032	E.CAPACITOR CH 6.3V 47U	1		02
Order			R3902	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		02
Order			R3903	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		02
Order			R3904	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		02
Order			R3905	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		02
Order			R3906	ERJ2GEJ220	M.RESISTOR CH 1/16W 22	1		02
Order			R3907	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		02

Order		R3908	D0GB150JA057	M.RESISTOR CH 1/10W 15	1		02
Order		R3909	ERJ2GEJ333	M.RESISTOR CH 1/16W 33K	1		02
Order		R3910	ERJ2GEJ331	M.RESISTOR CH 1/16W 330	1		02
Order		R3911	ERJ2GEJ271	M.RESISTOR CH 1/10W 270	1		02
Order		R3912	ERJ2GEJ102X	M.RESISTOR CH 1/16W 1K	1		02
Order		R3913	ERJ2GEJ102X	M.RESISTOR CH 1/16W 1K	1		02
Order		R3915	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		02
Order		R3916	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		02
Order		R3917	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		02
Order		R3918	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		02
Order		D6701	B3AAB0000334	LED	1	E.S.D.	05
Order		D6702	B3AGB0000051	LED	1	E.S.D.	05
Order		S6701	K0D112B00145	SWITCH, PLAY/REC	1		05
Order		S6702	K0F111A00589	SWITCH, SS	1		05
Order		LB6701	J0JJC0000015	FILTER	1		05
Order		LB6702	J0JJC0000015	FILTER	1		05
Order		JK6701	K4ZZ04000056	JK, BATTERY	1		05
Order		JK6702	K2EB2B000024	JK, DC IN	1		05
Order		FP6701	K1KB40AA0094	CONNECTOR 40P	1		05
Order		FP6703	K1MN06BA0197	CONNECTOR 6P	1		05
Order		P6702	K1KA02AA0051	CONNECTOR 2P	1		05
Order		R6701	ERJ2GEJ223	M.RESISTOR CH 1/16W 22K	1		05
Order		R6702	ERJ2GEJ472	M.RESISTOR CH 1/10W 4.7K	1		05
Order		R6703	ERJ2GEJ103	M.RESISTOR CH 1/10W 10K	1		05
Order		Q901	DSA300100L	TRANSISTOR	1	E.S.D.	07
Order		D901	B3AFB0000200	LED	1	E.S.D.	07
Order		D902	B3AFB0000200	LED	1	E.S.D.	07

Order		D903	B3AFB0000200	LED	1	E.S.D.	07
Order		D904	B3AFB0000200	LED	1	E.S.D.	07
Order		D905	B0BC016A0267	DIODE	1	E.S.D.	07
Order		D906	B0BC5R6A0266	DIODE	1	E.S.D.	07
Order		S901	K0F111A00589	SWITCH, AF/AE	1		07
Order		S902	K0F111A00589	SWITCH, MENU	1		07
Order		 B901	ML-614S/DN	BUTTON BATTERY	1	[Energy]	07
Order		FP901	K1MN26BA0197	CONNECTOR 26P	1		07
Order		FP902	K1MN24BA0197	CONNECTOR 24P	1		07
Order		FP903	K1MN06BA0197	CONNECTOR 6P	1		07
Order		C903	ECJ1VC1H390J	C.CAPACITOR CH 50V 39P	1		07
Order		C904	ECJ1VC1H390J	C.CAPACITOR CH 50V 39P	1		07
Order		C905	ECJ1VC1H390J	C.CAPACITOR CH 50V 39P	1		07
Order		C906	F1J1A475A023	C.CAPACITOR CH 10V 4.7U	1		07
Order		C908	ECJ1XB1C104K	C.CAPACITOR CH 16V 0.1U	1		07
Order		C909	ECJ1VB1A105K	C.CAPACITOR CH 10V 1U	1		07
Order		C910	ECJ1VB0J105K	C.CAPACITOR CH 6.3V 1U	1		07
Order		R903	ERJ3RBD271	M.RESISTOR CH 1/10W 270	1		07
Order		R904	ERJ3RBD271	M.RESISTOR CH 1/10W 270	1		07
Order		R905	ERJ3RBD271	M.RESISTOR CH 1/10W 270	1		07
Order		R906	D0GB222JA041	M.RESISTOR CH 1/10W 2.2K	1		07
Order		R907	D0GB103JA057	M.RESISTOR CH 1/10W 10K	1		07
Order		R908	D0GB272JA041	M.RESISTOR CH 1/10W 2.7K	1		07
Order		R909	D0GB103JA057	M.RESISTOR CH 1/10W 10K	1		07
Order		R910	D0GB272JA041	M.RESISTOR CH 1/10W 2.7K	1		07
Order		R911	D0GB562JA041	M.RESISTOR CH 1/10W 5.6K	1		07
Order		R912	D0GB183JA057	M.RESISTOR CH 1/10W 18K	1		07

Order		R913	ERJ3RBD563V	M.RESISTOR CH 1/10W 56K	1		07
Order		R914	ERJ3RBD562	M.RESISTOR CH 1/10W 5.6K	1		07
Order		R915	D0GB473JA057	M.RESISTOR CH 1/10W 47K	1		07
Order		R917	D0GB562JA041	M.RESISTOR CH 1/10W 5.6K	1		07
Order		R918	D0GB105JA057	M.RESISTOR CH 1/10W 1M	1		07
Order		D4301	B3AFB0000313	LED	1	T51PU,PR, T56PU E.S.D.	09
Order		1	VEP02584A	REAR P.C.B.	1	(RTL) E.S.D.	M1
Order		2	LSKF0753	REAR COVER	1		M1
Order		3	LSGK1050	FRONT CASE	1	(-K,-H)	M1
Order		3	LSGK1042	FRONT CASE	1	(-N,-R,-A,-P,-W)	M1
Order		4	LSYK2896	LENS PIECE U	1	(SDR-T50, T55, S50)	M1
Order		4	LSYK2897	LENS PIECE U	1	T51PU,PR, T56PU	M1
Order		5	LSYK2901	FRONT PANEL U	1		M1
Order		6	LSGT0633	SHUTTER KNOB	1		M1
Order		7	VDL2468	LED LIGHT LENS	1	T51PU,PR, T56PU	M1
Order		8	VEP20C83A	LED LIGHT P.C.B.	1	T51PU,PR, T56PU (RTL) E.S.D.	M1
Order		9	LSMG0199	LENS DAMPER	1		M1
Order		10	LSKM1994	GRIP COVER	1		M1
Order		11	LSMA1064	STRAP ANGLE	1		M1
Order		12	LSMA1064	STRAP ANGLE	1		M1
Order		13	LSGQ0371	GRIP BELT U	1		M1
Order		14	LSYK2951	JACK COVER(SD) u-As Mold(GLAY)	1		M1
Order		22	VEP03H83BP	MAIN P.C.B.	1	T50EG,EP,EF,EB,EC, T55EB (RTL) E.S.D.	M1
Order		22	VEP03H83BQ	MAIN P.C.B.	1	T50EE,GC,GK,GA, T55GC,GK,GA (RTL) E.S.D.	M1
Order		22	VEP03H83BN	MAIN P.C.B.	1	T50P,PC, T55P,PC (RTL) E.S.D.	M1
Order		22	VEP03H83BM	MAIN P.C.B.	1	T51PU,PR, T56PU (RTL) E.S.D.	M1
Order		22	VEP03H83CP	MAIN P.C.B.	1	S50EG,EP,EF,EB,EC (RTL) E.S.D.	M1

Order		22	VEP03H83CQ	MAIN P.C.B.	1	S50EE,GC,GN,GA (RTL) E.S.D.	M1
Order		22	VEP03H83CN	MAIN P.C.B.	1	S50P,PC,PU,PR (RTL) E.S.D.	M1
Order		23	LSKM1999	REAR CASE	1		M1
Order		24	LSGT0630	BATTERY RELEASE KNOB	1		M1
Order		25	LSMB0369	BATTERY RELEASE SPRING	1		M1
Order		26	LSMD1117	BATTERY RELEASE HOLDER	1		M1
Order		27	LSGT0631	MODE SELECT KNOB	1		M1
Order		28	LSGL1553	LED PANEL(REAR)	1		M1
Order		29	LSSC1111	EARTH PLATE(MODE)	1		M1
Order		30	LSGT0632	S/S BUTTON	1		M1
Order		31	VEP21310A	DC BATT OP FPC	1	(RTL) E.S.D.	M1
Order		32	LSSC1112	EARTH PLATE (REAR)	1		M1
Order		35	LSYK2834	SIDE CASE R U	1	(EXCEPT P,PC,PU,PR)	M1
Order		35	LSYK2833	SIDE CASE R U	1	T50P,PC, T55P,PC, S50P,PC,PU,PR	M1
Order		35	LSYK2835	SIDE CASE R U	1	T51PU,PR, T56PU	M1
Order		36	LSKM2010	TOP CASE	1	(-K)	M1
Order		36	LSKM2012	TOP CASE	1	(-R)	M1
Order		36	LSKM2011	TOP CASE	1	(-A)	M1
Order		36	LSKM2008	TOP CASE	1	(-N)	M1
Order		36	LSKM2009	TOP CASE	1	(-P)	M1
Order		36	LSKM2049	TOP CASE	1	(-W)	M1
Order		36	LSKM2065	TOP CASE	1	(-H)	M1
Order		37	LSGU0779	TOP BUTTON	1		M1
Order		38	LSGK1047	DECO. PIECE (TOP)	1	(-K,-H)	M1
Order		38	LSGK1039	DECO. PIECE (TOP)	1	(-N,-R,-A,-P,-W)	M1
Order		39	LSYK2810	TOP OPERATION U	1		M1
Order		40	L0AA01A00049	SPEAKER	1		M1

Order		41	LSMC0178	SPEAKER ANGLE	1		M1
Order		42	LSMA1169	MAIN FRAME	1		M1
Order		43	LSHN0021	TRIPOD SCREW	1		M1
Order		44	LSKM1991	SHUTTER GUIDE	1		M1
Order		45	LSML0386	SHUTTER ARM	1		M1
Order		46	LSKF0749	SHUTTER PANEL	1		M1
Order		47	LSGF0561	SHUTTER COVER	1		M1
Order		48	LSMB0370	SHUTTER SPRING	1		M1
Order		49	LSEQ0874	MIC U	1		M1
Order		50	VEP03H89A	ESD P.C.B.-4GB	1	(SDR-T50, T51) E.S.D.	M1
Order		50	VEP03H89B	ESD P.C.B.-8GB	1	(SDR-T55, T56) E.S.D.	M1
Order		51	VWJ2102	RELAY FPC	1	(SDR-T50, T51, T55, T56)	M1
Order		54	VEE1H20	LIGHT WIRE	1	T51PU,PR, T56PU	M1
Order		56	VWJ2129	REAR F.P.C.	1		M1
Order		58	LSSC1110	SIDE L ANGLE	1		M1
Order		B1	XQN16+BJ4FN	SCREW	1		M1
Order		B2	XQN16+BJ4FN	SCREW	1		M1
Order		B4	XQN16+BJ5FN	SCREW	1		M1
Order		B5	XQN16+BJ5FN	SCREW	1		M1
Order		B6	XQN16+BJ5FN	SCREW	1		M1
Order		B7	XQN16+B4FJK	SCREW	1		M1
Order		B8	XQN16+BJ5FJK	SCREW	1		M1
Order		B9	XQN16+B4FJK	SCREW	1		M1
Order		B10	XQN16+B4FJK	SCREW	1		M1
Order		B11	XQN16+B4FJK	SCREW	1		M1
Order		B12	XQN16+B4FJK	SCREW	1		M1
Order		B13	XQN16+B4FJK	SCREW	1		M1
























Order		B14	XQN16+B4FJK	SCREW	1		M1
Order		B15	XQN16+B4FJK	SCREW	1		M1
Order		B16	XQN16+B4FJK	SCREW	1		M1
Order		B18	XQN16+BJ5FJK	SCREW	1		M1
Order		B19	LSHD0132	SCREW	1		M1
Order		B20	LSHD0132	SCREW	1		M1
Order		B21	XQN16+BJ4FN	SCREW	1		M1
Order		B22	XQN16+BJ4FN	SCREW	1		M1
Order		B23	XQN16+BJ5FJK	SCREW	1		M1
Order		B24	XQN16+BJ5FN	SCREW	1		M1
Order		B25	XQN16+B4FJK	SCREW	1		M1
Order		B30	XQN16+B4FJK	SCREW	1		M1
Order		B31	XQN16+B4FJK	SCREW	1		M1
Order		B32	XQN16+BJ5FJK	SCREW	1		M1
Order		B33	XQN16+B4FJK	SCREW	1		M1
Order		B34	XQN16+B4FN	SCREW	1		M1
Order		B35	XQN16+B4FN	SCREW	1		M1
Order		B36	XQN16+BJ5FJK	SCREW	1		M1
Order		B37	XQN16+BJ4FN	SCREW	1		M1
Order		B38	XQN16+BJ4FN	SCREW	1		M1
Order		B39	XQN16+BJ4FN	SCREW	1		M1
Order		B40	XQN16+BJ4FN	SCREW	1		M1
Order		B41	XQN16+B4FN	SCREW	1		M1
Order		B42	XQN16+B4FN	SCREW	1		M1
Order		B43	XQN16+B4FN	SCREW	1		M1
Order		B44	XQN16+B4FJK	SCREW	1		M1
Order		B45	XQN16+B4FJK	SCREW	1		M1





Order		B46	LSHD0132	SCREW	1		M1
Order		B47	LSHD0132	SCREW	1		M1
Order		15	LSKM1982	LCD CASE B	1		M2
Order		16	LSGU0776	LCD OPERATION BUTTON	1		M2
Order		17	LSGU0776	LCD OPERATION BUTTON	1		M2
Order		18	LSSC1107	LCD SHIELD CASE	1		M2
Order		19	LSYK2868	LCD U	1		M2
Order		20	VEP26326A	MONITOR P.C.B.	1	(RTL) E.S.D.	M2
Order		21	LSYK2869	MENU SELECTOR U	1		M2
Order		33	LSYK2865	SHAFT CASE U	1	(-K,-H)	M2
Order		33	LSYK2866	SHAFT CASE U	1	(-N,-R,-A,-P,-W)	M2
Order		34	LSYK2880	LCD CASE A U	1	(-K)T50EG,EP,EF,EB,EC,EE,P,PC,GC,GA	M2
Order		34	LSYK2882	LCD CASE A U	1	(-R)T50PC,GC,GA	M2
Order		34	LSYK2883	LCD CASE A U	1	T50PC-A	M2
Order		34	LSYK2881	LCD CASE A U	1	(-N)T50GC,GK,GA	M2
Order		34	LSYK2884	LCD CASE A U	1	(-P)T50GC,GK,GA	M2
Order		34	LSYK2885	LCD CASE A U	1	(-W)T50GC,GK,GA	M2
Order		34	LSYK2997	LCD CASE A U	1	(-K)T51PU,PR	M2
Order		34	LSYK2998	LCD CASE A U	1	(-N)T51PU,PR	M2
Order		34	LSYK2999	LCD CASE A U	1	T51PU-R	M2
Order		34	LSYK3000	LCD CASE A U	1	T51PU-P	M2
Order		34	LSYK2886	LCD CASE A U	1	(-K)T55EB,P,PC,GC,GA	M2
Order		34	LSYK2887	LCD CASE A U	1	(-N)T55P,GK	M2
Order		34	LSYK2888	LCD CASE A U	1	T55P-A	M2
Order		34	LSYK2889	LCD CASE A U	1	T55GK-P	M2
Order		34	LSYK2890	LCD CASE A U	1	T55GK-W	M2
Order		34	LSYK3001	LCD CASE A U	1	T56PU-K	M2

Order	34	LSYK2875	LCD CASE A U	1	(-K)S50EG,EP,EF,EB,EC,EE,P,PC,PU,PR,GC,GN,GA	M2
Order	34	LSYK2876	LCD CASE A U	1	(-N)S50EG,EP,EE,P,PC,GC,GA	M2
Order	34	LSYK2877	LCD CASE A U	1	(-R)S50EG,EP,EF,EB,EC,EE,GC,GN,GA	M2
Order	34	LSYK2996	LCD CASE A U	1	(-A)S50EG,EF,EB,EC,EE,P,PC,GN	M2
Order	34	LSYK2878	LCD CASE A U	1	(-P)S50EG,EC,GC,GA	M2
Order	34	LSYK2879	LCD CASE A U	1	(-W)S50EG,EP,EF,EB,EC,GC,GA	M2
Order	34	LSYK2995	LCD CASE A U	1	S50EB-H	M2
Order	B17	XQN16+BJ4FN	SCREW	1		M2
Order	B26	XQN16+B3FN	SCREW	1		M2
Order	B27	XQN16+B3FN	SCREW	1		M2
Order	401	LSXN0061	LENS U	1		M3
Order	401-1	L6HA66NB0011	ZOOM MOTOR UNIT	1		M3
Order	401-2	L6HA66NB0012	FOCUS MOTOR UNIT	1		M3
Order	401-3	LSEM0118	AUTO IRIS U	1		M3
Order	402	VEP22409A	CCD P.C.B.	1		M3
Order	403	LSDW0141	CCD CASE	1		M3
Order	404	LSFL0343	OPTICAL LPF	1		M3
Order	405	LSMX0246	CCD CUSHION	1		M3
Order	B401	LSHD0136	SCREW	1		M3
Order	B402	LSHD0136	SCREW	1		M3
Order	B403	XQN16+BJ4FN	SCREW	1		M3
Order	B404	XQN16+BJ4FN	SCREW	1		M3
Order	B405	XQN16+BJ4FN	SCREW	1		M3
Order	B406	XQN16+BJ4FN	SCREW	1		M3
Order	B407	XQN16+BJ4FN	SCREW	1		M3
Order	B408	XQN16+BJ4FN	SCREW	1		M3
Order	501	VPG2D89	PACKING CASE U	1	(-K)T50EG,EP,EF,EB,EC,EE,GA	M4

Order		501	VPG2D88	PACKING CASE U	1	(-K)T50P,PC	M4
Order		501	VYQ5598	PACKING CASE U	1	(-R)T50PC	M4
Order		501	VYQ5326	PACKING CASE U	1	(-A)T50PC	M4
Order		501	VPG2H06	PACKING CASE U	1	(-K)T50GC	M4
Order		501	VYQ5325	PACKING CASE U	1	(-N)T50GC	M4
Order		501	VYQ5329	PACKING CASE U	1	(-R)T50GC	M4
Order		501	VYQ5333	PACKING CASE U	1	(-P)T50GC	M4
Order		501	VYQ5336	PACKING CASE U	1	(-W)T50GC	M4
Order		501	VYQ5324	PACKING CASE U	1	(-N)T50GK	M4
Order		501	VYQ5332	PACKING CASE U	1	(-P)T50GK	M4
Order		501	VYQ5335	PACKING CASE U	1	(-W)T50GK	M4
Order		501	VYQ5323	PACKING CASE U	1	(-N)T50GA	M4
Order		501	VYQ5328	PACKING CASE U	1	(-R)T50GA	M4
Order		501	VYQ5331	PACKING CASE U	1	(-P)T50GA	M4
Order		501	VYQ5334	PACKING CASE U	1	(-W)T50GA	M4
Order		501	VPG2K19	PACKING CASE U	1	(-K)T51PU,PR	M4
Order		501	VYQ5537	PACKING CASE U	1	(-N)T51PU,PR	M4
Order		501	VYQ5538	PACKING CASE U	1	(-R)T51PU	M4
Order		501	VYQ5539	PACKING CASE U	1	(-P)T51PU	M4
Order		501	VPG2J57	PACKING CASE U	1	(-K)T55EB,GA	M4
Order		501	VPG2D94	PACKING CASE U	1	(-K)T55P,PC	M4
Order		501	VYQ5318	PACKING CASE U	1	(-N)T55P	M4
Order		501	VYQ5319	PACKING CASE U	1	(-A)T55P	M4
Order		501	VPG2H08	PACKING CASE U	1	(-K)T55GC	M4
Order		501	VYQ5184	PACKING CASE U	1	(-N)T55GK	M4
Order		501	VYQ5320	PACKING CASE U	1	(-P)T55GK	M4
Order		501	VYQ5321	PACKING CASE U	1	(-W)T55GK	M4

Order		501	VPG2K17	PACKING CASE U	1	(-K)T56PU	M4
Order		501	VPG2D83	PACKING CASE U	1	(-K)S50EG,EP,EF,EB,EC,EE,GN,GA	M4
Order		501	VYQ5297	PACKING CASE U	1	(-N)S50EG,EP,EE,GA	M4
Order		501	VYQ5301	PACKING CASE U	1	(-R)S50EG,EP,EF,EB,EC,EE,GN,GA	M4
Order		501	VYQ5300	PACKING CASE U	1	(-A)S50EG,EF,EB,EC,EE,GN	M4
Order		501	VYQ5303	PACKING CASE U	1	(-P)S50EG,EC,GA	M4
Order		501	VYQ5305	PACKING CASE U	1	(-W)S50EG,EP,EF,EB,EC,GA	M4
Order		501	VPG2K68	PACKING CASE U	1	(-H)S50EB	M4
Order		501	VPG2D82	PACKING CASE U	1	(-K)S50P,PC,PU,PR	M4
Order		501	VYQ5296	PACKING CASE U	1	(-N)S50P,PC	M4
Order		501	VYQ5299	PACKING CASE U	1	(-A)S50P,PC	M4
Order		501	VPG2H04	PACKING CASE U	1	(-K)S50GC	M4
Order		501	VYQ5298	PACKING CASE U	1	(-N)S50GC	M4
Order		501	VYQ5302	PACKING CASE U	1	(-R)S50GC	M4
Order		501	VYQ5304	PACKING CASE U	1	(-P)S50GC	M4
Order		501	VYQ5306	PACKING CASE U	1	(-W)S50GC	M4
Order		502	VPF1294	POLYETHYLENE BAG	1		M4
Order		503	VPF1388	PROTECT BAG	1		M4
Order		504	K2KYYYY00054	AV CABLE	1		M4
Order		505	K1HY04YY0032	USB CABLE	1		M4
Order		⚠ 506	K2CQ29A00002	AC CORD	1	T50EG,EP,EF,EC,EE,GC,GA, T55GC,GA, S50EG,EP,EF,EC,EE,GC,GA	M4
Order		⚠ 506	K2CA2CA00025	AC CORD	1	T50P,PC, T51PU, T55P,PC, T56PU, S50P,PC,PU	M4
Order		⚠ 506	K2CA2YY00070	AC CORD	1	T50GK, T55GK	M4
Order		⚠ 506	K2CJ29A00003	AC CORD	1	T51PR, S50PR	M4
Order		⚠ 506	K2CT39A00002	AC CORD	1	T50EB,GC,GA, T55EB,GC,GA, S50EB,GC,GA	M4
Order		⚠ 506	K2CJ29A00002	AC CORD	1	S50GN	M4
Order		⚠ 507	VSK0712	AC ADAPTER CHARGER	1	(EXCEPT P,PC,GK)	M4

Order	 507	VSK0713	AC ADAPTER CHARGER	1	T50GK, T55GK	M4
Order	 507	VSK0711	AC ADAPTER CHARGER	1	T50P,PC, T55P,PC, S50P,PC	M4
Order	508	VPN6972	PAD	1		M4
Order	508	VPN6994	PAD	1	T50GC, T55GC, S50GC	M4
Order	509		CD-ROM	1	(EXCEPT GK)	M4
Order	509		CD-ROM	1	T50GK, T55GK	M4
Order	 510	VQT2L19	O/I	1	T50EG, S50EG GERMAN/FRENCH	M4
Order	 510	VQT2L20	O/I	1	T50EG, S50EG ITALIAN/DUTCH	M4
Order	 510	VQT2L21	O/I	1	T50EG, S50EG TURKISH	M4
Order	 510	VQT2L22	O/I	1	T50EF, S50EF FRENCH	M4
Order	 510	VQT2L28	O/I	1	T50EB, T55EB, S50EB ENGLISH	M4
Order	 510	VQT2L33	O/I	1	T50EE, S50EE RUSSIAN	M4
Order	 510	VQT2L34	O/I	1	T50EE, S50EE UKRAINIAN	M4
Order	 510	VQT2L14	O/I	1	T50P,PC, T55P,PC, S50P,PC ENGLISH	M4
Order	 510	VQT2L15	O/I	1	T50PC, T55PC, S50PC CANADIAN FRENCH	M4
Order	 510	VQT2L26	O/I	1	T50EP, S50EP ENGLISH/POLISH	M4
Order	 510	VQT2L27	O/I	1	T50EP, S50EP CZECH/HUNGARIAN	M4
Order	 510	VQT2L23	O/I	1	T50EC, S50EC PORTUGUESE/SPANISH	M4
Order	 510	VQT2L24	O/I	1	T50EC, S50EC SWEDISH/DANISH	M4
Order	 510	VQT2L25	O/I	1	T50EC, S50EC FINNISH	M4
Order	 510	VQT2L29	O/I	1	T50GC, T55GC, S50GC ENGLISH	M4
Order	 510	VQT2L30	O/I	1	T50GC, T55GC, S50GC ARABIC/PERSIAN	M4
Order	 510	VQT2L36	O/I	1	T50GK, T55GK CHINESE(SIMPLIFIED)	M4
Order	 510	VQT2L31	O/I	1	T50GA, T55GA, S50GA ENGLISH/CHINESE(TRADITIONAL)	M4
Order	 510	VQT2L32	O/I	1	T50GA, T55GA, S50GA THAI/HINDI	M4
Order	 510	VQT2L16	O/I	1	T51PU, T56PU, S50PU ENGLISH	M4
Order	 510	VQT2L17	O/I	1	T51PU,PR, T56PU, S50PU,PR SPANISH	M4

Order	 510	VQT2L35	O/I	1	S50GN ENGLISH	M4
Order	 511	VFF0568	CD-ROM(O/I)	1	T50EG,EP,EC, S50EG,EP,EC	M4
Order	 511	VFF0569	CD-ROM(O/I)	1	T50GC, T55GC, S50GC	M4
Order	 511	VFF0570	CD-ROM(O/I)	1	T50GA, T55GA, S50GA	M4