


## 5. Exploded View & Part List

### 5-1. UE32B7000WW Exploded View



**5-1-1. UE32B7000WW Parts List**

Location No.	Code No.	Description & Specification	Q'ty	S.A/S.N.A	Remark
T0003	BN96-11251E	ASSY COVER P-FRONT;UE7050 32",XE,PMMA,,S	1	S.A	
M0215	BN07-00737A	LCD-PANEL;T320FBE1-DB	1	S.A	
T0175	BN96-09470F	ASSY SPEAKER P;8ohm,4pin,15W,R:650 / L:4	1	S.A	
M0115	BN61-05486A	BRACKET-STAND LINK;UB6000 32inch,SECC,T2	1	S.N.A	
M0014	BN94-02706T	ASSY PCB MAIN-BNE;UE32B7000WWXXU	1	S.A	
M0523	BN96-11440B	ASSY STAND P-GUIDE;UB6000 32,PC+G/F,20%,	1	S.N.A	
M0013	BN96-11254B	ASSY COVER P-REAR;B7000 32,PCM T0.5,BKN-	1	S.A	
M0027	BN96-11247A	ASSY STAND P-BASE;B7000 32,PI50 X L96,GL	1	S.A	

**5-1-2. UE32B7020WW Parts List**

Location No.	Code No.	Description & Specification	Q'ty	S.A/S.N.A	Remark
T0003	BN96-11251F	ASSY COVER P-FRONT;UE7070 32",XE,PMMA,,S	1	S.A	
M0215	BN07-00737A	LCD-PANEL;T320FBE1-DB	1	S.A	
T0175	BN96-09470F	ASSY SPEAKER P;8ohm,4pin,15W,R:650 / L:4	1	S.A	
M0115	BN61-05486A	BRACKET-STAND LINK;UB6000 32inch,SECC,T2	1	S.N.A	
M0014	BN94-02706T	ASSY PCB MAIN-BNE;UE32B7000WWXXU	1	S.A	
M0523	BN96-11440B	ASSY STAND P-GUIDE;UB6000 32,PC+G/F,20%,	1	S.N.A	
M0013	BN96-11254B	ASSY COVER P-REAR;B7000 32,PCM T0.5,BKN-	1	S.A	
M0027	BN96-11247B	ASSY STAND P-BASE;B7000 32,PI50 X L96,GL	1	S.A	