


- 51 1497  
Aufstellanweisung  
(D,GB,F,I,NL)
- 51 2679  
Gebrauchsanweisung  
(F)
- 51 2680  
Programmtabelle  
(D,GB,F,I,NL,SF)
- 1) 02 5334
- 2) 02 5332



- 1) 04 5561
- 2) 01 4687
- 3) 02 5342
- 4) 02 5343
- 5) 02 5345



