




Gebrauchsanweisung
52 6674 (fr)

Aufstellanweisung
52 2698 (fr)


Programmtabelle
52 6675 (fr)

1) Blende kompl.
36 1842


Zubehör:

Bodenbefestigung
WX9756

Entkalker
46 0038



1) 2 x pro Gerät



- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
- kompl.
- 8) 16 5978

