


Service
Service
Service

32PF9531/79
32PF9531/93
32PF9531/98
37PF9531/79
37PF9531/93

37PF9531/98
37PF9631D/10
42PF9531/79
42PF9531/93
42PF9531/98

42PF9631D/10
42PF9631D/37
50PF9531/69
50PF9631D/10
50PF9631D/37

Styling Sheet



8 September 2006

Step 2K6_2006_36_A_RT.fm



©Copyright 2006 Philips Consumer Electronics B.V. Eindhoven, The Netherlands.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Safety regulations require that the set is restored to its original condition and that parts which are identical with those specified are used.

PHILIPS

Mechanical Parts List

Step 2K6				32PF9531/79	32PF9531/93	32PF9531/98	37PF9531/79	37PF9531/93	37PF9531/98	37PF9631D/10 (SJRP)	37PF9631D/10	42PF9531/79	42PF9531/93	42PF9531/98	42PF9631D/10	42PF9631D/37	50PF9531/69	50PF9631D/10	50PF9631D/37
Pos. number	Item number	12NC	Description																
1	0164	310430816932	Fixation bracket	x	x	x													
1	0164	310430817062	Fixation bracket				x	x	x	x	x								
1	0164	310430817131	Fixation bracket									x	x	x	x	x			
1	0164	310430817181	Fixation bracket														x	x	x
2	0220	310430428851	Locking part LVDS	x	x	x	x	x	x	x	x								
2	0504	310430428841	Locking part LVDS									x	x	x	x	x	x	x	
3	0233	310430813411	SSB top shielding		x	x	x	x	x			x				x			x
3	0233	310430815921	SSB top shielding							x	x				x				x
3	0233	310430813411	SSB top shielding AP/US	x	x	x	x	x	x			x	x	x		x	x		x
4	1110	310432845102	Side control	x	x	x	x	x	x	x	x								
4	1110	310432845092	Side control									x	x	x	x	x			
4	1110	310432845152	Side control														x	x	x
4	0036	310430429592	Side control bracket	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
4	0037	310430816251	Side control knobs	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
5	5223	244125710006	Loudspeaker right 10R 12W													x			x
5	5223	314113000201	Loudspeaker right 4R 15W				x	x	x	x	x	x	x	x	x				
5	5223	314113000221	Loudspeaker right 8R 15W														x	x	
5	5223	242226400576	Loudspeaker right 8R 8W	x	x	x													
6	0011	310430816172	Back cover 32"	x	x	x													
6	0011	310430816442	Back cover 37"				x	x	x	x	x								
6	0011	310430817233	Back cover 42"									x	x	x	x	x			
6	0011	310430817243	Back cover 42"													x			
6	0011	310430817283	Back cover 50"														x	x	
6	0011	310430818912	Back cover 50"																x
7	0050	310430012381	Wordmark Philips				x	x	x	x	x	x	x	x	x	x	x	x	x
7	0050	310430012401	Wordmark Philips	x	x	x													
8	0004	310430816152	Inner front 32"	x	x	x													
8	0004	310430816401	Inner front 37"				x	x	x	x	x								
8	0004	310430817211	Inner front 42"									x	x	x	x	x			
8	0004	310430817262	Inner front 50"														x	x	x
9	0003	310430816921	Outer front 32"	x	x	x													
9	0003	310430816411	Outer front 37"				x	x	x	x	x								
9	0003	310430817221	Outer front 42"									x	x	x	x				
9	0003	310430818881	Outer front 42"													x			
9	0003	310430817272	Outer front 50"														x	x	
9	0003	310430818902	Outer front 50"																x
8+9	0005	310432844203	Front 32"	x	x	x													
8+9	0005	310432844632	Front 37"				x	x	x	x	x								
8+9	0006	310432844672	Front 42"									x	x	x	x	x			
8+9	0006	310432844703	Front 50"														x	x	
8+9	0006	310432847682	Front 50"																x
10	0179	310430128041	Lightguide	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
10	1112	310432845811	Lightguide	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
10	0163	313912010171	Light sensor holder	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
12	1004	932223532682	LCD display 32" LK315T3LZ43 (SHRP)	x	x	x													
12	1004	932223583682	LCD display 37" LK370T3LZ53 (SHRP)				x	x	x	x	x								
12	1004	932223543682	PDP display 42" FPF42C128135UA-52 (FHP)									x	x	x	x				
12	1004	932224008682	PDP display 42" S42AX-YD02 (SDI)													x			
12	1004	932224025682	PDP display 50" S50HW-YD01 PP50HW-10A (SDI)														x	x	x
13	0052	310430816201	Speaker grill 32"	x	x	x													
13	0052	310430816741	Speaker grill 37"				x	x	x	x	x								
13	0052	310430817251	Speaker grill 42"									x	x	x	x				
13	0052	310430817321	Speaker grill 42"													x			
13	0052	310430817301	Speaker grill 50"														x	x	
13	0052	310430817311	Speaker grill 50"																x
14	5222	244125710006	Loudspeaker left 10R 12W													x			x
14	5222	314113000191	Loudspeaker left 4R 15W				x	x	x	x	x	x	x	x	x				
14	5222	314113000211	Loudspeaker left 8R 15W														x	x	
14	5222	242226400575	Loudspeaker left 8R 8W	x	x	x													
15	0264	310430817771	Upright stand							x	x								
15	0264	310430817811	Upright stand												x				
15	0264	310430817821	Upright stand															x	
15	0264	310430817951	Upright stand	x	x	x													
15	0264	310430817961	Upright stand				x	x	x										
15	0264	310430817971	Upright stand									x	x	x		x			
15	0264	310430817981	Upright stand														x		x
16	0261	310430817761	Base stand							x	x								
16	0261	310430817791	Base stand												x				
16	0261	310430817802	Base stand															x	
16	0261	310430817911	Base stand	x	x	x													
16	0261	310430817921	Base stand				x	x	x										
16	0261	310430817931	Base stand									x	x	x		x			
16	0261	310430817942	Base stand														x		x
17	0033	310430429311	Ambient light diffusor	x	x	x													
17	0033	310430429351	Ambient light diffusor				x	x	x	x	x								
17	0033	310430429391	Ambient light diffusor									x	x	x	x	x			

Mechanical Parts List

Step 2K6				32PF9531/79	32PF9531/93	32PF9531/98	37PF9531/79	37PF9531/93	37PF9531/98	37PF9631D/10 (SJRP)	37PF9631D/10	42PF9531/79	42PF9531/93	42PF9531/98	42PF9631D/10	42PF9631D/37	50PF9531/69	50PF9631D/10	50PF9631D/37
Pos. number	Item number	12NC	Description																
17	0033	310430429991	Ambient light diffusor														x	x	x
18	0023	310430429552	Side AV bracket	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
19	0158	310430812071	Mushroom	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	1131	272217100374	Ambient light left	x	x	x													
	1131	272217100376	Ambient light left				x	x	x	x	x								
	1131	272217100378	Ambient light left									x	x	x	x	x			
	1131	272217100404	Ambient light left														x	x	x
	1132	272217100375	Ambient light right	x	x	x													
	1132	272217100377	Ambient light right				x	x	x	x	x								
	1132	272217100379	Ambient light right									x	x	x	x	x			
	1132	272217100405	Ambient light right														x	x	x
	0160	310430126741	Interface bracket 32"	x	x	x													
	0160	310430126831	Interface bracket 37"				x	x	x	x	x								
	0161	310430814181	Interface bracket 42"									x	x	x	x				
	0161	310430814171	Interface bracket 42"														x		
	0161	310430814251	Interface bracket 50"														x	x	x
	8150	310431108082	LVDS cable									x	x	x	x				
	8150	310431108841	LVDS cable														x	x	x
	8150	310431108891	LVDS cable	x	x	x													
	8150	310431109701	LVDS cable				x	x	x	x	x								
	8194	242207000015	Mainscord AUS/NZ									x		x			x		
	8194	242207000016	Mainscord AUS/NZ	x		x	x		x										
	8193	242207000017	Mainscord CH										x						
	8193	242207098146	Mainscord CH					x											
	8191	242207098259	Mainscord EU/AP	x		x	x		x	x	x								
	8191	242207000083	Mainscord EU/AP									x		x	x		x	x	
	8192	242207098258	Mainscord UK									x		x	x		x	x	
	8192	462200400393	Mainscord UK	x		x	x		x	x	x								
	8195	242207000054	Mainscord US														x		x
	1850	242254900847	Remote control RC4401/EU	x	x	x	x	x	x	x	x	x	x	x	x		x	x	
	1850	242254900849	Remote control RC4403/LATAM														x		x
	0251	310430815402	Wall mount bracket	x	x	x	x	x	x			x	x	x			x		
	0256	310430429221	Wall spacer	x		x	x		x				x						