



C60SUNI



Terminal		A	B	D	F	G	H	L
Wire Colour		Brown	White	Black	Grey	Red	Blue	Blue
Timer Type	Crouzet Cod 38740	B4	C1	C2	A4	A2	A1	0
	Eaton Cod. 38740(8272B)	2	1	10	3	5	4	—
	Eaton Cod. 38740(8272C)	2	1	10	3	5	4	8

Key

152	-	On/Off Switch	420	-	Timer Motor
152A	-	Heat Selector Switch	443	-	Cycling Thermostat
155	-	Indicator Neon	448	-	Heater Assembly
164	-	Suppressor	481	-	Safety Thermostat
171	-	Motor Assembly			



Legenda componenti**components list**

115/A/AG	Indicator Light	Lampada spia
162	Door Switch	Micro interruttore
164	Suppressor	Filtro antidistrurbo
171	Main Motor	Motore
220	Drum	Cesto
420	Timer	Timer
443	Thermostat (Druct)	Termostato 2 temperature
	Front	
448	Heating Element	Resistenza
461	Ceramic Thermostat	Termostato sicurezza
	(Safety)	
618	Economic Switch	Interruttore
619	ON/OFF Switch	Interruttore ON/OFF
677	Electronic Module	Controllo umidità
	Assy	