



16 EXPLODED VIEWS

16.1. CASING PARTS AND MECHANISM SECTION



16.2. PACKING & ACCESSORIES SECTION



17 REPLACEMENT PARTS LIST

Notes:

*Important safety notice:

Components identified by $\triangle$ mark have special characteristics important for safety.

Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of components, be sure to use only manufactures specified parts shown in the parts list.

*Warning: This product uses a laser diode. Refer to caution statements.

*Capacity values are in microfarads (μ F) unless specified otherwise, P=Pico-farads (pF), F=Farads (F).

*Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM), 1M=1,000k (OHM).

*The marking (RTL) indicates the retention time is limited for this item. After the discontinuation of this assembly in production, it will no longer be available.

*All parts except parts mentioned [SPC] in the Remarks column are supplied from PAVCG.

*Parts mentioned [SPC] are supplied from PAVC

*The 1, 2, 3, 4, 5 in the Remarks column shows the models as follows:

1 = DMR-EX75EC-S

2 = DMR-EX75EG-S

3 = DMR-EX75EB-S

4 = DMR-EX85EB-S

5 = DMR-EX85EG-S

No indication = all models

17.1. CASING PARTS & PRINTED CIRCUIT BOARDS

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
&bblock ; 1	REPD0030A	FRONT L PCB U	1	RTL 1, 2, 3, 4, 5
&bblock ; 2	VEP73135A	DV JACK PCB UNIT	1	RTL 1, 2, 3, 4, 5
&bblock ; 3	REPD0029D	MAIN PCB UNIT	1	RTL 3, 4
■ 3	REPD0029FT	MAIN PCB UNIT	1	RTL 1,
■ 3	REPD0029CT	MAIN PCB UNIT	1	RTL 2, 5
4	RMX0364	SPACER	2	1, 2, 3, 4, 5
5	RGR0365C-H1	REAR PANEL	1	$\triangle$; 1, 2
5	RGR0365C-J1	REAR PANEL	1	$\triangle$ 3
5	RGR0365C-L1	REAR PANEL	1	$\triangle$ 4
5	RGR0365C-K1	REAR PANEL	1	$\triangle$ 5
6	RHD30111-3	SCREW	16	1, 2, 3, 4, 5
7	RHD30119-L	SCREW	16	1, 2, 3, 4, 5
8	RMA1979A	DIGITAL ANGLE A	1	1, 2, 3, 4, 5
&bblock ; 9	RFKNEX75EC	RAM DIGITAL PCB MODULE	1	RTL 1
■ 9	RFKNEX75EG	RAM DIGITAL PCB MODULE	1	RTL 2
■ 9	RFKNEX75EB	RAM DIGITAL PCB MODULE	1	RTL 3

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
■ 9	RFKNEX85EG	RAM DIGITAL PCB MODULE	1	RTL 5
■ 9	RFKNEX85EB	RAM DIGITAL PCB MODULE	1	RTL 4
10	RMQ1513	HEAT TRANSFER SHEET	1	1, 2, 3, 4, 5
11	L6FAJDAE0001	FAN MOTOR	1	1, 2, 3, 4, 5
12	RKA0144-K	FOOT RUBBER	4	1, 2, 3, 4, 5
13	RMC0672	PLATE SPRING	1	1, 2, 3, 4, 5
14	RMV0357	HEAT SINK	1	1, 2, 3, 4, 5
15	RHD32001	SCREW WITH WASHER	2	1, 2, 3, 4, 5
16	VKC0295	MINI CARD SPACER	2	1, 2, 3, 4, 5
17	RMG0704-W	DAMPER	4	1, 2, 3, 4, 5
17-1	RHD30149	SCREW	4	1, 2, 3, 4, 5
18	RYP1326-S	FRONT PANEL U	1	5
18	RYP1326A-S	FRONT PANEL U	1	4
18	RYP1325A-S	FRONT PANEL U	1	3
18	RYP1325-S	FRONT PANEL U	1	1, 2
18-1	RGK1969-S	FL ORNAMENT	1	4, 5
18-1	RGK1968A-Q	FL ORNAMENT	1	1, 2, 3,
18-2	RGK1971-S	REC BUTTON RING	1	1, 2, 3, 4, 5
18-3	RKF0753J-S	PANEL DOOR	1	4, 5
18-3	RKF0753H-S	PANEL DOOR	1	1, 2, 3
18-4	RYF0785-K	TRAY DOOR UNIT	1	4, 5
18-4	RYF0782C-K	TRAY DOOR UNIT	1	1, 2, 3
18-5	VMB3410	BLINDER SPRING	1	1, 2, 3, 4, 5
18-6	RHD26045	SCREW (PANEL)	2	1, 2, 3, 4, 5
18-7	RKF0754-K	SD BLINDER	1	1, 2, 3, 4, 5
18-8	RMB0841-1	SD LID SPRING	1	1, 2, 3, 4, 5
18-9	RMR1767-K	SD CHASSIS	1	1, 2, 3, 4, 5
19	RHD30113	SCREW TOP CASE SIDE	2	1, 2, 3, 4, 5
20	RFKV0069HDK	HDD ASSEMBLY	1	1, 2, 3
20	RFKV0071HDK	HDD ASSEMBLY	1	4, 5
21	RKM0552A-S	TOP PANEL	1	$\triangle$ 1, 2, 3, 4, 5
22	RMN0857	HDD BRACKET	1	1, 2, 3, 4, 5
23	RMC0625	TUNER GND	2	1, 2, 3, 4, 5
25	VEE0Z41	MAIN-HDD CABLE U	1	1, 2, 3, 4, 5
27	VMC1534	EARTH SPRING (T)	2	1, 2, 3, 4, 5
&bblock ; 28	VEP71110B	POWER PCB UNIT	1	RTL 1, 2, 3, 4, 5
&bblock ; 29	REPD0032A	TUNER PCB UNIT	1	RTL 2, 5
■ 29	REPD0032B	TUNER PCB UNIT	1	RTL 3, 4
■ 29	REPD0032C	TUNER PCB UNIT	1	RTL 1
30	XSN3+4FJ	SCREW (TUNER)	2	1, 2, 3, 4, 5
&bblock ; 31	REPD0031A	BACKEND PCB UNIT	1	RTL 2, 5
■ 31	REPD0031C	BACKEND PCB UNIT	1	RTL 3, 4,
■ 31	REPD0031D	BACKEND PCB UNIT	1	RTL 1,
32	VMX1336	MINI CARD SPACER	1	1, 2, 3, 4, 5
&bblock ; 34	VEP73136A	SD CARD PCB UNIT	1	1, 2, 3, 4, 5
34-1	RMR1766-K	SD CARD HOLDER	1	1, 2, 3, 4, 5
34-2	XTN2+8GFJ	SCREW	2	1, 2, 3, 4, 5
35	RMQ1514	HEAT TRANSF. SHEET D	1	1, 2, 3, 4, 5
36	VWJ1877	DIGITAL-SD FFC	1	1, 2, 3, 4, 5
37	N5EZZ0000003	ATAPI CONNECTOR UNIT	1	1, 2, 3, 4, 5
38	REZD0026	DIGITAL-HDD FFC	1	1, 2, 3, 4, 5
39	RMX0358	SLEEVE	4	1, 2, 3, 4, 5
40	RMX0359	HDD CUSHION SPACER	4	1, 2, 3, 4, 5
41	RMV0312	SHEET COVER	1	1, 2, 3, 4, 5
42	RMX0362	GEL SPACER	4	1, 2, 3, 4, 5
43	XYN3+J8FJ	SCREW	2	1, 2, 3, 4, 5
&bblock ; 44	VEP73137AB	HDMI PCB U	1	RTL 1, 2, 3, 4, 5
45	VWJ1878	DIGITAL-HDMI FFC	1	1, 2, 3, 4, 5

17.2. PACKING & ACCESSORIES PARTS

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
A1	EUR7659YM0	REMOTE CONTROL	1	2, 5
A1	EUR7659YG0	REMOTE CONTROL	1	3, 4
A1	EUR7659T40	REMOTE CONTROL	1	1
A2	UR76EC5903	BATTERY COVER	1	1, 2, 3, 4, 5
A3	RJA0043-1C	POWERCORD	1	△ 1, 2, 5
A3	K2CT3CA00004	POWERCORD UK	1	△ 3, 4
A4	K1TWACC00001	RF CABLE	2	1, 2, 3, 4, 5
A5	K1TWACA00001	RF CABLE	1	3, 4
A6	K2KA6BA00003	AV CORD	1	1, 2, 3, 4, 5
A7	RPQFD0001	ACCESSORY BOX	1	1, 2, 3, 4, 5
A8	RPFD0007	PE-BAG, 24cmx37cmx40	1	3, 4
A8	RPFD0005	PE-BAG, 28cmx41cmx40	1	1, 2, 5
A9	RPQD0003	PAD (C)	1	1, 2, 3, 4, 5
A10	RQTD0211-A	O/I BOOK ENG CONT	1	2, 5
A10	RQTD0216-A	O/I BOOK ENG CONT	1	1
A10	RQTD0214-1B	O/I BOOK ENG UK	1	3, 4
A10	RQTD0212-C	O/I BOOK FRE	1	1
A10	RQTD0210-D	O/I BOOK GER	1	2, 5
A10	RQTD0215-V	O/I BOOK ITA	1	1
A10	RQTD0213-M	O/I BOOK SPA	1	1
A10	RQCC2704	DVD-MEDIA LEAFLET	1	1, 2, 3, 4, 5
A10	RQCAD0032	QUICK START GUIDE	1	3, 4
A10	RQCAD0034	REFERENCE GUIDE	1	3, 4
A10	RQCB1293	REGISTRATION LEAFLET	1	1, 2, 5
PC1	RP67861-1	CARTON BOX	1	3
PC1	RP67860-2	CARTON BOX	1	1
PC1	RP67859-1	CARTON BOX	1	2
PC1	RP68020-2	CARTON BOX	1	4
PC1	RP68019-2	CARTON BOX	1	5
PC2	RPFD0004	MIRAMAT BAG	1	1, 2, 3, 4, 5
PC3	RPN1859A-2	CUSHION(LEFT)	1	1, 2, 3, 4, 5
PC4	RPN1859B-2	CUSHION(RIGHT)	1	1, 2, 3, 4, 5

17.3. ELECTRICAL PARTS

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C1120	ECQU2A683MLC	X2 CAPACITOR	1	△ 1, 2, 3, 4, 5
C1121	ECQU2A223MLC	EMI CAPACITOR	1	△ 1, 2, 3, 4, 5
C1122	ECKWNA102MEV	CERAMIC CAPACITOR	1	△ 1, 2, 3, 4, 5
C1123	ECKWNA102MEV	CERAMIC CAPACITOR	1	△ 1, 2, 3, 4, 5
C1125	ECKWNA102MEV	CERAMIC CAPACITOR	1	△ 1, 2, 3, 4, 5
C1143	F2B2W4700003	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1150	F2A1V6800002	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1151	F1B3D102A011	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
C1152	ECJ2VC1H331J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1153	ECJ6VB1H222K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1154	ECJ6VB1H102K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1200	F1J1E104A081	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1201	ECJ2VB1E473K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1270	F2A1C1820005	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1271	F2A1C1820005	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1272	F2A1C8210008	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1503	F2A1A2210063	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1504	F2A1E1010067	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1506	F2A1A470A388	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1508	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1509	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1510	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1511	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1512	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1515	F2A1A470A388	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1516	F2A1A4710038	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C1518	F2A0J681A550	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1519	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1520	ECJ3FB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1522	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1523	F2A1A470A388	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1524	F2A1A101A389	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1526	ECJ2FB1A225K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1527	F1H1H1020005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1528	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1529	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1530	F2A1E1010103	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1531	ECJ1VB1A334K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1532	ECJ1VB1H331K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1533	F2A0J681A550	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1534	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1535	F2A1E3310051	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1538	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1539	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1540	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1541	F2A1E1010067	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1601	F2A1E2210050	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1602	F1J1E104A081	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1603	F1J1E104A081	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1604	ECJ2VB1C474K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1605	ECJ2VC1H181J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1606	ECJ6VB1H103K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1607	F2A1A6810022	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1608	F1J1E104A081	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1701	F2A1E2210050	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1702	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1703	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1704	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1705	ECJ1VC1H181J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1706	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C1707	F2A0J6810007	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C1800	F2A1E4700048	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3001	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3002	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3003	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3004	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3005	F2A0J471A016	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3006	F2A0J471A016	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3007	F2A0J471A016	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3008	F2A1A1010072	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3009	F2A0J471A016	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3010	F2A1A1010072	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3011	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3012	F2A0J471A016	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3013	F2A1E4700048	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3014	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3015	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3016	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3017	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3018	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3019	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3020	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3021	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3022	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3023	F1H1H330A736	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3025	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3026	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3027	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3028	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3029	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3030	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3031	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3032	ECEA0JKA101B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3033	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3034	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3035	ECEA0JKA101B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3036	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3037	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3038	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C3039	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3040	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3041	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3042	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3043	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3044	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3057	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3058	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3059	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3060	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3064	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3065	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3070	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3071	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3072	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3910	F2A1V100A534	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3911	F2A1V100A534	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3914	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3915	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3916	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3917	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3918	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3919	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3928	F2A1V100A534	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3929	F2A1V100A534	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3935	F2A1E2210050	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C3951	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3952	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3953	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3954	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3955	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3956	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3957	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3958	ECJ1VB1H471K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3959	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3960	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3961	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C3962	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4005	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4006	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4008	F2A1E1010067	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4019	F2A1C220A637	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4021	F2A1C220A637	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4023	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4024	F2A1E1010067	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4025	F2A1H100A236	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4027	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4028	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4030	F1H1H472A219	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4031	F1H1H472A219	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4033	F2A1C220B173	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4034	F2A1C220B173	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4052	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4053	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4054	F2A1H100A638	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4055	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4056	F2A1C471A628	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4057	ECJ2VC1H330J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4059	ECQV1H104JL2	PLAST FILM CAPACITOR	1	1, 2, 3, 4, 5
C4060	ECJ2VC1H330J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4061	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4062	F2A1A221A206	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4063	F2A1C220B173	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4064	F2A1C220B173	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4065	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4066	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4067	F2A1E4700048	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4082	ECJ2VC1H561J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4083	ECJ2VC1H561J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C4092	F2A1E2210050	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4093	F2A1E4700048	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C4094	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56001	ECJ0EC1H221J	CHIP CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C56101	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56102	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56103	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56104	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56105	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56106	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56107	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56108	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56109	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56110	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56111	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56112	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56113	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56114	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56115	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56116	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56117	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56118	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56119	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56120	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56121	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56122	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56123	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56124	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56125	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56126	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56127	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56128	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56129	ECJ0EC1H221J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56130	F1H0J1050012	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56131	F1J0J106A014	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56132	ECJ0EB1C103K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56133	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56134	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56135	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C56140	ECJ0EB1A104K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C6801	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C6802	F1H1A225A051	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7301	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7302	ECEA0JKA101B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7303	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7304	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7305	F1H1H330A736	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7306	F1H1H330A736	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7307	F1H1H332A219	CHIP CAPACITOR	1	2, 5
C7308	ECJ1VC1H681J	CHIP CAPACITOR	1	2, 5
C7308	D0GB822JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
C7309	F1H1H332A219	CHIP CAPACITOR	1	2, 5
C7310	ECJ1VC1H681J	CHIP CAPACITOR	1	2, 5
C7311	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7312	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7313	ECJ1VF1C474Z	CHIP CAPACITOR	1	2, 5
C7314	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7314	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7315	F1H1H9R0A735	CHIP CAPACITOR	1	2, 5
C7316	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7317	ECJ1VB1H152K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7318	ECEA0JKA470B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7319	ECEA1CKA100B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7320	ECEA1CKA100B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7321	F1H1H472A219	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7322	ECJ1VF1C474Z	CHIP CAPACITOR	1	2, 5
C7323	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7325	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7327	ECJ1VB1H152K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7328	ECJ1VF1C474Z	CHIP CAPACITOR	1	2, 5
C7328	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7329	ECJ1VF1C474Z	CHIP CAPACITOR	1	2, 5
C7330	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7331	F1J1C4740012	CHIP CAPACITOR	1	2, 5
C7331	F1J1A105A003	CHIP CAPACITOR	1	1, 3, 4
C7343	ECEA0JKA101B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7402	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C7404	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7406	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7412	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7413	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7417	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7418	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7419	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7420	F2A1A2210063	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7439	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7440	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7501	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7502	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7503	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7504	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7505	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7506	ECJ1VB1H221K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7507	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7508	ECJ1VB1H221K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7509	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7510	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7511	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7512	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7513	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7515	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7516	ECJ1VC1H180J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7517	ECJ1VC1H180J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7518	ECJ1VC1H220J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7519	ECJ1VC1H180J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7520	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7522	F1H1H1010005	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7523	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7524	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7528	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7531	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7532	ECJ1VC1H100D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7534	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7541	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7542	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7543	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7544	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7546	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7547	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7551	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7554	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7555	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
C7556	ECJ1VC1H102J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7557	ECJ1VC1H102J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7558	ECJ1VC1H102J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7565	F2A1E2210050	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7569	ECQB1H392KF3	PLAST FILM CAPACITOR	1	1, 2, 3, 4, 5
C7570	F2A1V470A006	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7571	F2A1H100A003	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7572	F2A1A2210005	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7573	F2A1H100A003	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7577	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7578	ECEA0JKA221B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7584	F4D55473A013	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7585	F2A0J101A012	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7587	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7592	ECEA0JKA470B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7800	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7801	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7802	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7803	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7804	ECEA0JKA470B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7805	ECEA0JKA470B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7806	ECEA1HKA010B	ALU ELEC CAPACITOR	1	1, 2, 3, 4, 5
C7807	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7808	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7809	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7810	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7811	F1H1H330A736	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7812	F1H1H330A736	CHIP CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C7813	ECEA1CKA220B	ALU ELEC CAPACITOR	1	1, 2, 5
C7814	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7815	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7816	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7817	ECJ1VB1A105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7818	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7819	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7820	F1H1E104A030	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7821	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7822	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C7822	F1H1H2700003	CHIP CAPACITOR	1	3, 4
C9001	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9002	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9003	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9004	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9005	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9006	ECJ1VC1H020C	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9007	ECJ2FB1A225K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9008	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9009	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9010	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9011	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9012	ECJ1VC1H100C	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9012	F1H1H1200004	CHIP CAPACITOR	1	1
C9013	ECJ1VC1H100C	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9013	F1H1H1200004	CHIP CAPACITOR	1	1
C9014	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9038	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9039	ECJ1VB1H221K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9040	ECJ1VB1H221K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9042	F1H1C104A008	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9201	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9202	ECJ1VC1H102J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9203	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9204	ECJ1VF1C334Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9205	F1H1H1500009	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9206	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9207	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9208	F1H1H1500009	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9211	ECJ1VB1H152K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9212	ECJ1VC1H100C	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9303	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9305	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9306	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9307	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9308	F1H1C104A008	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9309	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9310	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9311	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9312	F1H1C104A008	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9313	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9501	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9502	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9503	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9504	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9505	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9506	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9507	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9508	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9509	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9510	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9511	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9512	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9513	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9514	F1H1H4700004	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9801	EEEA0J101P	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9802	EEEA0J101P	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9803	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9804	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9805	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9806	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9807	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9808	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
C9809	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9810	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9811	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9812	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9813	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9814	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9815	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9816	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9817	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9818	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9819	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9820	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9821	F1H1H1030007	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9822	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9823	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9824	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9825	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9826	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9827	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9828	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9829	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9830	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9831	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9832	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9833	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9834	F1H1C104A042	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9835	ECJ1VB1C105K	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9836	F1H1H1030006	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9839	ECJ1VC1H102J	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9903	F2H1C100A013	CAPACITOR	1	1, 2, 3, 4, 5
C9904	F2H1H1R0A006	CAPACITOR	1	1, 2, 3, 4, 5
C9905	F2H1H1R0A006	CAPACITOR	1	1, 2, 3, 4, 5
C9906	F2H1C100A013	CAPACITOR	1	1, 2, 3, 4, 5
C9909	ECJ1VC1H070D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9910	ECJ1VC1H070D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9911	ECJ1VC1H070D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9912	ECJ1VC1H070D	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9913	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9914	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9915	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9916	ECJ1VF1C105Z	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9917	F1H1H1510001	CHIP CAPACITOR	1	1, 2, 3, 4, 5
C9918	F1H1H1510001	CHIP CAPACITOR	1	1, 2, 3, 4, 5
CN7800	K1KB18B00012	CONNECTOR	1	1, 2, 3, 4, 5
CN9001	K1KB11B00013	CONNECTOR	1	1, 2, 3, 4, 5
CN9003	K1KB12B00030	CONNECTOR	1	1, 2, 3, 4, 5
D1140	B0EDKT000009	DIODE	1	1, 2, 3, 4, 5
D1151	B0HAGM000006	DIODE	1	1, 2, 3, 4, 5
D1152	MAZ4100NMF	DIODE	1	1, 2, 3, 4, 5
D1155	MAZ73000BC	DIODE	1	1, 2, 3, 4, 5
D1156	MA2C165001VT	DIODE	1	1, 2, 3, 4, 5
D1157	B0HADV000001	DIODE	1	1, 2, 3, 4, 5
D1270	B0JBSG000010	DIODE	1	1, 2, 3, 4, 5
D1502	MAZ40390HF	DIODE	1	1, 2, 3, 4, 5
D1504	B0JCPE000015	DIODE	1	1, 2, 3, 4, 5
D1601	B0JCPD000021	DIODE	1	1, 2, 3, 4, 5
D1701	B0JCPD000021	DIODE	1	1, 2, 3, 4, 5
D1800	MA2J11100L	CHIP DIODE	1	1, 2, 3, 4, 5
D3901	B0JDCE000002	DIODE	1	1, 2, 3, 4, 5
D4005	MA3Z142D0LG	DIODE	1	1, 2, 3, 4, 5
D4006	MA3Z142D0LG	DIODE	1	1, 2, 3, 4, 5
D56101	MA2J72800L	DIODE	1	1, 2, 3, 4, 5
D7301	MA2C165001VT	DIODE	1	1, 2, 3, 4, 5
D7501	B0BA03600021	DIODE	1	1, 2, 3, 4, 5
D7504	MAZ4220NLF	DIODE	1	1, 2, 3, 4, 5
D7505	B0AADM000003	DIODE	1	1, 2, 3, 4, 5
D7506	B0AADM000003	DIODE	1	1, 2, 3, 4, 5
D7507	B0JAMD000026	DIODE	1	1, 2, 3, 4, 5
D7508	MAZ4180NHF	DIODE	1	1, 2, 3, 4, 5
D7509	MA2C723001VT	DIODE	1	1, 2, 3, 4, 5
D7510	MA2C165001VT	DIODE	1	1, 2, 3, 4, 5
D7511	B0ACCK000005	DIODE	1	1, 2, 3, 4, 5
D7512	B0ACCK000005	DIODE	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
D7800	MAZ4300NMF	DIODE	1	1, 2, 3, 4, 5
D7801	MA2C723001VT	DIODE	1	1, 2, 3, 4, 5
D7802	MAZ409100F	DIODE	1	1, 2, 5
D9201	B0CCAB000039	DIODE	1	1, 2, 3, 4, 5
DP7501	K2BD00000145	FL DISPLAY	1	1, 2, 3, 4, 5
F1101	A5D202BK0005	FUSE	1	△ 1, 2, 3, 4, 5
FL6101	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6102	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6103	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6104	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6105	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6106	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FL6110	F1H0J1050025	CERAMIC CAPACITOR	1	1, 2, 3, 4, 5
FP6101	K1MN40AA0082	CONNECTOR	1	1, 2, 3, 4, 5
IC1150	C0DACZH00017	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1200	C0DAEMB00003	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1504	C0CBCYG00004	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1506	C0CBCYG00004	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1508	C0DBAJG00011	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1520	C0CBCDC00052	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1521	C0CBCBD00048	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1522	C0EBJ0000143	RESET IC	1	1, 2, 3, 4, 5
IC1601	C0DBAZZ00132	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC1701	C0DBAZZ00132	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC3001	C1AB00002379	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC4009	C0ABBB000216	AMPLIFIERS	1	1, 2, 3, 4, 5
IC4011	C0DBAHD00013	VOLTAGE REGULATOR	1	1, 2, 3, 4, 5
IC4901	B3ZAZ0000017	OPTICAL LINK	1	1, 2, 3, 4, 5
IC6101	C0JBAB0002116	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC6102	C0JBAB0002116	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC6103	MN8647011	HDMI LSI IC	1	1, 2, 3, 4, 5
IC6104	C0CBCBD00048	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC6105	C0CBCDC00052	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC6107	C0JBAB000604	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC7301	C0BZB0001081	INTEGRATED CIRCUIT	1	2, 5
IC7301	C1AB00002225	INTEGRATED CIRCUIT	1	1, 3, 4
IC7401	C0CBCYG00004	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC7403	C0CBCDD00025	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC7404	RFKFM6016KT	EEPROM	1	1, 2, 5 SPC
IC7404	RFKFM6016K	EEPROM	1	3, 4 SPC
IC7405	C0CBCBC00174	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC7501	C2CBJG0000726	INTEGRATED CIRCUIT	1	2, 3, 4, 5
IC7501	C2CBY0000298	INTEGRATED CIRCUIT	1	1
IC7502	C0EBE0000504	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC7504	C0HBB0000044	DISPLAY DRIVER IC	1	1, 2, 3, 4, 5
IC7505	C0EBJ0000153	RESET IC	1	1, 2, 3, 4, 5
IC7507	C0CBCDD00025	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC7800	C0DBGY000033	POWER SUPPLY IC	1	1, 2, 5
IC7801	C0CBCDD00025	POWER SUPPLY IC	1	1, 2, 3, 4, 5
IC9001	C1AB00002208	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC9201	C0JBAB0000706	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC9301	C3ABQG000083	SDRAM	1	1, 2, 3, 4, 5
IC9302	C3FBMD000166	16 MBIT LOW VOLTAGE	1	1, 2, 3, 4, 5
IC9303	C0EBE0000504	INTEGRATED CIRCUIT	1	1, 2, 3, 4, 5
IC9901	C0ABBB000216	AMPLIFIERS	1	1, 2, 3, 4, 5
IP1501	K5H302100004	CHIP FUSE	1	1, 2, 3, 4, 5
IP1601	K5H3022A0013	FUSE	1	△ 1, 2, 3, 4, 5
IP7501	K5H7512A0010	FUSE	1	△ 1, 2, 3, 4, 5
IR7501	PNA4618M09VT	IR RECEIVER	1	1, 2, 3, 4, 5
JA1	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA10	ERJ8GEY0R00V	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA11	ERJ8GEY0R00V	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA12	ERJ8GEY0R00V	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA2	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA3	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA4	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
JA5	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
JK3001	K1U822B00003	CONNECTOR	1	1, 2, 3, 4, 5
JK3002	K2HE1YY00002	JACKS	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
JK3901	K1FB242B0005	21 PIN SCART	1	1, 2, 3, 4, 5
JK3903	K2HA306B0005	JACKS	1	1, 2, 3, 4, 5
K3092	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K3093	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7306	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7307	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7404	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7489	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7490	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
K7510	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
L1120	G0B233D00001	LINE FILTER	1	△ 1, 2, 3, 4, 5
L1270	G0A100H00025	CHOKE COIL	1	1, 2, 3, 4, 5
L1400	G0A100HA0023	CHOKE COIL	1	1, 2, 3, 4, 5
L1501	G0C2R2JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L1502	G0A330ZA0042	CHOKE COIL	1	1, 2, 3, 4, 5
L1504	G0A220GA0026	CHOKE COIL RADIAL	1	1, 2, 3, 4, 5
L1505	G0A100HA0023	CHOKE COIL	1	1, 2, 3, 4, 5
L1601	G0A150ZA0041	CHOKE COIL	1	1, 2, 3, 4, 5
L1701	G0A220ZA0041	CHOKE COIL	1	1, 2, 3, 4, 5
L4001	G0C270JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L4901	G0C220JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L56101	J0MAB0000170	BEAD CORE	1	1, 2, 3, 4, 5
L56102	J0MAB0000170	BEAD CORE	1	1, 2, 3, 4, 5
L56103	J0MAB0000170	BEAD CORE	1	1, 2, 3, 4, 5
L56104	J0MAB0000170	BEAD CORE	1	1, 2, 3, 4, 5
L7301	G0C1R0JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L7302	G0C470JA0019	CHOKE COIL AXIAL	1	2, 5
L7302	G0C2R2JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L7401	G0A220GA0026	CHOKE COIL RADIAL	1	1, 2, 3, 4, 5
L7501	G0C390JA0055	PEAKING COIL RADIAL	1	1, 2, 3, 4, 5
L7502	G0C220JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L7800	G0C220JA0019	CHOKE COIL AXIAL	1	1, 2, 3, 4, 5
L9005	J0JJC0000015	BEAD CORE	1	1, 2, 3, 4, 5
L9007	J0JJC0000015	BEAD CORE	1	1, 2, 3, 4, 5
L9008	G1CR15M00002	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9201	ELJNA2R7JFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9501	ELJFA1R0MFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9502	J0JJC0000015	BEAD CORE	1	1, 2, 3, 4, 5
L9503	ELJFA150KFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9504	ELJFA100JFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9505	ELJFA100JFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9801	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
L9802	J0JDC0000002	BEAD CORE	1	1, 2, 3, 4, 5
L9803	J0JHC0000075	BEAD CORE	1	1, 2, 3, 4, 5
L9804	ELJPA270KFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
L9903	ELJFA330KFB	CHIP INDUCTOR	1	1, 2, 3, 4, 5
LB1126	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB1502	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB1503	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB1504	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB1506	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB1508	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB1509	J0JCC0000060	BEAD CORE	1	1, 2, 3, 4, 5
LB1600	J0JHC0000048	BEAD CORE	1	1, 2, 3, 4, 5
LB1700	J0JHC0000048	BEAD CORE	1	1, 2, 3, 4, 5
LB3001	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3002	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3003	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3005	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3006	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3007	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3008	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3009	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB3010	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB3011	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB3012	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3013	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3901	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
LB3902	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
LB3903	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
LB3907	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3908	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
LB3911	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB3912	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB3913	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB6101	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6102	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6103	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6104	J0JCC0000119	FERRITE CORE	1	1, 2, 3, 4, 5
LB6105	J0JCC0000119	FERRITE CORE	1	1, 2, 3, 4, 5
LB6106	J0JCC0000119	FERRITE CORE	1	1, 2, 3, 4, 5
LB6107	J0JCC0000119	FERRITE CORE	1	1, 2, 3, 4, 5
LB6108	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6109	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6110	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6111	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6112	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6115	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6116	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6801	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB6802	J0JHC0000045	BEAD CORE	1	1, 2, 3, 4, 5
LB7301	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7302	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB7303	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7402	J0JKB0000012	BEAD CORE	1	1, 2, 3, 4, 5
LB7403	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB7405	J0JKB0000012	BEAD CORE	1	1, 2, 3, 4, 5
LB7407	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB7409	J0JKB0000003	BEAD CORE	1	1, 2, 3, 4, 5
LB7410	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB7412	J0JGC0000020	BEAD CORE	1	1, 2, 3, 4, 5
LB7413	J0JBC0000011	BEAD CORE	1	1, 2, 3, 4, 5
LB7414	J0JCC0000060	BEAD CORE	1	1, 2, 3, 4, 5
LB7501	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7502	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7507	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7508	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7509	J0JCC0000060	BEAD CORE	1	1, 2, 3, 4, 5
LB7510	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7515	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7516	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7517	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7518	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7519	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
LB7800	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB7801	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB7802	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB7803	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
LB7804	J0JHC0000032	BEAD CORE	1	1, 2, 3, 4, 5
P1101	K2AA2H000007	AC INLET	1	△ 1, 2, 3, 4, 5
P1102	K1KB23A00004	CONNECTOR	1	1, 2, 3, 4, 5
P1103	K1KA03AA0192	CONNECTOR	1	1, 2, 3, 4, 5
P1501	K1KA23A00003	CONNECTOR	1	1, 2, 3, 4, 5
P1503	K1KA04AA0180	CONNECTOR	1	1, 2, 3, 4, 5
P37001	K1KA06B00181	CONNECTOR	1	1, 2, 3, 4, 5
P37002	K2HZ104B0012	CONNECTOR	1	1, 2, 3, 4, 5
P56101	K1KY10BA0033	CONNECTOR	1	1, 2, 3, 4, 5
P56102	K1FA119E0002	CONNECTOR	1	1, 2, 3, 4, 5
P6801	K1NA09E00075	CONNECTOR	1	1, 2, 3, 4, 5
P6802	K1MY20AA0021	CONNECTOR	1	1, 2, 3, 4, 5
P7402	K1KA88A00002	CONNECTOR	1	1, 2, 3, 4, 5
P7412	K1KA12AA0288	CONNECTOR	1	1, 2, 3, 4, 5
P7413	K1KA11AA0288	CONNECTOR	1	1, 2, 3, 4, 5
P7501	K1KY10AA0107	CONNECTOR	1	1, 2, 3, 4, 5
PP7401	K1KA18AA0288	CONNECTOR	1	1, 2, 3, 4, 5
Q1200	B3PBA0000402	PHOTO COUPLER	1	△ 1, 2, 3, 4, 5
Q1501	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q1502	B1DHED000008	TRANSISTOR	1	1, 2, 3, 4, 5
Q1600	B1DHED000008	TRANSISTOR	1	1, 2, 3, 4, 5
Q1700	B1DHDD000022	TRANSISTOR	1	1, 2, 3, 4, 5
Q4006	2SD132800L	CHIP TRANSISTOR	1	1, 2, 3, 4, 5
Q4007	2SD132800L	CHIP TRANSISTOR	1	1, 2, 3, 4, 5
Q4008	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
Q4009	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q4060	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q56001	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q56002	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q56101	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q56102	B1CFHA000002	TRANSISTOR	1	1, 2, 3, 4, 5
Q56103	B1CFHA000002	TRANSISTOR	1	1, 2, 3, 4, 5
Q56104	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q56105	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7501	2SB1218A0L	SS-TRANSISTOR	1	1, 2, 3, 4, 5
Q7502	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7503	2SB1218A0L	SS-TRANSISTOR	1	1, 2, 3, 4, 5
Q7504	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7505	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7509	2SD0602ARL	TRANSISTOR	1	1, 2, 3, 4, 5
Q7510	B1BABK000001	POWER TRANSISTOR	1	1, 2, 3, 4, 5
Q7511	2SB0709A0L	PNP TRANSISTOR	1	1, 2, 3, 4, 5
Q7514	2SD0601A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7515	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7516	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7517	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7800	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q7801	2SD1819A0L	TRANSISTOR	1	1, 2, 3, 4, 5
Q9201	2SB0709A0L	PNP TRANSISTOR	1	1, 2, 3, 4, 5
QR1501	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR1502	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR1800	B1GDCFNN0002	TRANSISTOR	1	1, 2, 3, 4, 5
QR1801	B1GBCFNN0004	TRANSISTOR	1	1, 2, 3, 4, 5
QR3901	B1GDCFJJ0008	DIGITAL TRANSISTOR	1	1, 2, 3, 4, 5
QR3902	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR4002	B1GDCFJJ0008	DIGITAL TRANSISTOR	1	1, 2, 3, 4, 5
QR7401	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR7503	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR7504	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR7507	B1GBCFNN0009	TRANSISTOR	1	1, 2, 3, 4, 5
QR7508	B1GBCFJN0009	TRANSISTOR	1	1, 2, 3, 4, 5
R1150	ERJ6GEYJ180V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1151	ERJ6GEYJ682V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1152	ERJ6GEYJ103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1153	ERJ6GEYJ180V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1154	ERJ6GEYJ6912V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1155	ERJ6GEYJ752V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1156	ERJ6GEYJ613V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1157	ERJ6GEYJ511V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1158	ERX2SJR22E	METAL FILM RESISTOR	1	1, 2, 3, 4, 5
R1200	ERJ6GEYJ122V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1201	ERJ6GEYJ6822V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1205	ERJ6GEYJ224V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1206	ERJ6GEYJ242V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1207	ERJ6GEYJ103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1208	ERJ6GEYJ222V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1209	ERJ6GEYJ102V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1210	ERJ6GEYJ102V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1501	D0GB331JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1503	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1505	D0GB104JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1506	ERJ3RBD202V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1507	ERJ3RBD182V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1508	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1509	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1510	ERJ3RBD202V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1511	ERJ3RBD182V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1513	D0GB273JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1515	D1BB1201A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1516	D1BB1001A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1517	D0GB470JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1518	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1519	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1601	D1BFR0240001	RESISTOR ARRAY	1	1, 2, 3, 4, 5
R1602	ERJ6GEYJ513V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1603	ERJ6RBD202V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1604	ERJ6RBD822V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1605	ERJ6RBD272V	CHIP RESISTOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
R1701	D1BFR0240001	RESISTOR ARRAY	1	1, 2, 3, 4, 5
R1702	D0GB513JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1703	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1704	ERJ3RBD123V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1705	ERJ3RBD562V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1800	ERJ6GEYJ471V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1801	ERJ6GEYJ104V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1802	ERJ6GEYJ472V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R1803	ERJ6GEYJ103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3001	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3002	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3003	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3004	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3005	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3007	D0GB330JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3008	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3009	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3037	D0GB104JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3038	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3039	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3040	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3041	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3042	J0JCC0000103	BEAD CORE	1	1, 2, 3, 4, 5
R3048	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3054	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3055	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3056	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3057	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3058	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3059	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3060	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3061	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3062	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3901	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3902	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3903	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3904	ERDS2TJ471T	CARBON RESISTOR	1	1, 2, 3, 4, 5
R3905	D0GB153JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3906	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3912	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3913	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3914	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3918	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3919	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3920	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3921	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3922	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3923	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3924	ERDS2TJ471T	CARBON RESISTOR	1	1, 2, 3, 4, 5
R3925	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3926	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3927	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3928	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3929	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3930	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3932	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3934	D1BB75R0A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3935	D0GB750JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3975	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3976	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3983	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3984	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3987	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3988	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3989	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3990	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3991	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3992	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3993	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R3994	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4006	D0GB823JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4007	D0GB823JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4008	D0GB823JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
R4013	D0GB823JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4046	D0HB912ZA002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4047	D0HB912ZA002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4055	D0HB153ZA002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4057	D0HB153ZA002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4066	D0HB123ZA002	METAL FILM RESISTOR	1	1, 2, 3, 4, 5
R4067	D0HB123ZA002	METAL FILM RESISTOR	1	1, 2, 3, 4, 5
R4071	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4074	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4076	D0GB821JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4077	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4078	D0GB272JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4079	D0GB272JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4080	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4081	D0GB821JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4088	D0GB272JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4089	D0GB272JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4090	D0GB121JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4093	D0GB121JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4094	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4102	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4104	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R4105	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R56001	ERJ2GEJ472X	RESISTOR	1	1, 2, 3, 4, 5
R56002	ERJ2GEJ473X	RESISTOR	1	1, 2, 3, 4, 5
R56003	ERJ2GEJ225X	RESISTOR	1	1, 2, 3, 4, 5
R56004	ERJ2GEJ104X	RESISTOR	1	1, 2, 3, 4, 5
R56101	ERJ2GEJ220X	RESISTOR	1	1, 2, 3, 4, 5
R56102	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56103	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56104	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56105	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56106	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56107	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56108	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56109	ERJ2GEJ121X	RESISTOR	1	1, 2, 3, 4, 5
R56110	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56111	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56112	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56114	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56115	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56116	ERJ2GEJ101X	RESISTOR	1	1, 2, 3, 4, 5
R56117	ERJ2GEJ151X	RESISTOR	1	1, 2, 3, 4, 5
R56118	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56119	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56120	ERJ2GEJ151X	RESISTOR	1	1, 2, 3, 4, 5
R56121	ERJ2GEJ151X	RESISTOR	1	1, 2, 3, 4, 5
R56122	ERJ2GEJ151X	RESISTOR	1	1, 2, 3, 4, 5
R56123	ERJ2GEJ511X	RESISTOR	1	1, 2, 3, 4, 5
R56124	ERJ2GEJ103X	RESISTOR	1	1, 2, 3, 4, 5
R56125	ERJ2GEJ202X	RESISTOR	1	1, 2, 3, 4, 5
R56126	ERJ2GEJ202X	RESISTOR	1	1, 2, 3, 4, 5
R56127	ERJ2GEJ103X	RESISTOR	1	1, 2, 3, 4, 5
R56128	ERJ2GEJ202X	RESISTOR	1	1, 2, 3, 4, 5
R56129	ERJ2GEJ202X	RESISTOR	1	1, 2, 3, 4, 5
R56130	ERJ2GEJ273X	RESISTOR	1	1, 2, 3, 4, 5
R56131	ERJ2GEJ221X	RESISTOR	1	1, 2, 3, 4, 5
R56132	ERJ2GEJ224X	RESISTOR	1	1, 2, 3, 4, 5
R56133	ERJ2GEJ104X	RESISTOR	1	1, 2, 3, 4, 5
R56134	ERJ2GEJ470X	RESISTOR	1	1, 2, 3, 4, 5
R56135	ERJ2GEJ470X	RESISTOR	1	1, 2, 3, 4, 5
R56137	ERJ2GE0R00X	RESISTOR	1	1, 2, 3, 4, 5
R56138	ERJ2GE0R00X	RESISTOR	1	1, 2, 3, 4, 5
R56139	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56140	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56142	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56143	ERJ2GEJ330X	RESISTOR	1	1, 2, 3, 4, 5
R56144	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56145	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56146	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56147	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56148	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56149	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
R56150	ERJ2GEJ8R2X	RESISTOR	1	1, 2, 3, 4, 5
R56151	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56152	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56153	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56154	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56155	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56156	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56157	ERJ2GEJ820X	RESISTOR	1	1, 2, 3, 4, 5
R56158	ERJ2GEJ152X	RESISTOR	1	1, 2, 3, 4, 5
R56159	ERJ2GEJ332X	RESISTOR	1	1, 2, 3, 4, 5
R56160	ERJ2GEJ223X	RESISTOR	1	1, 2, 3, 4, 5
R56161	ERJ2GEJ470X	RESISTOR	1	1, 2, 3, 4, 5
R6801	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R6802	D0GB220JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R6803	D0GB220JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R6804	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R6805	D0GB123JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R6807	D0GB223JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7301	D0GB912JA057	CHIP RESISTOR	1	2, 5
R7302	D0GB122JA057	CHIP RESISTOR	1	2, 5
R7302	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7303	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7304	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7305	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7306	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7307	D0GB562JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7309	D0GB273JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7310	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7310	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7311	D0GB752JA057	CHIP RESISTOR	1	2, 5
R7312	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7312	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7313	D0GB332JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7313	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7314	D0GB332JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7314	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7315	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7315	D0GB221JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7316	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7316	D0GB221JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7328	D0GB682JA057	CHIP RESISTOR	1	2, 5
R7328	D0GB221JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7329	D0GB682JA057	CHIP RESISTOR	1	2, 5
R7329	D0GB221JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7402	D0GB153JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7406	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7410	D0GB821JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7411	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7412	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7421	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7422	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7444	ERJ3GEYJ300V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7445	ERJ3RBD682V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7446	ERJ3RBD202V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7501	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7502	D0GB392JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7503	D0GB104JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7504	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7505	D1BB10020004	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7506	D0GB104JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7507	ERJ3GEYF472V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7509	D0GB331JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7510	D0GB331JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7512	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7513	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7514	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7516	D0GB220JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7517	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7518	D0GB273JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7519	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7520	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7521	D0GB473JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R7522	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5

86

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
R9242	D0GB560JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9243	D0GB560JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9244	D0GB560JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9245	D0GB560JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9246	D0GB560JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9247	J0JDC0000026	BEAD CORE	1	1, 2, 3, 4, 5
R9249	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9250	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9254	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9271	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9272	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9301	D0GB330JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9302	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9303	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9305	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9306	D0GB472JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9307	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9308	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9310	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9311	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9312	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9313	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9314	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9315	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9316	D0GB820JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9317	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9318	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9319	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9320	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9322	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9323	D0GB102JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9501	D1BB10020004	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9502	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9503	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9504	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9505	D1BB2000A010	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9506	D1BB33000002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9507	D1BB33000002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9508	D1BB33000002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9509	D1BB33000002	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9801	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9802	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9803	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9804	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9805	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9806	D0GB101JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9903	D0GB240JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9904	D0GB240JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9905	D0GB240JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9906	D0GB240JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9907	ERJ3RBD103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9908	ERJ3RBD103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9909	ERJ3RBD103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9910	ERJ3RBD103V	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9911	ERJ3RED204V	RESISTOR	1	1, 2, 3, 4, 5
R9912	ERJ3RED204V	RESISTOR	1	1, 2, 3, 4, 5
R9915	ERJ3RED204V	RESISTOR	1	1, 2, 3, 4, 5
R9916	ERJ3RED204V	RESISTOR	1	1, 2, 3, 4, 5
R9917	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9918	D0GB103JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9919	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
R9920	D0GB471JA057	CHIP RESISTOR	1	1, 2, 3, 4, 5
RX6101	D1H83304A024	RESISTOR ARRAY	1	1, 2, 3, 4, 5
RX6102	D1H83304A024	RESISTOR ARRAY	1	1, 2, 3, 4, 5
RX6801	EXB38V220JV	RESISTOR ARRAY	1	1, 2, 3, 4, 5
RX6802	EXB38V123JV	RESISTOR ARRAY	1	1, 2, 3, 4, 5
S7002	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7500	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7501	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7503	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7504	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7505	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7506	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
S7507	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
S7508	EVQ11A04M	TOUCH SWITCH	1	1, 2, 3, 4, 5
SW1	K0L1BA000123	SWITCH	1	1, 2, 3, 4, 5
SW4	K0L1BA000078	SWITCH	1	1, 2, 3, 4, 5
T1150	ETS28BF1W6AD	TRANSFORMER	1	△ 1, 2, 3, 4, 5
T7501	G4D1A0000117	SWITCH. TRANSFORMER	1	1, 2, 3, 4, 5
TU7800	ENG7506GF	TUNER	1	△ 2, 5
TU7800	ENG7507GF	TUNER	1	△ 3, 4
TU7800	ENG7508GF	TUNER	1	△ 1
VA1110	ERZVA5V471	SURGE ABSORBER	1	△ 1, 2, 3, 4, 5
VA6101	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6102	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6103	EZJZ0V800AA	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6104	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6105	EZJZ0V800AA	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6106	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6107	EZJZ0V800AA	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6108	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6109	EZJZ0V800AA	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6110	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6111	EZJZ0V800AA	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6112	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
VA6113	D4ED13900002	SURGE ABSORBER	1	1, 2, 3, 4, 5
W501	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W502	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W503	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W504	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W505	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W506	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W507	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W508	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W509	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W510	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W511	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W512	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W513	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W514	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W515	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W516	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W517	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W518	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W519	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W520	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W521	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W522	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W523	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W524	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W525	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W526	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W527	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W528	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W529	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W530	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W531	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W532	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W533	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W534	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W535	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W536	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W537	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W538	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W539	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W540	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W541	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W542	ERJ6GEY0R00Z	CHIP RESISTOR	1	1, 2, 3, 4, 5
W543	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W545	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W546	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W548	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5

Ref. No.	Part No.	Part Name & Description	PCS	Remarks
W549	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
W550	D0YBR0000020	CHIP RESISTOR	1	1, 2, 3, 4, 5
X7301	H0H400400006	CRYSTAL OSCILLATOR	1	2, 5
X7301	H0D245500016	CRYSTAL OSCILLATOR	1	1, 3, 4
X7501	H0D100500018	OSCILLATOR	1	1, 2, 3, 4, 5
X7502	H0A327200108	CRYSTAL OSCILLATOR	1	1, 2, 3, 4, 5
X9002	H0J270500100	CRYSTAL OSCILLATOR	1	1, 2, 3, 4, 5
X9201	H0J270500098	CRYSTAL OSCILLATOR	1	1, 2, 3, 4, 5
ZA1103	EYF52BCY	FUSE HOLDER	1	1, 2, 3, 4, 5
ZA1104	EYF52BCY	FUSE HOLDER	1	1, 2, 3, 4, 5
ZA1105	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZA1106	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZA1107	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZA1150	VSC5603	HEAT SINK	1	1, 2, 3, 4, 5
ZA1270	VSC5614	HEAT SINK	1	1, 2, 3, 4, 5
ZB7501	RMN0836A-1	FL HOLDER	1	1, 2, 3, 4, 5
ZJ3001	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7401	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7402	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7404	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7420	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7421	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7423	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5
ZJ7501	K9ZZ00001279	EARTH FITTING	1	1, 2, 3, 4, 5

17.4. SERVICE FIXTURE AND TOOLS

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
	RFKZ0260	Extension Cable Main PCB - RAM/Digital PCB 88 Pin	1	Same as EH50 series (SPC)
	RFKZ0216	Extension Cable Main PCB - Power PCB 23 Pin	1	Same as EH55/ EH56 series (SPC)
	RFKZ0366	Extension FFC HDMI PCB and HDD - RAM/Digital PCB 40 Pin / 500mm	2	Same as E55/E65 series (SPC)
	RFKZ0168	Extension Cable Power PCB - Fan Motor 3 Pin	1	Same as E50/E55 series (SPC)
	RFKZ0339	Extension Cable Main PCB - HDD 4 Pin	1	Same as E55/E65 series (SPC)
	JZS0484	Eject Pin	1	Same as ES15 (SPC)
	RFKZ03D01K	Lead Free Solder 0.3 mm / 100 g Reel	1	Same as ES15 (SPC)
	RFKZ06D01K	Lead Free Solder 0.6 mm / 100 g Reel	1	Same as ES15 (SPC)
	RFKZ010D01	Lead Free Solder 1.0 mm / 100 g Reel	1	Same as ES15 (SPC)
	RFKZ0316	Solder Remover Lead free 10 W temperature Solder / 180 g	1	Same as ES15 (SPC)
	RFKZ0328	Flux	1	Same as ES15 (SPC)
	RFKZ0329	Bottle of Flux	1	Same as ES15 (SPC)