

## Terra Vented&Condenser Timed / Base Dryers

- Plug the electrical connection and be sure dryer is working properly.
- Turn on dryer.
- Press “**Start / Stop**” button for a while and restart program.
- Turn off dryer.
- Adjust the rotary switch 4th program clockwise direction after airing.
- By pressing Low heat function button turn on dryer.
- Wait until “**Start / Stop**” led is blinking.
- Press “**Start / Stop**” button to follow steps of service program:
  1. All led is blinking.
  2. Controlling leds. All the leds are on and blinking.
  3. Motor is turning anti-clockwise direction.
  4. While motor is turning first level of heater is on. 1400 W ( 7 A)
  5. While motor is turning second level of heater is on. 2000 W (9,6 A)
  6. Motor is stopping. Heaters are off.
  7. Motor is turning clockwise direction.

Continuing pressing “**Start / Stop**” repeats steps 1 to 7.

