

5. Exploded View and Parts List

5-1 Assembly Chassis-----5-2

5-2 Electrical Parts List-----5-5

5-1 Assembly Chassis



Loc. No	Parts No.	Description ; Specification	Q ty	SA	Remark
OD201	AD82-00690A	A/S ASSY-CABINET FRONT;HMX-U20B,A	1	SA	HMX-U20BP
	AD82-00692A	A/S ASSY-CABINET FRONT;HMX-U20L,A	1	SA	HMX-U20LP
	AD82-00691A	A/S ASSY-CABINET FRONT;HMX-U20R,A	1	SA	HMX-U20RP
	AD82-00693A	A/S ASSY-CABINET FRONT;HMX-U20S,A	1	SA	HMX-U20SP
OD202	AD82-00694A	A/S ASSY-COMPL,COVER RIGHT-SG4F4;	1	SA	
OD203	AD82-00695A	A/S ASSY-ADHESIVE HL STAND-SG4F4;	1	SA	
OD204	AD82-00696A	A/S ASSY-COMPL,BUTTON BACK-SG4F4;	1	SA	
OD205	AD82-00697A	A/S ASSY-BUTTON LEFT-SG4F4/KRSE;H	1	SA	
OD206	AD82-00698A	A/S ASSY-COVER LEFT-SG4F4/KRSE;HM	1	SA	
OD207	AD82-00699A	A/S ASSY-COVER JACK-SG4F4/KRSE;HM	1	SA	
OD208	AD82-00700A	A/S ASSY-DEC LED POWER-SG4F4/KRSE	1	SA	
OD209	AD82-00701A	A/S ASSY-DEC BUTTON-SG4F4/KRSE;HM	1	SA	
OD210	AD82-00703A	A/S ASSY-EARTH SPEAKER-SG4F4/KRSE	1	SA	
OD211	AD82-00704A	A/S ASSY-HEAT SINK CP1-SG4F4;HMX-	1	SA	
OD213	AD82-00707A	A/S ASSY-HOLDER BATTERY-SG4F4/KRS	1	SA	
OD215	AD82-00709A	A/S ASSY-HOLDER TERMINAL-SG4F4;HM	1	SA	
OD216	AD82-00710A	A/S ASSY-HOLDER LENS RUBBER-SG4F4	1	SA	
OD217	AD82-00711A	A/S ASSY-SPRING BATT EJECT-4F4/US	1	SA	
OD218	AD82-00712A	A/S ASSY-SPRING COVER BATT-SG4F4/	1	SA	
OD219	AD82-00713A	A/S ASSY-SPACER WIRE USB-SG4F4;HM	1	SA	
OD220	AD82-00716A	A/S ASSY-STAND-SG4F4/KRSE;HMX-U20	1	SA	
OD221	AD82-00719A	A/S ASSY-SPEAKER,8;HMX-U20B,ALL,S	1	SA	
OD222	AD82-00720A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20BP
	AD82-00722A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20LP
	AD82-00721A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20RP
	AD82-00723A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20SP
OD224	AD82-00724A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,A	1	SA	
OD224	AD82-00725A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,A	2	SA	
OD224	AD82-00725A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,A	2	SA	
OD224	AD82-00725A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,A	1	SA	
OD224	AD82-00724A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,A	1	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.	1	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.	1	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.	1	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.	1	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.	1	SA	
OD226	AD82-00727A	A/S ASSY-SCR S-TPG PAN PCS 1.7X6.	2	SA	
OD226	AD82-00727A	A/S ASSY-SCR S-TPG PAN PCS 1.7X6.	1	SA	

Loc. No	Parts No.	Description ; Specification	Q ty	SA	Remark
OD227	AD82-00729A	A/S ASSY-SCR S-TPG PAN PCS 1.7X3.	1	SA	
OD227	AD82-00729A	A/S ASSY-SCR S-TPG PAN PCS 1.7X3.	1	SA	
OD228	AD82-00730A	A/S ASSY-SCR PAN PCS 1.7X2.0;HMX-	1	SA	
OD229	AD82-00735A	A/S ASSY-COMPL PWB,CP-1 F/W;HMX-U	1	SA	
OD232	AD82-00741A	A/S ASSY-COMPL PWB,TB-1;HMX-U20B,	1	SA	
OD233	AD82-00742A	A/S ASSY-COMPL PWB,TB-2;HMX-U20B,	1	SA	
OD235	AD82-00744A	A/S ASSY-FPC CA1 SV-SG4F4;HMX-U20	1	SA	
OD236	AD82-00745A	A/S ASSY-SHIELD SD SOCKET SG315/J	1	SA	
OD237	AD82-00748A	A/S ASSY-ADHESIVE CABI FRONT;HMX-	1	SA	
OD238	AD82-00749A	A/S ASSY-CABI B SV-SG4F4;HMX-U20B	1	SA	HMX-U20BP
OD239	AD82-00750A	A/S ASSY-HL MONITOR SV-SG4F4;HMX-	1	SA	
OD240	AD82-00751A	A/S ASSY-HL LENS SV-SG4F4;HMX-U20	1	SA	
OD241	AD82-00752A	A/S ASSY-UNIT LCD SV-SG4F4;HMX-U2	1	SA	
OD242	AD82-00857A	A/S ASSY-ADHESIVE COVER LEFT-SG4F	1	SA	
OD243	AD82-00858A	A/S ASSY-EARTH USB-SG4F4/KRSE;HMX	1	SA	
OD244	AD82-00860A	A/S ASSY-SPACER MOUNTING CA1-4F4;	1	SA	
OD245	AD82-00861A	A/S ASSY-SPACER EARTH SPEAKER-4F4	1	SA	
OD246	AD82-00862A	A/S ASSY-SPACER FLAP CON-SG4F4;HM	1	SA	
OD247	AD82-00864A	A/S ASSY-SPACER MONITOR C-SG4F4;H	1	SA	
OD248	AD82-00867A	A/S ASSY-SHAFT COVER BATT-SG4F4;H	1	SA	
OD249	AD82-00868A	A/S ASSY-SHIELD TAPE CA1-SG4F4;HM	1	SA	
OD250	AD82-00869A	A/S ASSY-SHIELD TAPE STAND-SG4F4;	1	SA	
OD250	AD82-00869A	A/S ASSY-SHIELD TAPE STAND-SG4F4;	1	SA	
OD252	AD82-00872A	A/S ASSY-TERMINAL BATT-SG4F4/KRSE	3	SA	
OD253	AD82-00879A	A/S ASSY-CORE,FERRITE;HMX-U20,ALL	1	SA	
OD254	AD82-00749C	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20LP
	AD82-00749B	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20RP
	AD82-00749D	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20SP
W425	AD82-00731A	A/S ASSY-SPECIAL SCREW-1.7X3.5;HM	1	SA	

5-2 Electrical Parts List

Loc.No	Part No	Description : Specification	Q'ty	(S.N.A)	Remark
CABINET					
OD080	AD82-00487A	A/S ASSY-SCREW;HMX-R10,ALL,4111924200,SC	1	SA	
OD201	AD82-00690A	A/S ASSY-CABINET FRONT;HMX-U20B,ALL,CABI	1	SA	HMX-U20BP
OD201	AD82-00692A	A/S ASSY-CABINET FRONT;HMX-U20L,A	1	SA	HMX-U20LP
OD201	AD82-00691A	A/S ASSY-CABINET FRONT;HMX-U20R,A	1	SA	HMX-U20RP
OD201	AD82-00693A	A/S ASSY-CABINET FRONT;HMX-U20S,A	1	SA	HMX-U20SP
OD202	AD82-00694A	A/S ASSY-COMPL COVER RIGHT-SG4F4;HMX-U20	1	SA	
OD203	AD82-00695A	A/S ASSY-ADHESIVE HL STAND-SG4F4;HMX-U20	1	SA	
OD204	AD82-00696A	A/S ASSY-COMPL,BUTTON BACK-SG4F4;HMX-U20	1	SA	
OD205	AD82-00697A	A/S ASSY-BUTTON LEFT-SG4F4/KRSE;HMX-U20B	1	SA	
OD206	AD82-00698A	A/S ASSY-COVER LEFT-SG4F4/KRSE;HMX-U20B,	1	SA	
OD207	AD82-00699A	A/S ASSY-COVER JACK-SG4F4/KRSE;HMX-U20B,	1	SA	
OD208	AD82-00700A	A/S ASSY-DEC LED POWER-SG4F4/KRSE;HMX-U2	1	SA	
OD209	AD82-00701A	A/S ASSY-DEC BUTTON-SG4F4/KRSE;HMX-U20B,	1	SA	
OD210	AD82-00703A	A/S ASSY-EARTH SPEAKER-SG4F4/KRSE;HMX-U2	1	SA	
OD211	AD82-00704A	A/S ASSY-HEAT SINK CP1-SG4F4;HMX-U20B,AL	1	SA	
OD212	AD82-00706A	A/S ASSY-HEAT SINK RUBBER CMOS-4F4;HMX-U	4	SA	
OD213	AD82-00707A	A/S ASSY-HOLDER BATTERY-SG4F4/KRSE;HMX-U	1	SA	
OD214	AD82-00708A	A/S ASSY-HOLDER STAND-SG4F4/KRSE;HMX-U20	1	SA	
OD215	AD82-00709A	A/S ASSY-HOLDER TERMINAL-SG4F4;HMX-U20B,	1	SA	
OD216	AD82-00710A	A/S ASSY-HOLDER LENS RUBBER-SG4F4;HMX-U2	1	SA	
OD217	AD82-00711A	A/S ASSY-SPRING BATT EJECT-4F4/USE;HMX-U	1	SA	
OD218	AD82-00712A	A/S ASSY-SPRING COVER BATT-SG4F4/K;HMX-U	1	SA	
OD219	AD82-00713A	A/S ASSY-SPACER WIRE USB-SG4F4;HMX-U20B,	1	SA	
OD220	AD82-00716A	A/S ASSY-STAND-SG4F4/KRSE;HMX-U20B,ALL,S	1	SA	
OD221	AD82-00719A	A/S ASSY-SPEAKER,8;HMX-U20B,ALL,SPEAKER,	1	SA	
OD222	AD82-00720A	A/S ASSY-COVER BATT SV-SG4F4;HMX-U20B,AL	1	SA	HMX-U20BP
OD222	AD82-00722A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20LP
OD222	AD82-00721A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20RP
OD222	AD82-00723A	A/S ASSY-COVER BATT SV-SG4F4;HMX-	1	SA	HMX-U20SP
OD224	AD82-00724A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,ALL,SCR	2	SA	
OD224	AD82-00725A	A/S ASSY-SCR TIN 1.7X3;HMX-U20B,ALL,SCR	5	SA	
OD225	AD82-00726A	A/S ASSY-SCR S-TPG PAN PCS 1.7X4.0;HMX-U	4	SA	
OD226	AD82-00727A	A/S ASSY-SCR S-TPG PAN PCS 1.7X6.0;HMX-U	3	SA	
OD227	AD82-00729A	A/S ASSY-SCR S-TPG PAN PCS 1.7X3.5;HMX-U	2	SA	
OD228	AD82-00730A	A/S ASSY-SCR PAN PCS 1.7X2.0;HMX-U20B,AL	1	SA	
OD229	AD82-00735A	A/S ASSY-COMPL PWB,CP-1 F/W;HMX-U20B,ALL	1	SA	
OD230	AD82-00738A	A/S ASSY-FUSE 32V 1A;HMX-U20B,ALL,FUSE 3	1	SA	
OD231	AD82-00739A	A/S ASSY-FUSE 32V 2.5A;HMX-U20B,ALL,FUSE	2	SA	
OD232	AD82-00741A	A/S ASSY-COMPL PWB,TB-1;HMX-U20B,ALL,COM	1	SA	
OD233	AD82-00742A	A/S ASSY-COMPL PWB,TB-2;HMX-U20B,ALL,COM	1	SA	
OD234	AD82-00743A	A/S ASSY-BATTERY,RECHARGE;HMX-U20B,ALL,B	1	SA	
OD235	AD82-00744A	A/S ASSY-FPC CA1 SV-SG4F4;HMX-U20B,ALL,F	1	SA	
OD236	AD82-00745A	A/S ASSY-SHIELD SD SOCKET SG315/J;HMX-U2	2	SA	
OD237	AD82-00748A	A/S ASSY-ADHESIVE CABI FRONT;HMX-U20B,AL	1	SA	
OD238	AD82-00749A	A/S ASSY-CABI B SV-SG4F4;HMX-U20B,ALL,CA	1	SA	HMX-U20BP
OD239	AD82-00750A	A/S ASSY-HL MONITOR SV-SG4F4;HMX-U20B,AL	1	SA	
OD240	AD82-00751A	A/S ASSY-HL LENS SV-SG4F4;HMX-U20B,ALL,H	1	SA	
OD241	AD82-00752A	A/S ASSY-UNIT LCD SV-SG4F4;HMX-U20B,ALL,	1	SA	
OD242	AD82-00857A	A/S ASSY-ADHESIVE COVER LEFT-SG4F4;HMX-U	1	SA	
OD243	AD82-00858A	A/S ASSY-EARTH USB-SG4F4/KRSE;HMX-U20,AL	1	SA	
OD244	AD82-00860A	A/S ASSY-SPACER MOUNTING CA1-4F4;HMX-U20	2	SA	
OD245	AD82-00861A	A/S ASSY-SPACER EARTH SPEAKER-4F4;HMX-U2	1	SA	
OD246	AD82-00862A	A/S ASSY-SPACER FLAP CON-SG4F4;HMX-U20,A	2	SA	
OD247	AD82-00864A	A/S ASSY-SPACER MONITOR C-SG4F4;HMX-U20,	1	SA	
OD248	AD82-00867A	A/S ASSY-SHAFT COVER BATT-SG4F4;HMX-U20,	1	SA	
OD249	AD82-00868A	A/S ASSY-SHIELD TAPE CA1-SG4F4;HMX-U20,A	1	SA	
OD250	AD82-00869A	A/S ASSY-SHIELD TAPE STAND-SG4F4;HMX-U20	1	SA	
OD251	AD82-00871A	A/S ASSY-SHIELD TAPE BATT-SG4F4;HMX-U20,	1	SA	
OD252	AD82-00872A	A/S ASSY-TERMINAL BATT-SG4F4/KRSE;HMX-U2	3	SA	
OD253	AD82-00879A	A/S ASSY-CORE,FERRITE;HMX-U20,ALL,CORE,F	1	SA	
OD254	AD82-00749C	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20LP
OD254	AD82-00749B	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20RP
OD254	AD82-00749D	A/S ASSY-ASSY,CABI B SV-SG4F4;HMX	1	SA	HMX-U20SP
W425	AD82-00731A	A/S ASSY-SPECIAL SCREW-1.7X3.5;HMX-U20B,	1	SA	
W426	AD82-00878A	A/S ASSY-SPECIAL SCREW-1.7X3.5;HMX-U20,A	1	SA	
ACCESSORIES					
C1096	AD63-04924A	STRAP-HAND;SMX-C20,LEATHER,T5.0,5,10,BLA	1	SA	
	AD43-00190A	BATTERY-PACK;JA-BH130LB,ICP663450M,Li-io	1	SA	
	AD44-00150A	ADAPTOR;AA-MA9/EUR,EUROPE,CP2,AC TO D	1	SA	EDC Only
	AD44-00150A	ADAPTOR;AA-MA9/EUR,EUROPE,CP2,AC TO D	1	SA	SEA Only
	AD44-00155A	ADAPTOR;AA-MA9/CHN,CHINA,AC TO DC,AC10	1	SA	CHN Only
	AD44-00151A	ADAPTOR;AA-MA9/XAA,AMERICA,AC TO DC,	1	SA	AAW Only
	AD44-00153A	ADAPTOR;AA-MA9/XSA,AUSTRALIA,A	1	SA	XSA Only
	AD82-00679A	A/S ASSY-CD IB;HMX-U20,PAL	1	SA	
	AD82-00689A	A/S ASSY-MULTI-AV CABLE;HMX-U20,ALL	1	SA	

Memo