3-1. KDL- 43W*C 3-1-1. Disassembly, Exploded View LCD PANEL **BT ANTENNA** (10 BRACKET, SP (14 SWITCH UNIT SPEAKER BOX ASSY (R) SHEET, THERMAL BMX BOARD (16 15 BRACKET, This part is not stocked. The purpose of indicated in this BRACKET, illustrator is just for reference BRACKET UNDER, TU (12) UNDERCOVER (6 SPEAKER BOX ASSY (L) (SM LAK) A BRACKETUNDER BRACKETSIDE LABEL, UNDER TERMINAL (TU) LABEL, SIDE TERMINAL AC LABEL, UNDER ADAPTOR ((a) TERMINAL CORD, POWER SUPPLY