

## 17MB6X FULL SOFTWARE UPDATE PROCEDURE

1. Copy these files into the empty and formatted USB.
  - \*mb6x\_en.bin
  - \*mboot.bin
  - \*usb\_auto\_update.txt
2. Unplug the 220 cable from the power socket and plug the USB to TV's USB-1 port.
3. Plug 220 cable to power socket and press OK key until the led starts blinking.
4. Sw update starts automatically when the led starts blinking.
5. Sw update is completed after led blink is done.
  - \*Sw version can be controlled from other settings or service menu.