


1260110


Vue éclatée



1260230

Vue éclatée

Matr. 40914.000



1260230


Vue éclatée

This exploded view diagram illustrates the components of a washing machine door assembly. The central element is the door drum (17), which is surrounded by various parts including the door panel (18), door gasket (14), door lock (15), door hinge (16), door latch (19), door handle (20), door knob (21), door seal (22), door latch (23), door latch (24), door latch (25), and door latch (26). The diagram also shows the door lock assembly (1), door lock (2), door lock (3), door lock (4), door lock (5), door lock (6), door lock (7), door lock (8), door lock (9), door lock (10), door lock (11), door lock (12), door lock (13), and door lock (14). The diagram is labeled with the number 1260310 in the bottom right corner.

1260310

1260410A

Vue éclatée



1260410A