SEC 5. EXPLODED VIEWS

• Items with no part number and no description are not stocked because they are seldom required for roution serv
• The construction parts of an assembled part are indicated with a collation number in the remark colum.
• Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be an

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

The components identified by mark 🔒 contain confidential information. Strictly follow the instructions whenever the components are repaired and/or replaced.

5-1. KDL-32EX700

5-1-1. CHASSIS-1



REF.NO.	PART NO.	DESCRIPTI
1	X-2547-285-1	REAR COV
1	X-2541-871-1	REAR COV
2	* 4-115-101-02	COVER, EC
3	4-169-434-01	COVER, UN
4	4-169-437-01	COVER, HC
5	4-164-305-01	BRACKET,
6	1-842-031-11	AC INLET (2
7	1-487-798-11	SWITCH UN
8	1-798-309-11	POWER SW
9	X-2546-096-1	BASE (M3A
10	4-170-477-01	COVER, NE
11	4-170-485-01	COVER, NE
12	4-170-449-01	NECK (M3A

5-1. KDL-32EX700

5-1-2. CHASSIS-2



REF.NO.		PART NO.	DES
1		4-166-898-01	BRA
2	🔒	A-1763-471-A	BAI (32 SO
2	🔒	A-1763-470-A	BAI
3		4-182-211-01	GA
4		A-1754-371-A	GE
5		4-169-442-01	BRA
6		X-2547-773-1	BRA
7		X-2547-771-1	BRA
8,9		1-826-873-41	LOU
10		A-1744-405-A	HLF
11		A-1736-860-A	HM
12		1-856-068-11	LEN
13	⚠	1-811-088-11	LCD
14		X-2541-866-1	BEZ

5-1. KDL-32EX700

5-1-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-639-01	SCREW, +BVTP 4X12 TYPE2 IT-3
□	2-580-611-01	SCREW, +PSW M6X16
▼	2-580-600-01	SCREW +PSW M4X8
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10
☆	2-580-591-01	SCREW, +PSW M3X5
★	7-685-646-79	SCREW, +BVTP 3X8 TYPE2 IT-3







5-2. KDL-40EX700

5-2-1. CHASSIS-1



REF.NO.	PART NO.	DESCRIP
1	X-2547-249-1	REAR COV
		(EXCEPT I
1	X-2541-872-1	REAR COV
		(IRAN (SHA
2	* 4-115-101-02	COVER, E
		(40EX700(
		SOUTH AF
2	4-115-101-41	COVER, E
3	X-2547-769-1	COVER, U
4	4-169-438-01	COVER, H
5	4-164-305-01	BRACKET
6	1-842-031-11	AC INLET
7	1-487-798-11	SWITCH U
8	1-798-309-11	POWER S
9	X-2546-097-1	BASE (ML
10	4-170-477-01	COVER, N
11	4-170-485-01	COVER, N
12	4-170-450-01	NECK(ML3

5-2. KDL-40EX700

5-2-2. CHASSIS-2



REF.NO.		PART NO.	DESCRIPT
1		4-166-898-01	BRACKET
2	★	A-1763-471-A	BAL COM (40EX700(SINGAPO
2	★	A-1763-470-A	BAL COM
3		4-182-211-01	GASKET
4		A-1754-371-A	GE3A UNI
5		4-169-441-01	BRACKET
6		X-2547-777-1	BRACKET
7		X-2547-775-1	BRACKET
8,9		1-826-873-41	LOUDSPE
10		A-1744-405-A	HLR MOU
11		A-1736-860-A	HMS2 MO
12		1-856-068-11	LENS
13	⚠	1-811-089-11	LCD PANE
14		X-2547-265-2	BEZEL (40

5-2. KDL-40EX700

5-2-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-639-01	SCREW, +BVTP 4X12 TYPE2 IT-3
□	2-580-611-01	SCREW, +PSW M6X16
▲	2-580-603-01	SCREW, +PSW M4X16
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10
☆	2-580-591-01	SCREW, +PSW M3X5
★	7-685-646-79	SCREW, +BVTP 3X8 TYPE2 IT-3











5-3. KDL-46EX700

5-3-1. CHASSIS-1



REF.NO.	PART NO.	DESCRIP
1	X-2541-873-1	REAR CO
2	* 4-115-101-02	COVER,
		(46EX700
		SOUTH A
2	4-115-101-41	COVER,
3	X-2547-769-1	COVER,
4	4-169-438-01	COVER,
5	4-164-305-01	BRACKE
6	1-842-031-11	AC INLET
7	1-487-798-11	SWITCH
8	1-798-309-11	POWER
9	X-2546-097-1	BASE (M
10	4-170-477-01	COVER,
11	4-170-485-01	COVER,
12	4-170-450-01	NECK (M

5-3. KDL-46EX700

5-3-2. CHASSIS-2



REF.NO.		PART NO.	D
1		4-166-898-01	BRA
2	🔒	A-1763-471-A	BAL (46E SING 46EX
2	🔒	A-1763-470-A	BAL
3		4-182-211-01	GAS
4		A-1754-366-A	GE2
5		4-169-441-01	BRA
6		X-2547-783-1	BRA
7		X-2547-780-1	BRA
8,9		1-826-873-41	LOU
10		A-1744-405-A	HLR
11		A-1736-860-A	HMS
12		1-856-068-11	LENS
13	⚠	1-811-090-11	LCD
14		X-2547-264-1	BEZ

5-3. KDL-46EX700

5-3-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-639-01	SCREW, +BVTP 4X12 TYPE2 IT-3
□	2-580-611-01	SCREW, +PSW M6X16
▲	2-580-603-01	SCREW, +PSW M4X16
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10
☆	2-580-591-01	SCREW, +PSW M3X5
★	7-685-646-79	SCREW, +BVTP 3X8 TYPE2 IT-3









5-4. KDL-52EX700

5-4-1. CHASSIS-1



REF.NO.	PART NO.	
1	X-2541-874-1	
1	X-2547-252-1	
2	* 4-115-101-02	
3	X-2547-769-1	
4	4-169-439-01	
5	4-164-305-01	
6	1-842-031-11	
7	1-487-798-11	
8	1-798-309-11	
9	X-2546-098-1	
10	4-170-479-01	
11	4-170-487-01	
12	4-170-451-01	

5-4. KDL-52EX700

5-4-2. CHASSIS-2



REF.NO.	PART NO.	DESCR
1	4-166-898-01	BRACKE
2	A-1763-471-A	BAL CO (52EX70 SINGAP
2	A-1763-470-A	BAL CO
3	4-182-211-01	GASKET
4	A-1754-366-A	GE2B U
5	4-169-441-01	BRACKE
6	X-2547-786-1	BRACKE
7	X-2547-785-1	BRACKE
8,9	1-826-873-41	LOUDSP
10	A-1744-405-A	HLR MO
11	A-1736-860-A	HMS2 M
12	1-856-068-11	LENS
13	⚠1-811-091-11	LCD PA
14	X-2547-263-1	BEZEL(5

5-4. KDL-52EX700

5-4-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-639-01	SCREW, +BVTP 4X12 TYPE2 IT-3
□	2-580-611-01	SCREW, +PSW M6X16
▲	2-580-603-01	SCREW, +PSW M4X16
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10
☆	2-580-591-01	SCREW, +PSW M3X5
★	4-685-646-79	SCREW, +BVTP 3X8 TYPE2 IT-3





5-5. KDL-60EX700

5-5-1. CHASSIS-1



REF.NO.	PART NO.
1	X-2541-875-1
2	* 4-115-101-02
3	4-169-436-01
4	4-169-440-01
5	4-164-305-01
6	1-842-104-31
7	1-487-798-11
8	1-798-309-11
9	X-2546-099-1
10	4-170-476-01
11	4-170-488-01
12	4-170-452-01

5-5. KDL-60EX700

5-5-2. CHASSIS-2



REF.NO	PART NO.	DE
1	4-166-898-01	BR
2	A-1763-471-A	BA
		NE
		GA
2	A-1763-470-A	BA
3	4-182-211-01	GA
4	1-474-211-11	ST
5	4-169-441-01	BR
6	X-2547-788-1	BR
7	X-2547-787-1	BR
8	1-826-873-41	LO
10	A-1744-405-A	HL
11	A-1736-860-A	HM
12	1-856-068-11	LE
13	1-811-092-11	LC
13	1-811-092-21	LC
14	X-2541-870-1	BE

5-5. KDL-60EX700

5-5-3. SCREWS

	PART No.	DESCRIPTION
■	2-580-639-01	SCREW, +BVTP 4X12 TYPE2 IT-3
□	2-580-611-01	SCREW, +PSW M6X16
▲	2-580-603-01	SCREW, +PSW M4X16
▽	2-580-608-01	SCREW, +PSW M5X16
●	2-580-592-01	SCREW, +PSW M3X8
○	4-159-298-01	SCREW, +PSW M4X10
☆	2-580-591-01	SCREW, +PSW M3X5
★	7-685-646-79	SCREW, +BVTP 3X8 TYPE2 IT-3







5-6. OTHER PART (KDL-32EX700)

5-6-1. MISCELLANEOUS

PART NO.	DESCRIPTION	REMARK
	(CONNECTORS)	
1-837-790-11	LEAD WIRE WITH CONNECTOR(LVDS) (CN2600-TCON(1))	
1-837-663-12	CONNECTOR ASSY (CN6003-ACSW(1))	
1-910-100-16	HARNESS ASSY (1) (CN2602, CN4300-CN002, SW, HMS2,SP(1))	
1-910-100-17	HARNESS ASSY (2) (CN6151-CN3800, CN2561,TCON(1))	
	(OTHERS)	
A-1565-554-C	R2 MOUNT	
2-580-626-01	SCREW, SP 4-4O UNC (R2 PWB)	
* 4-164-923-01	LABEL, REAR TERMINAL (32EX700(AUSTRALIA, NEW ZEALAND, SOUTH AFRICA, IRAN(SHAHAB)), GA-ANALOG))	
4-164-924-01	LABEL, REAR TERMINAL(32EX700(Hong Kong))	

5-6-2. PACKING

PART NO.	DESCRIPTION	REMARK
*4-182-605-01	CARTON,INDIVIDUAL(32OCA)	
*4-176-721-01	CUSHION, UPPER (OCA32)	
*4-176-722-01	CUSHION, LOWER (OCA32)	
* 4-188-559-01	SHEET, SLIP	
1-821-926-11	PLUG CONVERSION ADAPTOR (32EX700(AUSTRALIA, NEW ZEALAND, SOUTH AFRICA), GA-ANALOG))	
* 1-837-463-11 ⚠	POWER-SUPPLY CORD (32EX700(SOUTH AFRICA), GA-ANALOG))	
1-837-646-11 ⚠	POWER-SUPPLY CORD (32EX700(SOUTH AFRICA), GA-ANALOG))(HONG KONG)	
1-837-651-11 ⚠	POWER-SUPPLY CORD (32EX700(SOUTH AFRICA), GA-ANALOG))	

5-6-2. PACKING (continue)

PART NO.	DESCRIPTION
1-837-650-11 ⚠	POWER-SUPPLY CORD SE (32EX700(AUSTRALIA, NEW
1-837-642-11 ⚠	POWER-SUPPLY CORD SE (32EX700(SOUTH AFRICA), (IRAN(SHAHAB)

5-6-3. ACCESSORIES

PART NO.	DESCRIPTION
4-182-864-11	MANUAL, INSTRUCTION (32
4-181-157-31	MANUAL, INSTRUCTION (32EX700(AUSTRALIA, NEW SOUTH AFRICA), GA-ANAL
4-181-157-11	MANUAL, INSTRUCTION (32EX700(AUSTRALIA, NEW SOUTH AFRICA), GA-ANAL
4-181-157-21	MANUAL, INSTRUCTION (32EX700(AUSTRALIA, NEW SOUTH AFRICA), GA-ANAL
4-182-055-11	MANUAL, INSTRUCTION (32
4-182-055-21	MANUAL, INSTRUCTION (32

5-6-4. REMOTE COMMANDER

1-487-764-11	REMOTE COMMANDER (RM

5-6. OTHER PART (KDL-40EX700)

5-6-5. MISCELLANEOUS

PART NO.	DESCRIPTION	REMARK
	(CONNECTORS)	
1-837-665-12	CONNECTOR ASSY (CN6003-ACSW(1))	
1-837-704-11	FLEXIBLE FLAT CABLE 51P (CN2600-TCON(1))	
1-910-100-18	HARNESS ASSY (1)(CN2602,CN4300-CN002,SW,HMS2,SP(1	
1-910-100-19	HARNESS ASSY (2) (CN6151-CN3800, CN2561,TCON(1))	
	(OTHERS)	
A-1565-554-C	R2 MOUNT	
2-580-626-01	SCREW, SP 4-4O UNC (R2 PWB)	
* 4-164-923-01	LABEL, REAR TERMINAL (40EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE. SOUTH AFRICA, IRAN(SHAHAB),GA-ANALOG))	
4-164-924-01	LABEL, REAR TERMINAL (40EX700(Hong Kong))	
4-182-212-01	SPACER	

5-6-6. PACKING

PART NO.	DESCRIPTION	REMARK
* 4-182-604-01	CARTON,INDIVIDUAL(40OCA)	
* 4-176-746-01	CUSHION, LOWER (OCA40)	
* 4-176-745-01	CUSHION, UPPER (OCA40)	
* 4-182-692-01	CUSHION,SIDE CENTER(OCA40)	
1-821-926-11	PLUG CONVERSION ADAPTOR (40EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))	
1-822-631-11	PLUG CONVERSION ADAPTOR (40EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))	
* 1-837-463-11 ⚠	POWER-SUPPLY CORD (40EX700(SINGAPORE, SOUTH AFRICA, GA-ANALOG))	

5-6-6. PACKING (continue)

PART NO.	DESCRIPTION
1-837-646-11 ⚠	POWER-SUPPLY SOUTH AFRICA,
1-837-650-11 ⚠	POWER-SUPPLY (40EX700(AUSTR
1-837-642-12 ⚠	POWER-SUPPLY (40EX700(SINGAP IRAN (SHAHAB),
1-837-651-11 ⚠	POWER-SUPPLY (40EX700(SINGAP

5-6-7. ACCESSORIES

PART NO.	DESCRIPTION
4-182-864-11	MANUAL, INSTRU
4-181-157-11	MANUAL, INSTRU (40EX700(AUSTR SOUTH AFRICA,
4-181-157-21	MANUAL, INSTRU (40EX700(AUSTR SOUTH AFRICA,
4-181-157-31	MANUAL, INSTRU (40EX700(AUSTR SOUTH AFRICA,
4-182-055-11	MANUAL, INSTRU
4-182-055-21	MANUAL, INSTRU

5-6-8. REMOTE COMMAND

PART NO.	DESCRIPTION
1-487-764-11	REMOTE COMMA

5-6. OTHER PART (KDL-46EX700)

5-6-9. MISCELLANEOUS

PART NO.	DESCRIPTION	REMARK
	(CONNECTORS)	
1-837-666-12	CONNECTOR ASSY(CN6003-ACSW(1))	
1-837-705-11	FLEXIBLE FLAT CABLE 51P(CN2600-TCON(1))	
1-910-100-20	HARNESS ASSY (1)(CN2602,CN4300-CN002,SW,HMS2,SP(1))	
1-910-100-21	HARNESS ASSY (2)(CN6151-CN3800,CN2561,TCON(1))	
	(OTHERS)	
4-182-212-01	SPACER	
4-100-136-01	SHEET(CORE), C(46EX700(IRAN(SHAHAB))	
A-1565-554-C	R2 MOUNT (46EX700(AUSTRALIA,NEW ZEALAND,SINGAPORE, SOUTH AFRICA,GAANALOG),46EX700(HONG KONG))	
* 4-164-923-01	LABEL, REAR TERMINAL (46EX700(AUSTRALIA,NEW ZEALAND,SINGAPORE, SOUTH AFRICA,GA-ANALOG),46EX700(IRAN(SHAHAB))	
4-164-924-01	LABEL, REAR TERMINAL(46EX700(HONG KONG))	
2-580-626-01	SCREW, SP 4-4O UNC (R2 PWB)	

5-6-10. PACKING

PART NO.	DESCRIPTION	REMARK
* 3-209-296-31	BAG, PROTECTION	
* 4-182-603-01	CARTON,INDIVIDUAL(46OCA)	
* 4-176-794-01	CUSHION, LOWER (OCA46)	
* 4-176-793-01	CUSHION, UPPER (OCA46)	
4-188-559-21	SHEET, SLIP (46EX700(AUSTRALIA,NEW ZEALAND,SINGAPORE, SOUTH AFRICA,GA-ANALOG),46EX700(HONG KONG))	
* 4-176-796-01	TRAY (OCA46)	
1-821-926-11	PLUG CONVERSION ADAPTOR (46EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE,SOUTH AFRICA,GA-ANALOG))	

5-6-10. PACKING (continue)

PART NO.	DESCRIPTION
1-822-631-11	PLUG CONVERSION ADAPTOR (46EX700(AUSTRALIA,NEW ZE SINGAPORE,SOUTH AFRICA,G
* 1-837-463-11 ⚠	POWER-SUPPLY CORD 46EX700(SINGAPORE,SOUTH A
1-837-651-11 ⚠	POWER-SUPPLY CORD 46EX700(SINGAPORE,SOUTH A
1-837-646-11 ⚠	POWER-SUPPLY CORD 46EX700(SINGAPORE,SOUTH A 46EX700(HONG KONG))
1-837-650-11 ⚠	POWER-SUPPLY CORD (46EX
1-837-642-12 ⚠	POWER-SUPPLY CORD SET (46EX700(SINGAPORE, SOUTH 46EX700(IRAN(SHAHAB))

5-6-11. ACCESSORIES

PART NO.	DESCRIPTION
4-181-157-31	MANUAL, INSTRUCTION (46EX700(AUSTRALIA,NEW ZE
4-181-157-11	MANUAL, INSTRUCTION ((46EX SINGAPORE,SOUTH AFRICA,,
4-182-055-11	MANUAL, INSTRUCTION(/AC/G
4-182-864-11	MANUAL, INSTRUCTION (46EX

5-6-12. REMOTE COMMANDER

PART NO.	DESCRIPTION
1-487-764-11	REMOTE COMMANDER (RM-G

5-6. OTHER PART (KDL-52EX700)

5-6-13. MISCELLANEOUS

PART NO.	DESCRIPTION	REMARK
	(CONNECTORS)	
1-837-667-12	CONNECTOR ASSY (CN6102-ACSW(1))	
1-837-706-11	FLEXIBLE FLAT CABLE 51P(CN2600-TCON(1))	
1-910-100-22	HARNESS ASSY (1)((CN2602,CN4300-CN002, SW,HMS2,SP(1))	
1-910-100-23	HARNESS ASSY (2)CN6151-CN3800,CN2561, TCON(1)	
	(OTHERS)	
* 4-164-923-01	LABEL, REAR TERMINAL(/LB/RC(1)) (52EX700(AUSTRALIA,NEW ZEALAND,SINGAPORE, SOUTH AFRICA,GA-ANALOG))	
4-164-924-01	LABEL, REAR TERMINAL(/LB/RC(1)) (52EX700(HONG KONG))	
4-182-212-01	SPACER	
A-1777-460-A	STAND (LL3A) ASSY	
A-1565-554-C	R2 MOUNT	
2-580-626-01	SCREW, SP 4-4O UNC(R2-PWB)	

5-6-14. PACKING

PART NO.	DESCRIPTION	REMARK
* 4-176-843-01	TRAY (OCA52)	
* 4-182-602-01	CARTON,INDIVIDUAL(52OCA)	
* 4-176-841-01	CUSHION, LOWER (OCA52)	
* 4-176-840-01	CUSHION, UPPER (OCA52)	
1-821-926-11	PLUG CONVERSION ADAPTOR (52EX700(AUSTRALIA, NEW ZEALAND,SINGAPORE, SOUTH AFRICA,GA-ANALOG))	

5-6-14. PACKING (continue)

PART NO.	DESCRIPTION
1-822-631-11	PLUG CONVERSION ADAP (52EX700(AUSTRALIA,NEW SOUTH AFRICA,GA-ANALO
* 1-837-463-11 ⚠	POWER-SUPPLY CORD(52 GA-ANALOG))
1-837-651-11 ⚠	POWER-SUPPLY CORD(52 GA-ANALOG))
1-837-646-11 ⚠	POWER-SUPPLY CORD(52 ,GA-ANALOG),52EX700(HO
1-837-650-11 ⚠	POWER-SUPPLY CORD SE (52EX700(AUSTRALIA,NEW
1-837-642-12 ⚠	POWER-SUPPLY CORD SE (52EX700(SINGAPORE, SO

5-6-15. ACCESSORIES

PART NO.	DESCRIPTION
4-181-157-31	MANUAL, INSTRUCTION(52 SINGAPORE, SOUTH AFRI
4-181-157-21	MANUAL, INSTRUCTION(52 SINGAPORE, SOUTH AFRI
4-181-157-11	MANUAL, INSTRUCTION(52 SINGAPORE, SOUTH AFRI
4-182-864-11	MANUAL, INSTRUCTION(52

5-6-16. REMOTE COMMANDE

PART NO.	DESCRIPTION
1-487-764-11	REMOTE COMMANDER (R

5-4. OTHER PART
(KDL-60EX700)

5-4-17. MISCELLANEOUS

PART NO.	DESCRIPTION	REMARK
	(CONNECTORS)	
* 1-837-532-12	CONNECTOR ASSY CN6003-ACSW(1)	
* 1-837-710-11	FLEXIBLE FLAT CABLE 51P CN2600-TCON(1)	
* 1-910-100-24	HARNESS ASSY (1) CN2602,CN4300-CN002,SW,HMS2,SP(1)	
* 1-910-100-25	HARNESS ASSY (2) CN6151-CN3800,CN2561,TCON(1)	
	(OTHERS)	
4-182-212-01	SPACER	
* 4-164-923-01	LABEL, REAR TERMINAL (60EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))	
4-164-924-01	LABEL, REAR TERMINAL(60EX700(HONG KONG)	
A-1565-554-C	R2 MOUNT	
2-580-626-01	SCREW, SP 4-4O UNC (R2-PWB)	
* 4-184-461-31	SHEET, PROTECTION	

5-4-18. PACKING

PART NO.	DESCRIPTION	REMARK
* 4-182-601-01	CARTON,INDIVIDUAL(60OCA)	
* 4-176-908-01	CUSHION, LOWER (OCA60)	
* 4-176-911-01	CUSHION, LOWER TOP-FRONT (OCA6	
* 4-176-910-01	CUSHION, MIDDLE LEFT (OCA60)	
* 4-176-909-01	CUSHION, MIDDLE RIGHT (OCA60)	
* 4-176-907-01	CUSHION, UPPER (OCA60)	

5-4-18. PACKING (continue)

PART NO.	DESCRIPTION	RE
* 2-639-807-01	JOINT	
*4-176-913-01	TRAY (OCA60)	
1-837-654-11 ⚠	POWER-SUPPLY COR	
1-837-639-11 ⚠	POWER-SUPPLY COR GA-ANALOG))	
1-837-640-11 ⚠	POWER-SUPPLY COR GA-ANALOG)), 600EX	
1-837-634-11 ⚠	POWER-SUPPLY COR ((60EX700(SINGAPORE	
1-835-166-12 ⚠	POWER-SUPPLY COR ((60EX700(SINGAPORE	
* 1-837-657-11 ⚠	POWER-SUPPLY COR ((60EX700(SINGAPORE	
* 1-837-655-11 ⚠	POWER-SUPPLY COR ((60EX700(SINGAPORE	

5-4. OTHER PART (KDL-60EX700)

5-4-19. ACCESSORIES

PART NO.	DESCRIPTION	REMARK
4-181-157-31	MANUAL, INSTRUCTION	(60EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))
4-181-157-11	MANUAL, INSTRUCTION	(60EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))
4-181-157-21	MANUAL, INSTRUCTION	(60EX700(AUSTRALIA,NEW ZEALAND, SINGAPORE, SOUTH AFRICA, GA-ANALOG))
4-182-864-11	MANUAL, INSTRUCTION	(60EX700(HONG KONG))

5-4-20. REMOTE COM

PART NO.	DESCRIPTIO
1-487-764-11	REMOTE COMM

END

Sony Corporation
Sony EMCS (Malaysia) Sdn. Bhd.
TVEG

9-888-282-02

KDL-32/40/46/52/60EX700(HONG KONG,AUSTRALIA,NEW ZEALAND,SINGAPORE,SOUTH AFRICA,IRAN,GA-ANALOG AREA)

APPENDIX

CAUTI ON TO SHARP EDGE OF REAR COVER(40)



CAUTI ON TO SHARP EDGE OF REAR COVER(46)



CAUTI ON TO SHARP EDGE OF REAR COVER(52)



CAUTI ON TO SHARP EDGE OF REAR COVER(60)



Method of RC handling to open.



1. Lift up HOOK COVER a little to m
   REAR COVER and SP-BRACKET.
2. Grab REAR COVER at the bottom

Method of RC handling to open.



3. Hold REAR COVER
4. Lift up REAR COVER by both hand
   degrees.
5. Pull REAR COVER downward to r
   edge of BEZEL.



Method of RC handling to close.



1. Align the holes of REAR COVER to
   BEZEL at top edge, and insert.
2. Pushing RC at the middle of top e
   portion) can help insertion comp

Method of RC handling to close.



3. Align Close while pushing RC on t
4. Pushing Confirm screw holes ind
   aligned, and screw these holes at
   (Need to hold RC while screwing,
   moves downward due to the grav