HISTORY INFORMATION FOR THE FOLLOWING MANUAL:

Service Procedure for Panel, Board and Software Change / Upgrade

Version	Date	Subject	GN3TR <i>CHASSIS</i>
1	04/2017	1 st Issue.	KF, KFW segment



9-888-719-01

TABLE OF CONTENTS

Section Title				
1. NOTES				
1-1. Replacing Service Parts for GN3TR Series	3			
1-2. USB Memory Format	3			
1-3. USB Update file Preparation	4			
2-1. Service Procedure for Board Replacement	5			
3-1. Service Procedure for T-Con Replacement	6			
4-1. Service Procedure for Panel Module Replacement	7			
Appendix				

SECTION 1 NOTES

1-1. Replacing Service Parts for GN3TR Series

- 1. After replacing the B^{**} board, Panel, or T-Con you need to upgrade Software by using the USB memory. (Upgrade Software even if replacing the Panel only.)
- 2. Before upgrading Software, be sure to disconnect all cables.
- 3. After upgrading the version, you need to confirm the NVM Version, Model Name, Software version and Serial Number from the Service menu. (Incorrect settings affect the set's capabilities.)
- 4. When upgrading Software, be sure to download the most recent version. (If the version of Software already on the repair board is newer than the version of Software for upgrade, Software is not upgraded.)

Remark : List of (B^{**} Board); please refer to each segment Service Manual for details.

SAPL131008 - 2/8/2022 8:25 AM

1-2. USB Memory Format.

- 1. There is no special restriction on USB memory. If you connect the USB memory to the computer and it is recognized, you can use it.
- 2. The USB memory should be formatted in FAT32.



1-3. USB Update file Preparation [Making procedure]

- 1. Get a dtvota file for upgrade.
- 2. Extract dtvota file. (e.g. sony_dtvota_****_************_***.zip)

*** may differ depend on the destination.

- 3. Confirm file name. (e.g. sony_dtv*********_*******_*******.pkg)
- 4. Copy the file under root directory of USB device.

Note: The upgrade will not be performed if name of the file is modified.



2-1. Service Procedure for B-Board Replacement



3-1. Service Procedure for T-con Replacement



4-1. Service Procedure for Panel Module Replacement



Appendix



Appendix



Don't forget to press <Enter> key. Even if you don't change the setting, it must be required to press <Enter> key at each item. After above operation step, press Up/Down arrow key to choose "Start", and press <Enter> key. Wait 15sec and more to finish data transfer.

Appendix

Point	Details/Remarks/Notes
Reset Panel Operation Time	Service Mode SELF CHECK Model Information >> Self diagnosis History >> Video / Audio >> Panel / PQ >> General Setting >> Tuner >> Wiff >> 0002 FLARE REPORT 003 DCALERT 003 DCROCONDECCO 003 DCROCONDECCO 003 DCRER 003 DCRERR 004 BCRERR 005 FLORE RERR 00600000000 CONDECONDECCO 005 FLORE RERR 00600000000 CONDECONDECCO CONDECONDECCO 005 FLORE RERR CONDECONDECCO CONDECONDECCO CONDECONDECOND 0065 FLORE RERR
B 2 nd Software Upgrade condition	Condition 1: If there is no update of RCD version and recipe condition data is not changed, screen below is appears, then software update is not necessary and can be skipped. System software update Vour software is up to date. Please remove the USB device and select [OK] to ext.
	Condition 2: If RCD version is updated or recipe condition data is changed, screen below appears. Then TV will reboot when the progress bar reaches 100%, and the software upgrade will run as usual. System software update

24%

Copying update file from USB. Please wait...

Preparing for system software update. During the system software update, the TV will automatically restart. Please do not remove the USB device until an update complete message is displayed. The update may take up to minutes to complete

SAPL131008 - 2/8/2022 8:25 AM

Sony EMCS (Malaysia) Sdn. Bhd. RDCM